

DISCOVERY



Electrical troubleshooting manual

Elektrische diagnoseprocedure-handboek

Manuel de dépannage électrique

Handbuch zur Fehlersuche bei elektrischen
Bauteilen

Manuale per l'individuazione dei guasti elettrici

Manual de localización de averías eléctricas

Manual de diagnóstico de averías eléctricas



DISCOVERY

1996 Model

Contents

Section Title
i Introduction
A1 Multiport Fuel Injection (MFI-V8)
A2 Multiport Fuel Injection (MFI-T16)
A4 300Tdi
A5 300Tdi Glow Plug Control
B1 Starting and Charging
B5 Cruise Control
C1 Ignition and Shift Interlock
D1 Anti-Lock Brake System
D3 Data Link Connector
E1 Instruments
E2 Warnings and Indicators
E5 Horns
E6 Radio (except Japan)
E7 Radio (Japan)
F1 Front Wipe/Wash
F3 Rear Wipe/Wash
F8 Heated Rear Screen and Mirror Demisters
G1 Electrochromic Rear View Mirror
G4 Multi-Function Unit (MFU)
H1 Headlamps (except Japan)
H2 Headlamps (Japan)
H3 Headlamp Levelling
H4 Side Lamps
H5 Stop Lamps
H6 Direction Indicator Lamps
H7 Reversing Lamps
H9 Fog Guard Lamps
J1 Interior Lamps
J2 Cigar Lighter/Clock
K1 Blower Controls
K2 Compressor Controls
K5 Cooling Fans
L1 Power Windows
L4 Sunroof
L6 Central Locking (except Japan)
L7 Central Locking (Japan)
M1 Power Seats
M3 Power mirrors
P1 Trailer Auxiliary Socket
T1 Theft Alarm System
Y1 Power Distribution
Y2 Fuse Details
Y5 Ground Distribution
Z4 Component Location Table
Z5 Component Location Views
Z6 Connector Views
Z8 Harness Routing
Z9 Index

Published by Land Rover

© Rover Group Limited 1995
Publication Part No LRL0028ENG (2nd Edition)



INTRODUCTION

This manual is intended for use by trained Land Rover technicians as an aid to diagnosing electrical concerns.

This manual is organized into sections. Most sections contain circuit diagrams. Each section has a unique alpha-numeric code that will normally remain the same from year to year. For example, the Headlights circuit is in Section H1, with the first page of the section numbered H1-1. The following pages of this section will be numbered H1-2, H1-3, H1-4, etc. The manual does not contain any information concerning removal, refit or overhaul of electrical components or harnesses. These details are contained in the Workshop Manual. The following information forms the basis of the troubleshooting routines:

- Circuit Diagrams
- System Diagnosis Flow Charts
- Component Location Table
- Component Locations Views

Additional information, such as Circuit Operation, is also contained in the manual to aid in your understanding of how the different circuits operate.

bottom of the page. The ‘power’ labels at the top of a fuse show when the Battery, Main Light Switch, or Ignition Switch supplies power to that fuse.

Wires that connect to another circuit are shown with an arrowhead pointing in the direction of current flow. The name of the circuit that shares the wiring is provided for reference.

Wire Colour charts are no longer provided on each circuit page. One chart is provided in the SYMBOLS section of this chapter.

‘See Fuse Details’ means there are more connections to other circuits that are not shown. All such shared circuits are shown on the Fuse Details diagrams. ‘See Ground Distribution’ means there are more shared ground circuits which are shown on the Ground Distribution diagrams.

No attempt is made on the diagrams to represent components and wiring as they physically appear on the car. For example, a long length of wire is treated no differently in a diagram from one which is only a few centimetres long. The number of cavities for each connector is listed in the Component Location Table rather than illustrated. Similarly, switches and other components are shown as simply as possible, showing function only.

DESCRIPTION OF MANUAL

Circuit Operation and Diagram

The Circuit Operation information at the beginning of the section will give you an overview of how the circuit works.

The Circuit Diagrams should always be your starting point in using this Electrical Troubleshooting Manual. The diagram shows the electrical current paths when a circuit is operating properly. It is essential to understand how a circuit should work before trying to figure out why it doesn’t. Diagrams are shown with the Ignition Switch in the OFF position and other switches in the OFF or ‘at rest’ position.

Notes are provided after certain switches to clarify switch positions. Abbreviations found in the notes are explained in the Abbreviation Table found in the SYMBOLS section of this chapter.

Circuit Diagrams (schematics) break the entire electrical system into individual circuits. Electrical components that work together are shown together.

Each diagram is arranged so current flows from positive, at the top of the page, to ground, at the

Power Distribution

The Power Distribution diagrams are found in Section Y1. These diagrams show how voltage is supplied from the positive Battery terminal to the various circuits in the vehicle.

The individual Circuit Diagrams begin with a fuse or the Ignition Switch. Power Distribution shows the wiring from the Battery to the Fuse Boxes, the Ignition Switch, the Main Lighting Switch, and any circuit fuses not located in a Fuse Box.

Fuse Details

The Fuse Details diagrams are found in Section Y2. These diagrams show all the wiring between each fuse in the Fuse Boxes and the components connected to the output of the fuse. The Fuse Details diagrams are extremely helpful in locating a short circuit that causes a fuse to blow. These diagrams also aid in troubleshooting an inoperative circuit by showing a second circuit using the same fuse. If the second circuit works, then the fuse and certain wires of the inoperative circuit are good.

Ground Distribution

The Ground Distribution diagrams are found in Section Y5. These diagrams show which components share each ground point. This information can often be a timesaver when troubleshooting a poor ground.

For example, if the Fuel Pump does not run, you may suspect an open in its circuit to ground. However, if the Number Plate Lamps work, and they share the same ground point as the Fuel Pump, you know that the ground and the wire up to the common splice are good. You have learned this just by inspecting the diagram and knowing the vehicle's symptoms.

Connector Views

Connector Views are provided in section Z6. All connectors with 2 terminals or more will be shown. Pin-out tables with the appropriate wire colours will also be shown.

Component Location Table

A Component Location Table can be found in Section Z4. Except for the location of obvious components like the Left Headlight, the table lists the location of every component, connector and ground point depicted in the Circuit Diagrams. The table also gives references to Component Location Views located in Section Z5 and cross references to Workshop Manual remove and refit procedure sections. The number of cavities in each connector and the connector colour are also listed. Wires may not be used in all connector cavities.

TROUBLESHOOTING TECHNIQUE

The following five-step troubleshooting procedure is recommended.

1. Verify the Problem

Check the operation of the circuit to be sure you understand the problem. Do not begin disassembly or testing until you have narrowed down the possible causes.

2. Analyze the Circuit Diagram (schematic)

Analyze the diagram. Check circuits that share the wiring with the problem circuit. The names of shared circuits are often given on each Circuit Diagram to aid troubleshooting. Shared power and ground circuits can be found in the Power and Ground Distribution sections. Try to operate the shared circuits. If these circuits work, then the shared wiring is OK. The cause must be within the wiring used only by the problem circuit. If several circuits fail at the same time, chances are the power (fuse) or ground circuit is faulty.

3. Find the Cause

- Narrow down the possible causes.
- Before you replace a component, check power, signal, and ground wires at the component harness connector.

4. Repair the Problem

Once the specific problem is identified, make the repair. Be sure to use the correct tools and safe procedures.

5. Check the Repair

Check the operation of the repaired circuit in all modes to make sure you fixed the entire problem. If the problem was a blown fuse, be sure to test all of the circuits on that fuse. Make sure no new problems are present.

TEST EQUIPMENT

Where applicable, Land Rover—recommended testers should be used.

Voltmeter and Test Light

Use a voltmeter or test light to check for voltage. While a test light shows whether or not voltage is present, a voltmeter indicates how much voltage there is.

CAUTION: A number of circuits include solid state devices. Voltages in these circuits should be tested only with a 10 megohm or higher impedance digital

multimeter. Never use a test light on circuits that contain solid state devices. Damage to the device may result.

On circuits without solid state devices, a test light may be used to check for voltage. A test light is made up of a 12 volt bulb with a pair of leads attached. After grounding one lead, touch the other lead to various points along the circuit where voltage should be present. The bulb will come on if the voltage at the point being tested is greater than 5 volts.

Self-powered Test Light and Ohmmeter

Use a self-powered test light or ohmmeter to check for continuity. The ohmmeter shows how much resistance there is between two points along a circuit. Low resistance means good continuity.

CAUTION: Never use a self-powered test light on circuits that contain solid state devices. Damage to these devices may result.

Diodes and solid state devices in a circuit can make an ohmmeter give a false reading. To find out if a component is affecting a measurement, take one reading, reverse the leads, and take a second reading. If the readings differ, the component is affecting the measurement.

Circuits that contain solid state devices should only be tested with a 10 megohm or higher impedance digital multimeter.


A self-powered test light consists of a light bulb, battery and two leads. If the leads are touched together, the bulb will go on.

A self-powered test light is only used on an unpowered circuit. First, disconnect the battery or remove the fuse that feeds the circuit you are working on. Select two points along the circuit through which there should be continuity. Connect one lead of the self-powered test light to each point. If there is continuity, the test light's circuit will be completed and the bulb will go on.

Fused Jumper Wire


Use a fused jumper wire to bypass an open circuit. A fuse jumper wire is made up of an in-line fuse holder connected to a set of test leads. Never use a jumper wire across any load. This direct battery short will blow the fuse.

The following symbol represents a fused jumper:




SYMBOLS


The abbreviations and symbols explained here are used throughout the manual; it is necessary to know what they mean in order to use the diagrams effectively.



Potentiometer. Wiper moves by external force



Battery



Steering Column Rotary Coupler



F1 Fuse




Diode. Current flows in direction of arrow only



MF2 Maxi-Fuse®




LED



One-pole on/off switch



Bulb




Two-pole switch


Dashed line indicates mechanical connection between switches




Electronic or Solid State device




Multiple Position Switch




Permanent magnet motor (one speed)



Variable resistor. Wiper moves by external force




Permanent magnet motor (two speed)




Heating Element




Antenna




Loudspeaker or horn




Hall Effect Sensor




Coil




Solenoid







Switch is drawn into the closed position when current flows through coil




Ignition Coil


Steering Column
Horn Brush/
Slip Ring









Entire component




Part of a component



Component with screw terminals



Plug connected at component




Plug connected to connection
wire of component



Component housing connected
directly to vehicle ground



Component is disconnected.
Backprobe harness connector




Component is connected.
Backprobe harness connector




Component is disconnected.
Probe component



Component is disconnected.
Probe harness connector



Probe in-line connector



Terminal number	Designation	Terminal number	Designation
50	Battery voltage: Ignition Switch in position III	X	Switched battery voltage through the ignition load relay or accessory relay; ignition switch is in position I or II.
30	Battery voltage: supplied constantly	49	Flasher unit input
15	Battery voltage: Ignition Switch in position II or III	49a	Flasher unit output
R	Battery voltage: Ignition Switch in positions I, II	50	Start
31	Ground	56	Headlamp
		56a	High beam
		56b	Low beam
		56d	Headlamp flash
		58	Side lamps
		85	End of relay coil
		86	Start of relay coil
		87	Relay contact
		87a	Relay contact

Definition of Vehicle Component Codes

All components are identified by a letter followed by an arbitrary number assigned to the component. The letter assigned to the component indicates the type of component.

B Bulbs, Heated Screens,
 Mirror Demisters, Cigar
 Lighters, and Heated
 Washer Jets

K Relays, Solenoids,
 Speakers, and Resistors

M Motors

P Fuse Boxes and Fusible
 Links

X Switches and Sensors

Z Electronic Control Units,
 Modules, Shields, Diodes,
 and Capacitors

Wire Colours

All wires are identified by letters which indicate a certain colour. Wire colour and size will only be shown once if it does not change throughout the circuit. The following chart explains the wire colour abbreviations.

Wire Colour Chart

B - Black	P - Purple
G - Green	R - Red
K - Pink	S - Grey
L - Light	U - Blue
N - Brown	W - White
O - Orange	Y - Yellow

Previous and Next Arrows

A schematic page which follows another schematic page of the same chapter will have an arrow in the upper left hand corner. There is no arrow on the first schematic page of a chapter. Schematic pages which are followed by another schematic page will have an arrow in the lower right hand corner. If the page is the last page of the chapter, there will be a square instead of an arrow.

Page Qualifiers

Schematic pages which are specific to certain model, option or country variations will have a small “Qualifier” after the Previous Arrow in the upper left-hand corner. For example, a section might contain pages specific to petrol engines and some pages specific to diesel engines. “Petrol” will be shown in the upper left hand corner of petrol specific pages, and “Diesel” will be shown in the upper left hand corner of diesel specific pages.

Circuit Qualifiers

Certain abbreviations are used throughout the Electrical Troubleshooting Manual as circuit qualifiers. The following list explains all abbreviations used as qualifiers in the Circuit Diagrams.

ABS	Anti-Lock Braking System
LHD	Lefthand Drive
RHD	Righthand Drive
LWB	Long Wheel Base
SWB	Short Wheel Base
NAS	North American Countries
MFI–V8	Multiport Fuel Injection (MFI–V8)
MFI–T16	Multiport Fuel Injection (MFI–T16)
300 Tdi	Tdi Diesel
300 Tdi with EGR	Tdi Diesel with Exhaust Gas Recirculation (EGR)
300 Tdi without EGR	Tdi Diesel without Exhaust Gas Recirculation (EGR)
300 Tdi with EDC	Tdi Diesel with Electronic Diesel Control (EDC)
300 Tdi without EDC	Tdi Diesel without Electronic Diesel Control (EDC) (applies to Tdi Diesels with and without EGR)
SFI–V8	Sequential Multiport Fuel Injection (SFI–V8)
A/C	Air Conditioning
BBUS	Battery Backed Up Alarm Sounder (Z272)


Switch Positions

Certain abbreviations are used throughout the Electrical Troubleshooting Manual as Switch Position notes. The following list explains all abbreviations used as Switch Position notes in the Circuit Diagrams.

< 100°	Less than 100°
> 100°	More than 100°

Connectors, Grounds, and Splices are identified by a letter followed by a number. Connectors are identified by C, grounds by E, and splices by S. Some splices are contained in junction connectors. These splices are identified by the prefix "HJ" below the splice's reference number. The number assigned to the connector, ground, or splice corresponds to its location in the vehicle.

Connector, Ground, and Splice Identification by Location



CIRCUIT DIAGRAMS

- Circuit diagrams are arranged so that current flow is from the top of the diagram (current source) to the bottom of the diagram (ground).
- Only those components that work together in the circuit are shown. If only part of a component is used in the circuit, then only that part of the component is shown.
- Remember:



Entire component



Part of a component


TERMINAL NUMBER

	DESIGNATION
50	Battery voltage: Ignition Switch in position III
30	Battery voltage: supplied constantly
15	Battery voltage: Ignition Switch in position II or III
R	Battery voltage: Ignition Switch in positions I, II
31	Ground


See Introduction (i) for additional circuit diagram symbols.


DIAGNOSIS


- If the diagram is accompanied by text:
 - Read the Circuit Operation before proceeding with the electrical diagnosis.
 - Read the Troubleshooting Hints before performing the System Diagnosis.
 - Tests follow the System Diagnosis
 - When performing the System Diagnosis, be certain that all components disconnected in previous steps are reconnected unless otherwise directed.


Component is disconnected.
Backprobe harness connectorComponent is connected.
Backprobe harness connectorComponent is disconnected.
Probe componentComponent is disconnected.
Probe harness connector


Probe in-line connector

































A1 MULTIPORT FUEL INJECTION (MFI–V8)






























Z132
Engine Control
Module (ECM)











**300Tdi without
EGR**





300Tdi with EGR









































CIRCUIT OPERATION

Starting System (MFI–V8) (300 Tdi without EDC)

For vehicles equipped with Theft Alarm without Engine Immobilisation:

Putting the Ignition Switch (X134) in position III applies battery voltage to the Starter Solenoid Relay's (K137) terminal 85. With the vehicle in Park or Neutral (Automatic only) and the Theft Alarm de-activated, the Starter Solenoid Relay (K137) energises. Battery voltage is then applied directly to the Starter Solenoid (K136) and the Starter (M134) via the Engine Immobilisation Control Unit (Spider) (Z271) shorting plug.

On manual transmission vehicles, the Theft Alarm Unit (Z163) provides a ground circuit to the Starter Solenoid Relay's (K137) 86 terminal.

On automatic transmission vehicles, the Theft Alarm Unit (Z163) provides a ground circuit to the Starter Solenoid Relay's (K137) 86 terminal via the Park/Neutral Position Switch (X167).

If the theft alarm is activated, the Theft Alarm Unit (Z163) will interrupt the Starter Solenoid Relay's (K137) ground path. The Starter Solenoid Relay (K137) will remain de-energised and prevent starting the engine.

For vehicles equipped with Theft Alarm and Engine Immobilisation:

Putting the Ignition Switch (X134) in position III applies battery voltage to the Starter Solenoid Relay's (K137) terminal 85. With the vehicle in Park or Neutral (Automatic only) and the Theft Alarm de-activated, the Starter Solenoid Relay (K137) energises. Battery voltage is then applied to the Engine Immobilisation Control Unit (Spider) (Z271).

If the Theft Alarm is activated, the Engine Immobilisation Control Unit (Spider) (Z271) will interrupt the battery supply to the Starter Solenoid (K136) and the Starter (M134).

On manual transmission vehicles, the Theft Alarm Unit (Z163) provides a ground circuit to the Starter Solenoid Relay's (K137) 86 terminal.

On automatic transmission vehicles, the Theft Alarm Unit (Z163) provides a ground circuit to the Starter Solenoid Relay's (K137) 86 terminal via the Park/Neutral Position Switch (X167).

If the theft alarm is activated, the Theft Alarm Unit (Z163) will interrupt the Starter Solenoid Relay's (K137) ground path. The Starter Solenoid Relay (K137) will remain de-energised and prevent starting the engine.

For vehicles not equipped with Theft Alarm and Engine Immobilisation:

Putting the Ignition Switch (X134) in position III applies battery voltage to the Starter Solenoid Relay's (K137) terminal 85. With the vehicle in Park or Neutral (Automatic only), the Starter Solenoid Relay (K137) energises. Battery voltage is then applied directly to the Starter Solenoid (K136) and the Starter (M134) via the Engine Immobilisation Control Unit (Spider) (Z271) shorting plug.

For vehicles not equipped with Theft Alarm, a black wire is used to short pins 10 and 11 of C274.

On Japan and manual transmission vehicles, a ground path is provided directly to the Starter Solenoid Relay's (K137) 86 terminal.

On automatic transmission vehicles, a ground path is provided to the Starter Solenoid Relay's (K137) 86 terminal via the Park/Neutral Position Switch (X167).

Starting System (MFI-T16) (300 Tdi with EDC)

Putting the Ignition Switch (X134) in position III applies battery voltage to the Starter Solenoid Relay's (K137) terminal 85. With the vehicle in Park or Neutral (Automatic only) and/or the Theft Alarm de-activated, the Starter Solenoid Relay (K137) energises. Battery voltage is then applied directly to the Starter Solenoid (K136) and the Starter (M134).

On manual transmission vehicles equipped with a theft alarm, the Theft Alarm Unit (Z163) provides a ground circuit to the Starter Solenoid Relay's (K137) 86 terminal.

On automatic transmission vehicles equipped with a theft alarm, the Theft Alarm Unit (Z163) provides a ground circuit to the Starter Solenoid Relay's (K137) 86 terminal via the Park/Neutral Position Switch (X167).


If the theft alarm is activated, the Theft Alarm Unit (Z163) will interrupt the Starter Solenoid Relay's (K137) ground path. The Starter Solenoid Relay (K137) will remain de-energised and prevent starting the engine.


For vehicles not equipped with Theft Alarm, a black wire is used to short pins 10 and 11 of C274.



Charging System


When the Ignition Switch (X134) is in position II, battery voltage is applied to the charging system fault light. When the Generator (Z106) is being turned by the engine, its stator windings are excited by voltage applied to the Generator (Z106) via the charging system fault light. The Generator (Z106) begins to produce electricity in order to charge the vehicle Battery (P104). If the Generator (Z106) fails to produce power, the Generator (Z106) grounds the fault light control wire, causing the charging system fault light to glow.

The tachometer displays engine speed in rpm. Voltage pulses are taken from the Generator (Z106) and are generated when the engine drive belt turns the Generator pulley. The tachometer responds to the frequency of the voltage pulses, which increases proportionally to that of the engine speed.













MFI-T16
300Tdi with EDC









CIRCUIT OPERATION

Cruise Control Switch (MFI–V8) (MFI–T16)

(300 Tdi without EDC)

With the Cruise Control Switch (X115) on, voltage from Fuse F18 is applied to the Cruise Control ECU (Z121), Cruise Control Lockout Relay (K110) (Automatic), Speed Trip Module (Z164) (Manual), and the Steering Wheel Cruise Switches (X266) through the WY wire, Rotary Coupler (Z104) and PB wire. The Cruise Control ECU (Z121) is grounded at terminal 8 through the B wire to E201.

Cruise Control Switch (300 Tdi with EDC)

With the Ignition Switch (X134) in position II, battery voltage is applied to the Cruise Control Switch (X115) through the closed switch contacts of the Cruise Control Disable Relay (K234). The Engine Control Module (ECM) (Z132) applies ground to the coil of the Cruise Control Disable Relay (K234) if an engine fault is detected. The relay energises, opening the switch contacts. The battery supply to the Cruise Control Switch (X115) is interrupted, disabling the Cruise Control System.

With the Cruise Control Switch (X115) on, voltage from Fuse F18 is applied to the Cruise Control ECU (Z121), Cruise Control Lockout Relay (K110) (Automatic), Speed Trip Module (Z164) (Manual), and the Steering Wheel Cruise Switches (X266) through the WY wire, Rotary Coupler (Z104) and PB wire. The Cruise Control ECU (Z121) is grounded at terminal 8 through the B wire to E201.

Cruise Control Vacuum Pump (M103)

With the Cruise Control Switch (X115) on, voltage is applied to the Cruise Control Vacuum Pump (M103) through the WU wire. When a cruise speed is set, the Cruise Control ECU (Z121) applies ground through the BR wire to operate the pump motor and applies ground through the BY wire to close the normally open solenoid valve in the pump. The pump applies vacuum to the actuator.

SET/ACCEL

To set a cruise speed, the Cruise Control Switch (X115) must be on and vehicle speed must exceed 28 mph (45 km/h). When the SET/ACCEL Switch is depressed under these conditions, voltage from Fuse F18 is applied to terminal 3 of the Cruise Control ECU (Z121) through the closed Cruise

Control Switch (X115) and Steering Wheel Cruise Switches (X266), causing the vacuum pump to operate. When the SET/ACCEL Switch is released, voltage is removed from terminal 3, signalling the ECU to set the speed.

RES/DECEL

When the RES/DECEL Switch is depressed, voltage is applied to terminal 4 of the Cruise Control ECU (Z121). This voltage signals the ECU to disengage the system and the vehicle slows down. When the switch is depressed a second time, voltage is again applied to the ECU and the vehicle returns to the previously set speed.

Speed Input

Terminal 11 of the Cruise Control ECU (Z121) monitors the Vehicle Speed output signal from the Instrument Cluster (Z142) through the YK wire. This signal is a pulsing voltage, and its frequency changes with vehicle speed.

System Disable

The Cruise Control System can be disabled in one of four ways:

6. The Cruise Control Switch (X115) is put in the 0 position, removing power from the Cruise Control ECU (Z121) and vacuum pump and erasing the set speed memory.
7. The RES/DECEL Switch is depressed, signalling the Cruise Control ECU (Z121) to disengage the system.
8. The brake pedal is depressed and a vacuum valve in the Brake Switch Vent Valve opens (X112). This vents vacuum to the actuator valve and releases the throttle.
9. The Voltage applied to Cruise Control ECU (Z121) terminal 9 is interrupted, causing the Cruise Control ECU (Z121) to turn off the vacuum pump and de-energise the vacuum solenoid valve. This voltage path is interrupted when the brake pedal is depressed, the Clutch Pedal is depressed, or the vehicle is in Park or Neutral. With the brake pedal depressed, the Brake Switch Vent Valve (X112) moves to 1 and the circuit is interrupted. With the vehicle in Park or Neutral, the Park/Neutral Position Switch (X167) energises the Cruise Control Lockout Relay (K110) by grounding the relay's coil. The relay then opens its contacts, interrupting the circuit. With the clutch pedal depressed, the Clutch Switch (X200) moves to 1 and the circuit is interrupted.


NOTE: For 300 Tdi vehicles equipped with an EDC Diesel engine, the Cruise Control System can also be disabled by the Engine Control Module (ECM) (Z132) when an engine fault has been detected.




Road Test


CAUTION: DO NOT ENGAGE CRUISE CONTROL WHEN VEHICLE IS BEING USED IN LOW TRANSFER GEARS


WARNING: The use of cruise control is not recommended on winding, snow covered or slippery roads, or in heavy traffic conditions where a constant speed cannot be maintained.


1. Start the engine and depress the Cruise Control Switch (X115) to activate the Cruise Control System. Accelerate to approximately 30 mph (50 km/h) and press the SET/ACCEL Switch. Immediately release the switch and remove foot from the accelerator pedal. The vehicle should maintain the speed at which the SET/ACCEL Switch was pressed.
2. Press the SET/ACCEL Switch and hold at that position. The vehicle should accelerate smoothly until the switch is released. The vehicle should now maintain the new speed at which the SET/ACCEL Switch was released.
3. Press the RES/DECEL Switch while the vehicle is in the cruise control mode. The cruise control should disengage. Slow to approximately 35 mph (55 km/h) and press the RES/DECEL Switch. Immediately release the switch and remove foot from the accelerator. The vehicle should smoothly accelerate to the previously set speed. Increase speed using the accelerator pedal. Releasing the pedal should return the vehicle to the previously set speed.
4. Depressing the brake pedal should immediately disengage the Cruise Control System and return the vehicle to driver's control at accelerator pedal. Press the RES/DECEL Switch and the vehicle should accelerate to the previously set speed without operation of the accelerator pedal.
5. Press the RES/DECEL Switch and allow the vehicle to decelerate to below 26 mph (42 km/h). Press the RES/DECEL Switch and the Cruise Control System should remain disengaged.
6. Press the SET/ACCEL Switch below 28 mph (45 km/h) and the Cruise Control System should remain disengaged. Accelerate the vehicle above 28 mph (45 km/h), press the RES/DECEL Switch and remove foot from the accelerator pedal. The vehicle should smoothly adjust to the previously memorized speed.
7. Pressing the Cruise Control Switch (X115) should immediately disengage the Cruise Control System and erase the previously set speed from ECU memory.


















Manual Trans-mission

B5-9



PW

1 C2035



X200
Clutch Pedal
Position Switch

[1] Clutch Pedal
Depressed

2 C2035

P


6 C218

P

5 C218

PY

1 C2005



X112
Brake Switch
Vent Valve

[1] Brake Pedal
Depressed

2 C2005

PG

9 C284



Z121
Cruise Control
ECU



CIRCUIT OPERATION

Selector Interlock

When the gear selector is in the park position, the solenoid inside the Transmission Range Selector Switch (Z110) is de-energised and prevents the selector from being moved into another gear. To free the selector, the Ignition Switch (X134) must be in position II and the brake pedal must be depressed. When this occurs, voltage from Fuse F1 is applied to the Transmission Range Selector through the closed Stop Lamp Switch (X168). The solenoid inside the Transmission Range Selector Switch is grounded at E201 through the selector switch, the KS wire and the B wire. The solenoid now energises, freeing the selector.

Ignition Key Interlock

On vehicles equipped with the interlock safety feature, the vehicle must be in park and the transfer case in high or low gear before the key can be removed from the ignition. If the gear selector or transfer gear is out of gear, the key must be cycled before removal.

If the vehicle is not in park, voltage from Fuse F12 is applied to the Key Barrel Switch (X230) through the closed contacts of the Transmission Range Selector Switch (Z110). When the ignition switch is placed in the 0 position, the Key Barrel Switch (X230) closes to energise the solenoid and prevent key removal.

If the key is in the ignition and the transfer box is in the neutral position, Interlock Relay 1 (K153) is de-energised since the relay coil is not grounded by the Transfer Box Position Switch (X175). When the relay is de-energised, voltage is applied to the Key Barrel Switch (X230) through the relay's switch contacts and the Key-In Switch (X229) causing the solenoid to energise and prevent key removal.


If the Transfer Box is in the "H" or "L" position, the Interlock Relay 1 (K153) is energised, since the relay coil is grounded by the Transfer Box Position Switch (X175). When the relay is energised, voltage to the Key Barrel Switch (X230) is interrupted. If the vehicle is in Park, the Transmission Range Selector Switch (Z110) contacts are open. When the switch contacts are open, voltage to the Key Barrel Switch (X230) is also interrupted. The Ignition Key Lock Solenoid (K191) is then disabled, allowing removal of the key.


Transfer Box Interlock


The Transfer Box Interlock safety feature is designed to prevent the transfer case shifter from being shifted out of "H" or "L" unless the vehicle's gear selector is in the neutral position.


When the gear selector is placed in the neutral position, voltage is applied to the Interlock Relay 2's coil through the Transmission Range Selector Switch (Z110). The relay's coil is grounded through the Park/Neutral Position Switch (X167).


Interlock Relay 2 now energises and applies voltage from Fuse F13 to the Transfer Box Solenoid (K161). When the Transfer Box Solenoid (K161) is energised, the transfer box shifter can be operated.































X318
Data Link Con-
nector (OBDII)



With ABS

Without ABS



With ABS


Without ABS

MFI-T16

MFI-V8

300Tdi with EDC

300Tdi without EDC



CIRCUIT OPERATION

Speedometer

The Vehicle Speed Sensor (X190) sends a signal to the speedometer in the form of voltage pulses. The pulses are filtered by a Vehicle Speed Sensor Buffer inside the speedometer. The voltage alternates between battery voltage and 0 volts 6 times per wheel revolution. The speed sensor signal is also sent to the Cruise Control ECU (Z121), Multifunction Unit (MFU) (Z148) (Persian Gulf States), and the Engine Control Module (Z132).

Tachometer


The tachometer displays engine speed in rpm. Voltage pulses are taken from the Generator (Z106) and are generated when the engine drive belt turns the Generator pulley. The tachometer responds to the frequency of the voltage pulses, which increases proportionally to that of the engine speed.


Engine Coolant Temperature Gauge

The Engine Coolant Temperature Gauge Sensor (X114) has approximately 136 ohms resistance when the coolant temperature is low. As coolant temperature increases, the resistance of the sensor decreases. This varying resistance causes the current through the sensor to change and the gauge to register the temperature. When the coolant is hot, the resistance of the sensor is approximately 17 ohms.

Fuel Gauge


When the fuel tank level is low, the resistance of the fuel gauge sender is approximately 245 ohms. As the fuel level increases, the resistance of the sender decreases, causing the gauge to register the change. When the fuel tank is full, the resistance of the sender is approximately 19 ohms. When the fuel gauge sender's resistance falls below approximately 25 ohms (6 liters/1.5 US gallons), the fuel warning light will illuminate to warn the driver.





With Cruise Con-trol

Without Cruise Control



With Cruise Con-trol

Without Cruise Control

MFI-V8

MFI-T16

300Tdi without EDC

12 C217

300Tdi with EDC

With Cruise Con-trol

Without Cruise Control


Not used


6 C243



Z132 Engine Control Module (ECM)

29 C243

Z132 Engine Control Module (ECM)








- [3] Fuel Gauge
- [4] Temperature Gauge
- [8] CPU
- [10] Low Fuel Warning and Anti-slosh Control

See Ground Distribution

See Ground Distribution



CIRCUIT OPERATION

Hazard Indicator

If the Hazard Switch (X220) is depressed, a pulsing voltage is applied to the Hazard Indicator which is permanently grounded by ground E200.

Direction Indicator

If the Direction Indicator Switch (X116) is turned on, a pulsing voltage is applied from the Flasher Unit (Z128) to the Direction Indicator which is permanently grounded by ground E200.

Trailer Indicator

With the Direction Indicator Switch (X116) turned on, the Flasher Unit (Z128) also applies a pulsing voltage to the Trailer Indicator which is permanently grounded by ground E200.

Main Beam Indicator

With the Headlamps turned on by the Main Lighting Switch (X145), battery voltage is applied to the Main Beam Indicator which is also permanently grounded by ground E200.

MFI-V8 and 300Tdi with EDC

Malfunction Indicator Lamp (Check Engine)

The Malfunction Indicator Lamp (Check Engine) is grounded by the Engine Control Module (ECM) (Z132) when a diagnostic trouble code is set.

Diesel

Glow Plug Indicator

The Glow Plug Indicator is grounded by the Glow Plug Timer Unit (Z135) to indicate that the Glow Plugs have been activated.

Fasten Seat Belt Indicator

(Japan and Gulf States Vehicles Only)

The Fasten Seat Belt Indicator receives battery voltage with the Ignition Switch (X134) in position II. The indicator is grounded through the Multi-Function Unit (MFU) (Z148) and the Driver's Seat Buckle Switch (X120). If the Driver's Seat Belt is buckled, the Driver's Seat Belt Buckle Switch opens and the Indicator turns off.

Oil Pressure Warning Light

The oil pressure warning light receives battery voltage with the Ignition Switch (X134) in position II. If the engine oil pressure is very low, the Oil Pressure Switch (X149) will apply ground to the warning light.

Differential Lock Indicator

The Differential Lock Indicator receives battery voltage with the Ignition Switch (X134) in position II. It is grounded by the Differential Lock Switch (X238) when the Differential is locked.

Brake Warning Light

The brake warning light receives battery voltage with the Ignition Switch (X134) in position II. It is grounded by the Brake Fluid Level Switch (X111) when the brake fluid level is low. It may also be grounded when the Handbrake Switch (X191) is closed. On Australian vehicles the brake warning light is grounded by a 3 second timer as a bulb check.

ABS Warning Light

The ABS warning light receives battery voltage with the Ignition Switch (X134) in position II. It is grounded by the Anti-Lock Brake System ECU (Z108) or the ABS Warning Relay (K103) in the event of an ABS problem.

Catalyst Warning Indicator (Japan Vehicles Only)

In case of a catalyst overheat, the catalyst overheat sensors send a signal to the Catalyst Warning ECU (Z274) which then provides battery voltage to the Catalyst Warning Relay (K172). The relay is energised and provides ground to the Catalyst Warning Indicator. The Catalyst Warning Indicator is also grounded by a 3 second timer as a bulb check.

NOTE: All Catalyst Warning Indicator circuitry is provided for Gulf States vehicles, but the bulb is not fitted.

Engine Immobilised Warning Lamp (EIWL)

(Except Japan and Gulf States Vehicles Only)

The EIWL receives battery voltage with the Ignition Switch (X134) in position II. It is grounded by the Theft Alarm Unit (Z163) to indicate the following conditions:

- Flashing = Immobilised
- Continuous = Immobilised (Cirrus Fail)

Theft Alarm LED

(Except Japan and Gulf States Vehicles Only)

The Theft Alarm LED receives battery voltage at all times. It is grounded by the Theft Alarm Unit (Z163) to indicate the following conditions:

- Slow Flash = Immobilised or Immobilised and armed
- Rapid Flash = Perimetrically and Volumetrically armed
- Intermittent Rapid Flash = Perimetrically armed
- No Flash for 10 Seconds = Mislock
- Continuous = Driver's door open (or ignition on) and Immobilised

Transmission/Transfer Box Oil Temperature Warning Light

Warning Light

The transmission/transfer box oil temperature warning light is grounded by the Automatic Transmission Oil Temperature Switch (X108) when the temperature of the transmission fluid exceeds 130°C (266°F). The warning light is also grounded by the Transfer Box Oil Temperature Switch (X174) when the temperature of the transfer box fluid exceeds 145°C (266°F). On Australian vehicles the warning light is grounded by a 3 second timer as a bulb check.

Low Fuel Warning Indicator


When the fuel gauge sender's resistance falls below approximately 25 Ohms (6 liters/1.5 US gallons), the Low Fuel Warning Indicator will illuminate to warn the driver.



Charge Warning Light


The charge warning light receives battery voltage with the Ignition Switch (X134) in position II. This warning light is grounded by the Generator (Z106) if the Generator is not producing normal power output or the Generator stops turning.




SRS Indicators



The SRS Indicators are controlled by the Air Bag Diagnostic Control Module (Z151) and the SRS Indicator Control Circuit of the Instrument Cluster (Z142) to indicate SRS System faults.








































With Cruise Con-trol

Without Cruise Control



CIRCUIT OPERATION


The audio system consists of a new head unit, and for mid/high-range, a subwoofer and subwoofer amplifier. For mid- and high-range, the system is also equipped with a radio waveband switch and a tune switch, a volume up and a volume down switch which are located on the fascia next to the instrument cluster.


The control head is equipped with an anti-theft feature which makes the unit inoperative once battery power is removed. A security code must be entered to restore power to the unit. On every level the system is equipped with two rear and two front speakers. Optional front tweeters are available for high line radio.

Battery voltage is provided to the control head at all times through the P wire. In addition to monitoring the anti-theft feature, this input keeps the preset station memory alive. Whenever battery power to the unit is lost, the anti-theft code must be entered and the preset stations must be reprogrammed.


When the Radio (Z111) and the ignition are turned on, the voltage signal through the LGO wire and the control head 'wakes up' the unit. The Radio (Z111) plays, the VF display comes on, and the control unit buttons illuminate. The VF display is dimmed when the headlights or park lights are turned on. When the lights are on, voltage from fuse F8 of the Fascia Fusebox (P126) is applied to the Radio (Z111) terminal 6, connector 230 signalling the Radio (Z111) to dim the display.

Except Japan
Low Line Radio








Except Japan
Low Line Radio




← Except Japan
Mid Line Radio






← Except Japan
Mid Line Radio







Except Japan
Mid Line Radio







Except Japan
Mid Line Radio







Except Japan
Mid Line Radio





← Except Japan
High Line Radio




←
Except Japan
High Line Radio







Except Japan
High Line Radio



CIRCUIT OPERATION


The audio system consists of a new head unit connected to a Radio Tune Switch, a waveband switch, a volume up and a volume down switch which are located on the fascia next to the Instrument Cluster. The system is also equipped with an amplifier, a subwoofer, a subwoofer amplifier and a CD changer which is connected to the Radio with a DIN cable. The amplifier is connected to power via a Power Amplifier Relay which is energised with Ignition on.

The control head is equipped with an anti-theft feature which makes the unit inoperative once battery power is removed. A security code must be entered to restore power to the unit. The system is equipped with two rear and four front speakers.


Battery voltage is provided to the control head at all times through the P wire. In addition to monitoring the anti-theft feature, this input keeps the preset station memory alive. Whenever battery power to the unit is lost, the anti-theft code must be entered and the preset stations must be reprogrammed.



When the Radio (Z111) and the ignition are turned on, the voltage signal through the LGO wire and the control head 'wakes up' the unit. The Radio (Z111) plays, the VF display comes on, and the control unit buttons illuminate. The VF display is dimmed when the headlights or park lights are turned on. When the lights are on, voltage from fuse F8 of the Fascia Fusebox (P126) is applied to the Radio (Z111) terminal 6, Connector 230 signalling the Radio (Z111) to dim the display.



Japan




← Japan









 Japan






Japan




← Japan










CIRCUIT OPERATION



Washer

The Rear Screen Wash Pump (M119) motor is grounded at all times. The motor runs when battery voltage is applied to the motor through the Rear Screen Wash Switch (X222) when the switch is switched to the WASH position.


Wiper



When the Rear Wipe Switch (X221) is pulled to the WIPE position, the Multifunction Unit (MFU) (Z148) applies ground to the Rear Wipe Relay (K183). Battery voltage is then applied to the Rear Wiper Motor (M120) from Fuse F18.








HEATED REAR SCREEN AND MIRROR DEMISTERS





























Front Wipe/Wash







Front Wipe/Wash





Front Wipe/Wash









1 C2062 Y
14



15 C208
See Fuse Details
S214 HJ9 LG



7 C221 PO
6 C209 WR
12 C205 Japan Gulf States





1 C378 X120
Driver's Seat Buckle Switch
0 [1]
1 Buckled


2 C378 B




S238 HJ3 See Ground Distribution


E201





































Rear Fog Guard
Lamps

5

Side Lamps

RY

3

Reversing Lamps

6

RB

GN

H5-2




GP

2

Direction Indica-
tor Lamps

1 C406

GR



- [1] Rear Fog Lamp
- [2] Tail Lamp
- [3] Reverse Lamp
- [4] Stop Lamp
- [5] Indicator Lamp


4 C403


B

S401

See Ground Dis-
tribution

E400





Rear Fog Guard Lamps

5

RY

Side Lamps

3

RO

Reversing Lamps

6

GN

Direction Indicator Lamps

H5-2


GP

GW

2


C


1 C406


B136
Right Rear Lamp Assembly



- [1] Rear Fog Lamp
- [2] Tail Lamp
- [3] Reverse Lamp
- [4] Stop Lamp
- [5] Indicator Lamp


See Ground Distribution




























































CIRCUIT OPERATION

Front Blower

With the Ignition Switch (X134) in position II, battery voltage is applied to the Ignition Load Relay (K127). The relay is energised, applying battery voltage to the Front Blower Motor Relay (K192).

When the Front Fan Speed Switch (X247) is turned to position I, ground is applied to terminal 85 of the Front Blower Motor Relay (K192). The relay is energised, applying battery voltage to terminal 2 of the Front Blower Motor (M101). Ground is applied to the Front Blower Motor (M101) through all three resistors of the Front Blower Resistor Unit (Z214). The Front Blower Motor (M101) then runs at low speed. When the Front Fan Speed Switch (X247) is turned to position II, the Front Blower Motor Relay (K192) remains energised. Battery voltage is still applied to terminal 2 of the Front Blower Motor (M101). Ground is now applied to the Front Blower Motor (M101) through two resistors of the Front Blower Resistor Unit (Z214) and the Front Fan Speed Switch (X247). The motor then runs at the low-medium speed. When the Front Fan Speed Switch (X247) is turned to position III, the Front Blower Motor Relay (K192) remains energised. Ground is now applied to the Front Blower Motor (M101) through one resistor of the Front Blower Resistor Unit (Z214) and the Front Fan Speed Switch (X247). The motor then runs at the medium-high speed. When the Front Fan Speed Switch (X247) is turned to position IV, the Front Blower Motor Relay (K192) remains energised. Ground is now applied directly to the Front Blower Motor (M101) through the Front Fan Speed Switch (X247). The motor then runs at high speed.

Fresh Air Mode

With the Ignition Switch (X134) in position II, battery voltage is applied to the Ignition Load Relay (K127). The relay is energised, applying battery voltage to the Air Recirculation Solenoid In-Line Fuse (P138) and Air Recirculation Solenoid (K123). When the Air Supply Selector Switch is moved to the Fresh Air position, ground is applied to the Air Recirculation Solenoid (K123). The solenoid now opens the fresh air intake flap allowing fresh air to enter the vehicle cabin. When the fresh air intake flap has been fully opened, the microswitch inside the Air Recirculation Solenoid (K123) moves to the Fresh Air position interrupting the ground supply. The solenoid now stops and remains in the Fresh Air position.

Recirculated Air Mode

With the Ignition Switch (X134) in position II, battery voltage is applied to the Ignition Load Relay (K127). The relay is energised, applying battery voltage to the Air Recirculation Solenoid In-Line Fuse (P138) and Air Recirculation Solenoid (K123). When the Air Supply Selector Switch is moved to Recirculate Air position, ground is applied to the Air Recirculation Solenoid (K123). The solenoid now closes the fresh air intake flap allowing only the air inside the vehicle cabin to circulate. When the fresh air intake flap has been fully closed, the microswitch inside the Air Recirculation Solenoid (K123) moves to the Recirculate Air position interrupting the ground supply. The solenoid now stops and remains in the Recirculate Air position.

Rear Blower

With the Ignition Switch (X134) in position II, battery voltage is applied to the Ignition Load Relay (K127). The relay is energised, applying battery voltage to the Rear Blower Motor Relay (K193), the Rear A/C Fan Speed Relay (K205) and the Rear A/C Control Relay (K194).


When the Rear A/C System is turned on, the Rear A/C Switch Amplifier provides ground to the Rear A/C Control Relay (K194). The relay is energised, applying ground to the Rear A/C Fan Speed Relay (K205). The Rear A/C Fan Speed Relay (K205) then energises. When the Passenger's Rear Fan Speed Switch (X246) is turned to position I, ground is applied to terminal 85 of the Rear Blower Motor Relay (K193) through the closed switch contacts of the Rear A/C Fan Speed Relay (K205). The Rear Blower Motor Relay (K193) energises, applying battery voltage to terminal 1 of the Rear Blower Motor (M145).


Ground is applied to the Rear Blower Motor (M145) through all three resistors of the Rear Blower Resistor Unit (Z215). The Rear Blower Motor (M145) then runs at low speed. When the Passenger's Rear Fan Speed Switch (X246) is turned to position II, the Rear Blower Motor Relay (K193) remains energised. Battery voltage is still applied to terminal 1 of the Rear Blower Motor (M145). Ground is now applied to the Rear Blower Motor (M145) through two resistors of the Rear Blower Motor Resistor Unit (Z215) and the Passenger's Rear Fan Speed Switch (X246).



The motor then runs at the low–medium speed.


When the Passenger's Rear Fan Speed Switch (X246) is turned to position III, the Rear Blower Motor Relay (K193) remains energised. Ground is now applied to the Rear Blower Motor (M145) through one resistor of the Rear Blower Motor Resistor Unit (Z215) and the Passenger's Rear Fan Speed Switch (Z246).

The motor then runs at medium–high speed. When the Passenger's Rear Fan Speed Switch (X246) is turned to position IV, the Rear Blower Motor Relay (K193) remains energised. Ground is now applied directly to the Rear Blower Motor (M145) through the Passenger's Rear Fan Speed Switch (X246). The motor then runs at high speed.










BLOWER CONTROLS (WITH REAR A/C)


K1





K1


BLOWER CONTROLS (WITH REAR A/C)

With Rear Air Conditioning



 With Rear Air Conditioning





CIRCUIT OPERATION

Compressor Control (MFI–V8)

With the Ignition Switch (X134) in position II, battery voltage is applied to the Ignition Load Relay (K127). The relay is energised, applying battery voltage to the Compressor Clutch Relay (K108) and the A/C Logic Relay (K170). When the Front Fan Speed Switch (X247) is turned to positions I, II, III, or IV and the Front A/C Switch (X225) is turned on, ground is provided to terminal 86 of the A/C Logic Relay (K170) through the closed contacts of the A/C Dual Pressure Switch (X102) and the Front A/C Evaporator Temperature Switch (X101).

The relay is energised, applying battery voltage to the Engine Control Module (ECM) (Z132), which signals the ECM that compressor operation has been requested. The ECM then provides ground to the coil of the Compressor Clutch Relay (K108). The relay is energised, applying battery voltage to the Compressor Clutch (K107). Compressor Clutch operation is now controlled by the status of the A/C Dual Pressure Switch (X102) and the Front A/C Evaporator Temperature Switch (X101).

The Front A/C Evaporator Temperature Switch (X101) is fitted in the airflow out of the front evaporator to sense the temperature of the exterior fins. Should ice begin to form due to low temperature, the switch will open. The A/C Dual Pressure Switch (X102) monitors refrigerant pressure in the high pressure line. Should pressure become too high or too low, the switch will open. When one or both of these switches open, the ground supply to terminal 86 of the A/C Logic Relay (K170) will be interrupted. The relay de-energises, removing battery voltage from the Engine Control Module (ECM) (Z132), which signals the ECM that compressor operation should be turned off. The ECM removes the ground supply to the coil of the Compressor Clutch Relay (K108). The relay then de-energises, removing battery voltage from the Compressor Clutch (K107), thereby disengaging the Compressor.

Compressor Control (MFI–T16)

With the Ignition Switch (X134) in position II, battery voltage is applied to the Compressor Clutch Relay (K108) and the A/C Logic Relay (K170). When the Front Fan Speed Switch (X247) is turned to positions I, II, III, or IV and the Front A/C Switch (X225) is turned on, ground is provided to terminal 85 of the A/C Logic Relay (K170) through the closed

contacts of the A/C Dual Pressure Switch (X102) and the Front A/C Evaporator Temperature Switch (X101).

The relay is energised, applying ground to terminal 35 of the Engine Control Module (ECM) (Z132), which signals the ECM that compressor operation has been requested. The ECM then provides ground to the terminal 86 of the Compressor Clutch Relay (K108). The relay is energised, applying battery voltage to the Compressor Clutch (K107). Compressor Clutch operation is now controlled by the status of the A/C Dual Pressure Switch (X102) and the Front A/C Evaporator Temperature Switch (X101).

The Front A/C Evaporator Temperature Switch (X101) is fitted in the airflow out of the front evaporator to sense the temperature of the exterior fins. Should ice begin to form due to low temperature, the switch will open. The A/C Dual Pressure Switch (X102) monitors refrigerant pressure in the high pressure line. Should pressure become too high or too low, the switch will open. When one or both of these switches open, the ground supply to terminal 85 of the A/C Logic Relay (K170) will be interrupted. The relay de-energises, removing the ground supply from terminal 35 of the Engine Control Module (ECM) (Z132), which signals the ECM that compressor operation should be turned off. The ECM removes the ground supply to terminal 86 of the Compressor Clutch Relay (K108). The relay then de-energises, removing battery voltage from the Compressor Clutch (K107), thereby disengaging the Compressor.

Compressor Control (NAS) (SFI–V8)

With the Ignition Switch (X134) in position II, battery voltage is applied to the Ignition Load Relay (K127). The relay is energised, applying battery voltage to the Compressor Clutch Relay (K108). When the Front Fan Speed Switch (X247) is turned to positions I, II, III, or IV and the Front A/C Switch (X225) is turned on, ground is provided to terminal 28 of the Engine Control Module (ECM) (Z132) through the closed contacts of the A/C Dual Pressure Switch (X102) and the Front A/C Evaporator Temperature Switch (X101). The signal informs the ECM that compressor operation has been requested. The ECM then provides ground to the coil of the Compressor Clutch Relay (K108). The relay is energised, applying battery voltage to the Compressor Clutch (K107). Compressor Clutch operation is now controlled by the status of the A/C Dual Pressure Switch (X102) and the Front A/C Evaporator Temperature Switch (X101).

The Front A/C Evaporator Temperature Switch (X101) is fitted in the airflow out of the front evaporator to sense the temperature of the exterior fins. Should ice begin to form due to low temperature, the switch will open. The A/C Dual Pressure Switch (X102) monitors refrigerant pressure in the high pressure line. Should pressure become too high or too low, the switch will open. When one or both of these switches open, the ground supply to terminal 28 of the ECM will be interrupted. This signal informs the ECM that compressor operation should be turned off. The ECM removes the ground supply to the coil of the Compressor Clutch Relay (K108). The relay then de-energises, removing battery voltage from the Compressor Clutch (K107), thereby disengaging the Compressor.

Compressor Control (300Tdi without EDC)

With the Ignition Switch (X134) in position II, battery voltage is applied to the Ignition Load Relay (K127). The relay is energised, applying battery voltage to the Compressor Clutch Relay (K108).

When the Front Fan Speed Switch (X247) is turned to positions I, II, III, or IV and the Front A/C Switch (X225) is turned on, ground is provided to terminal 86 of the Compressor Clutch Relay (K108) through the closed contacts of the A/C Dual Pressure Switch (X102), the Front A/C Evaporator Temperature Switch (X101), and the Compressor Clutch Cut-out Switch (X259).

The relay is energised, applying battery voltage to the Compressor Clutch (K107). Compressor Clutch operation is now controlled by the status of the A/C Dual Pressure Switch (X102), the Front A/C Evaporator Temperature Switch (X101), and the Compressor Clutch Cut-out Switch (X259).

The Front A/C Evaporator Temperature Switch (X101) is fitted in the airflow out of the front evaporator to sense the temperature of the exterior fins. Should ice begin to form due to low temperature, the switch will open. The A/C Dual Pressure Switch (X102) monitors refrigerant pressure in the high pressure line. Should pressure become too high or too low the switch will open. When one or more of these switches open, the ground supply to terminal 86 of the Compressor Clutch Relay (K108) will be interrupted. The relay de-energises, removing battery voltage from the Compressor Clutch (K107), thereby disengaging the Compressor.

Compressor Control (300Tdi with EDC)

With the Ignition Switch (X134) in position II, battery voltage is applied to the Ignition Load Relay (K127). The relay is energised, applying battery voltage to the Compressor Clutch Relay (K108). When the Front Fan Speed Switch (X247) is turned to positions I, II, III, or IV and the Front A/C Switch (X225) is turned on, ground is provided to terminal 44 of the Engine Control Module (ECM) (Z132) through the closed contacts of the A/C Dual Pressure Switch (X102) and the Front A/C Evaporator Temperature Switch (X101). The signal informs the ECM that compressor operation has been requested. The ECM then provides ground to the coil of the Compressor Clutch Relay (K108). The relay is energised, applying battery voltage to the Compressor Clutch (K107). Compressor Clutch operation is now controlled by the status of the A/C Dual Pressure Switch (X102) and the Front A/C Evaporator Temperature Switch (X101).

The Front A/C Evaporator Temperature Switch (X101) is fitted in the airflow out of the front evaporator to sense the temperature of the exterior fins. Should ice begin to form due to low temperature, the switch will open. The A/C Dual Pressure Switch (X102) monitors refrigerant pressure in the high pressure line. Should pressure become too high or too low, the switch will open. When one or both of these switches open, the ground supply to terminal 44 of the ECM will be interrupted. This signal informs the ECM that compressor operation should be turned off. The ECM removes the ground supply to the coil of the Compressor Clutch Relay (K108). The relay then de-energises, removing battery voltage from the Compressor Clutch (K107), thereby disengaging the Compressor.

Rear A/C Refrigerant Control Valve



When front A/C has been selected and the Compressor Clutch (K107) is engaged, the Compressor Clutch Relay (K108) is energised and voltage is applied on the BG wires to the Rear A/C Refrigerant Control Valve (K207). When rear A/C is selected a ground signal is applied to the Rear A/C Switch Amplifier (Z216). The Rear A/C Switch Amplifier (Z216) then applies a ground signal to energise the Rear A/C Control Relay (K194) and the Rear A/C Fan Speed Relay (K205). When the Passenger's Rear Fan Speed Switch (X246) is in any position other than Off,


ground is applied to the Rear A/C Refrigerant Control Valve (K207) through the closed contacts of the Passenger's Rear Fan Speed Switch (X246), BR wire, closed contacts of the Rear A/C Fan Speed Relay (K205), PG wire, UB wire, Rear A/C Refrigerant Control Valve Diode (Z228), P wire, closed contacts of the Rear A/C Evaporator Temperature Switch (X260), and the RG wire.

The Rear A/C Evaporator Temperature Switch (X260) senses the temperature of the exterior fins. Should ice begin to form due to low temperature, the switch will open and the ground supply to the Rear A/C Refrigerant Control Valve (K207) will then be interrupted. The valve de-energises and refrigerant flow is interrupted.


The Rear A/C Refrigerant Control Valve (K207) will also be de-energised if one or more of the following conditions occurs:

1. The Front A/C Switch (X225) has been turned OFF.
2. The Front Fan Speed Switch (X247) has been turned OFF.
3. The Rear A/C switches have been turned OFF.
4. The Passenger's Rear Fan Speed Switch (X246) has been turned OFF.
5. The ECM determines that compressor clutch operation is no longer required.
6. Compressor Clutch (K107) operation has been disabled by the A/C Dual Pressure Switch (X102) or the Front A/C Evaporator Temperature Switch (X101).
7. Compressor Clutch (K107) operation has been disabled by the Compressor Clutch Cut-Out Switch (X259) (300Tdi Without EDC Only).






MFI-T16



300Tdi without EDC



See Fuse Details



S295




1 C145

2 C145
B




B
S155

See Ground Dis-
tribution

E100




[1] > 115°C
(239°F)




X101
Front A/C Evap-
orator Tempera-
ture Switch


[1] > 0°C (32°F)
[2] < 0°C (32°F)




ON

K2-9 E






With Rear Air Conditioning




COMPRESSOR CONTROLS (WITH REAR A/C)

K2



With Rear Air
Conditioning



CIRCUIT OPERATION

Condenser Fan Operation (MFI-V8)

The Condenser Fans Motors (M113, M121) on vehicles equipped with MFI-V8 engines operate when any of the following conditions occur:

8. Coolant temperature exceeds 100°C (212°F).
9. The air conditioning system is operating.
10. The Engine Control Module (ECM) (Z132) determines that fuel temperature exceeds 70°C and coolant temperature exceeds 110°C after engine shutdown. When this occurs, the fans are turned on for approximately 10 minutes after the engine is shut off.

Operation with High Coolant Temperature (MFI-V8)

When the Ignition Switch (X134) is in position II, battery voltage is applied to the Ignition Load Relay (K127). The relay is energised, applying battery voltage to the Condenser Fan Relay (K109) and the Fan Control Module (Z118). If the coolant temperature exceeds 100°C (212°F), the Condenser Fan Coolant Temperature Switch (X113) closes and energises the Condenser Fan Relay (K109) by applying ground to the relay's coil. When the relay is energised, voltage from fuse F3 is applied to the Condenser Fan Motors (M113, M121) through the relay's contacts.

Fan Operation with A/C (MFI-V8)

With the Ignition Switch (X134) in position II, battery voltage is applied to the Ignition Load Relay (K127). The relay is energised, applying battery voltage to the Condenser Fan Relay (K109). When the Front A/C Switch (X225) is turned on and the Front Fan Speed Switch (X247) is turned to positions I, II, III, or IV, ground is applied to terminal 86 of the Condenser Fan Relay. The relay energises, applying battery voltage from fuse F3 to the Condenser Fan Motors (M113, M121).

Operation with the Engine Off (MFI-V8)

The Engine Control Module (Z132) monitors fuel temperature and coolant temperature through sensors. When the ECM determines that fuel temperature is above 70°C and coolant temperature exceeds 110°C after engine shutdown, the ECM will command fan operation for approximately 10

minutes. The ECM turns on the fans by momentarily grounding the Fan Control Module (Z118) through the BG wire. When the timer unit is grounded, it starts a solid state timer and begins to apply ground from its terminal 9 to the Condenser Fan Relay (K109) through the BP wire. With the Condenser Fan Relay energised, voltage from fuse F3 is applied to the Condenser Fan Motors (M113, M121) through the relay contacts.

Cooling Fan and Condenser Fan Operation**(MFI-T16)**

The Cooling Fan 1 (M141) or Cooling Fans (M141, M142) and Condenser Fan Motors (M113, M121) on vehicles equipped with MFI-T16 engines operate when any of the following conditions occur:

1. The A/C system is operating.
2. The Engine Control Module (ECM) determines that Cooling Fan and/or Condenser Fan Motor operation is required.

Cooling Fan Operation without A/C (MFI-T16)

With the Ignition Switch (X134) in position II, battery voltage is applied to the Cooling Fan Relay (K190) from fuse F3 of the Satellite Fuse Box 1 (P127).

When Cooling Fan Operation is required, the Engine Control Module (ECM) (Z132) grounds terminal 85 of the Cooling Fan Relay (K190). The relay energises, applying battery voltage from fuse F3 of the Engine Compartment Fuse Box (P125) to the Cooling Fan Motor 1 (M141). When Cooling Fan Operation is no longer required, the ECM removes the ground supply to the Cooling Fan Relay (K190). The Relay de-energises, removing the voltage supply to the Cooling Fan Motor 1 (M141).

Cooling Fan and Condenser Fan Operation with A/C (MFI-T16)

With the Ignition Switch (X134) in position II, battery voltage is applied to the Ignition Load Relay (K127).

The relay is energised, applying battery voltage to the Condenser Fan Relay (K109). When Cooling Fan and Condenser Fan operation is required, the Engine Control Module (ECM) (Z132) grounds terminal 85 of the Condenser Fan Relay (K109). The relay energises, applying battery voltage from fuse F3 of the Engine Compartment Fuse Box (P125) to the Cooling Fan Motors (M141, 142) and the Condenser Fan Motors (M113, M121). When Cooling Fan and Condenser Fan operation is no longer required, the ECM removes the ground supply to the Condenser Fan Relay (K109). The relay de-energises, removing the voltage supply to the Cooling Fans (M141, M142) and the Condenser Fan Motors (M113, M121).

Condenser Fan Operation (300Tdi)

The Condenser Fan Motors (M113, M121) on vehicles equipped with diesel engines operate when any one of the following conditions occur:



1. Coolant temperature exceeds 100°C (212°F).
2. The A/C is operating.

Condenser Fan with High Coolant Temperature**Operation (300Tdi)**


When the Ignition Switch (X134) is in position II, battery voltage is applied to the Ignition Load Relay (K127). The relay is energised, applying battery voltage to the Condenser Fan Relay (K109). If the coolant temperature exceeds 100°C (212°F), the Condenser Fan Coolant Temperature Switch (X113) closes and energises the Condenser Fan Relay (K109) by applying ground to the relay's coil. When the relay is energised, voltage from fuse F3 is applied to the Condenser Fan Motors (M113, M121) through the relay's contacts.

Fan Operation with A/C (300Tdi)


With the Ignition Switch (X134) in position II, battery voltage is applied to the Ignition Load Relay (K127). The relay is energised, applying battery voltage to the Condenser Fan Relay (K109) when the Front A/C Switch (X225) is turned on and the Front Fan Speed Switch (X247) is turned to positions I, II, III, or IV and grounding terminal 86 of the Condenser Fan Relay (K109). The relay energises, applying battery voltage from fuse F3 to the Condenser Fan Motors (M113, M121).



MFI-V8





◀ MFI-V8





▶


MFI-T16 without Air Conditioning











K5-6


MFI-V8

K5-9

300Tdi without
EDC

K5-10

300Tdi with EDC

Compressor
Controls

Not used

MFI-T16

C217

MFI-V8


300Tdi without
EDC
300Tdi with EDC

PB

NW

Compressor
Controls

Interior Lamps

X225
Front A/C Switch

CIRCUIT OPERATION

Voltage for window lift and sunroof operation is provided to the Window Lift ECU (Z147) from fuses F1 and F2. The Window Lift ECU is grounded through the B wire at ground E201.

Timeout Feature

Fuse F15 applies voltage to the Window Lift ECU terminal 3 when the ignition switch is on. When the ignition switch is turned off, the absence of voltage at terminal 3 signals the Window Lift ECU to start the timeout feature. When the timeout feature is activated, the Window Lift ECU will allow window and sunroof operation for an additional 45 seconds.

The timeout feature will be cancelled if the driver's door is opened and then closed. The Window Lift ECU monitors the door's position at terminal 9.

Front Window Operation

When a Front Window Switch is operated, the switch grounds one of four Window Lift ECU input terminals. This signals the Window Lift ECU to apply voltage and ground to the respective window motor. If the front window switch is held in the down position for more than 1/2 second, the express down feature is activated. The Window Lift ECU will operate the window motor until it is completely lowered.


Rear Window








The Window Lift ECU terminal 4 supplies voltage to the Rear Window Console and door switches for rear window operation.

When a window console switch is in the 'DOWN' position, voltage is applied to the window motor through the 'up' switch contacts. The window motors operate because they are grounded through the 'down' contacts of the window console switch. When a switch is in the 'UP' position, the polarity applied to the window motor is reversed, causing the motor to run in the opposite direction and the window to close.

Rear Window Isolation Switch (X187)

The Rear Window Isolation Switch (X187) is placed in series with the ground supply to the Rear Window Door Switches (X188, X189). If the isolation switch is opened, the ground supply is interrupted, preventing rear window operation using the rear door switches.





4 C338


4 C337


2 C3003



1 C3003


See Ground Distribution




E303















CIRCUIT OPERATION

The locking functions on models with the Theft Alarm System are controlled by the Theft Alarm Unit (Z163). Refer to the Theft Alarm System (T1). The locking functions on models without the Theft Alarm System are controlled by the Right Front Door Lock Actuator (M122).



The four doors and the tailgate are locked or unlocked using the right front exterior key or the interior door sill knob. The rear doors can be independently locked or unlocked from the inside by using the appropriate door sill knob. These can be overridden when the lock controls in the right front door are used. The left front door and the rear doors may be locked or unlocked in isolation from the outside using the key or from the inside using the door sill knob.



Lock

When the doors are locked by the right front exterior key or the interior door sill knob, the internal microswitches in the Right Front Door Lock Actuator (M122) move to the "Lock" position. Voltage from fuse F4 is applied to the lock actuators through the K wires. The lock actuators are grounded at E200 through the microswitch contacts and the O wires. The doors and the tailgate now lock. The solid state load sensor/timer ensures that the motors operate only for the time required to lock or unlock the doors and the tailgate.

Unlock

When the doors are unlocked by the right front exterior key or the interior door sill knob, the internal microswitches in the Right Front Door Lock Actuator (M122) move to the "Unlock" position. Voltage from Fuse F4 is applied to the lock actuators through the O wires. The lock actuators are grounded at E200 through the microswitch contacts and the K wires. Since the polarity of the voltage is now reversed, the doors and the tailgate unlock.





CIRCUIT OPERATION

Fuses F1 and F5 of the Satellite Fuse Box 1 (P127) and F4 of the engine compartment Fuse Box (P125) supply voltage to the Central Locking Control Unit (Z113). The control unit is grounded at terminals 10 and 11 of C274 to ground E201.

Central Locking Control Unit (Z113)

Central locking is controlled by the Central Locking Control Unit (Z113) and may be operated by the key, sill button(s) or handset. The system works on the driver's door only.

NOTE: The central door locking system will shut down for a period of approximately 15 seconds if the Central Locking Control Unit (Z113) determines that the lock actuators could be overheating.

Inputs


The Central Locking Control Unit (Z113) monitors the position of the front door locks through an input switch which is part of the right Front Door Lock Actuator (M122). When the control unit sees the input switch change position, the control unit responds by locking or unlocking the doors and the tailgate.


Lock

The Central Locking Control Unit (Z113) locks the doors and the tailgate by momentarily applying battery voltage to the actuators through the K wire. The lock actuators are grounded by the Central Locking Control Unit (Z113) through the O wire. The actuators now move to the locked position.



Unlock


To unlock the doors and the tailgate the Central Locking Control Unit (Z113) momentarily applies battery voltage to the actuators through the O wire. The actuators are grounded by the Central Locking Control Unit (Z113) through the K wire. The lock actuators now unlock.








Not used




















21 BS 15 B 14 BK
6 C2082
Not used

MFI-T16

300Tdi with EDC

MFI-V8
300Tdi without
EDC

21 B 24 BK C217
Not used
BK
13 C1007

21 B 24 BK C217
Not used
BS
45 C243

21 B 24 BK C217
Not used
B
9 C2095
Not used




CIRCUIT OPERATION



Driver Seat


When the Ignition Switch (X134) is in position I or II, or the right front door is open, the Right Seat Power Relay (K131) is energised. Battery voltage is then applied to the Right Front Seat Control Switch (X121) through the closed relay contacts and the Driver's Underseat Fuse Box (P108). Ground is applied to the Right Front Seat Control Switch (X121) at all times. The Right Front Seat Control Switch (X121) controls 4 seat control motors via 8 switches. When each switch is moved to operate its corresponding motor, one seat switch applies ground while the other applies battery voltage to the respective seat motor. The motor turns to adjust the seat in the requested direction.

Passenger Seat

Battery voltage is applied to the Left Front Seat Control Switch (X152) at all times. When the Ignition Switch (X134) is in position I or II, the Left Seat Power Relay (K113) is energised, applying ground to the Left Front Seat Control Switch (X152). The Left Front Seat Control Switch (X152) controls 4 seat control motors via 8 switches. When each switch is moved to operate its corresponding motor, one seat switch applies ground while the other applies battery voltage to the respective seat motor. The motor turns to adjust the seat in the requested direction.







CIRCUIT OPERATION

When the Ignition Switch (X134) is in position II, voltage is supplied to the power mirrors circuit by fuse F18.

Left/Right Movement


When a selected mirror is moved to the left by the Mirror Adjustment Switch (X146), the internal contacts move to the "Move Down or Left" and the "Move Left" positions. The Left/Right Motor of the selected actuator is grounded at E200 through the SW wires and the switch contacts. Voltage is applied to the Left/Right Motor through the BP, BU wires. The mirror now moves left.



When a selected mirror is moved to the right by the Mirror Adjustment Switch (X146), the internal contacts move to the "Move Up or Right" and the "Move Right" positions. The Left/Right Motor of the selected actuator is grounded at E200 through the BU, BP wires and the switch contacts. Voltage is applied to the Left/Right Motor through the SW wires. Since the polarity of the voltage to the motor has been reversed, the mirror now moves right.



Up/Down Movement

When a selected mirror is moved down by the Mirror Adjustment Switch (X146), the internal contacts move to the "Move Down or Left" and the "Move Down" positions. The Up/Down Motor of the selected actuator is grounded at E200 through the SW wires and the switch contacts. Voltage is applied to the Up/Down Motor through the BK, BN wires. The mirror now moves down.



When a selected mirror is moved up by the Mirror Adjustment Switch (X146), the internal contacts move to the "Move Up or Right" and the "Move Up" positions. The Up/Down Motor of the selected actuator is grounded at E200 through the BN, BK wires and the switch contacts. Voltage is applied to the Up/Down Motor through the SW wires. Since the polarity of the voltage to the motor has been reversed, the mirror now moves up.











[See Fuse Details](#)















CIRCUIT OPERATION

For 1996 models a vehicle alarm system is available as original equipment. Three different functions are integrated into the Theft Alarm System:

3. The main function of the system is to offer easy-to-use remote locking and unlocking of the vehicle (Central Locking).
4. Anti-Theft System function.
5. Engine Immobilisation function.

NOTE: The Theft Alarm ECU (Z163) is fully programmable to meet different market requirements; therefore some of the features listed will vary dependent on vehicle model or territory.

ALARM COMPONENTS

1. Theft Alarm Unit (Z163)
2. Handset Transmitter
3. Passive Immobilisation Coil (Z270) (Not on all vehicles!)
4. Alarm Sensor (X213) (Not on all vehicles!)
5. Lock Actuators (M114, M122, M117, M125, M132)
6. Alarm Bonnet Switch (X212) (Not on all vehicles!)
7. Right Front Door Key Switch (X202)
8. Door Switches (X150, X118, X142, X163)
9. Rear End Door Switch (X265)
10. Direction Indicator Lamps (Hazard Lamps)
11. Battery Backed Up Alarm Sounder (Z272) (Not on all vehicles!)
12. Alarm Sounder (Z171) and Sounder Relay (K160) (Not on all vehicles!)
13. Theft Alarm LED and Engine Immobilised Warning Lamp (EIWL) (Included in the Instrument Cluster (Z142))
14. Engine Immobilisation Control Unit (Z171)
MFI-V8 and 300 Tdi without EDC Engines only
(Not on all vehicles!)

Central Locking FUNCTION

Central Locking is controlled by the Theft Alarm Unit (Z163) and may be locked by using the driver's door key, sill button(s) or handset. The vehicle may be unlocked by using the handset or EKA code.

NOTE: The central door locking system will shut down for a period of approximately 15 seconds if the Theft Alarm Unit (Z163) determines that the Lock Actuators could be overheating.

ANTI-THEFT System Function

The alarm system offers the following forms of protection:

- Perimetric protection against unauthorised opening of all doors, tailgate, and bonnet.
- Engine crank inhibit against unauthorised engine crank.
- Electronic engine immobilisation against unauthorised engine start.
- Volumetric protection against intrusion into the passenger compartment.

NOTE: Perimetric protection is also triggered by the driver's door sill switch being lifted and the ignition switch being turned on.

Perimetric Protection

The system is perimetrically armed whenever the vehicle is manually central door locked using the driver's door key. A lock request from the handset will volumetrically arm the theft alarm.

Volumetric Protection

Using the handset transmitter will turn On and Off volumetric protection. In volumetric mode all doors, tailgate, and bonnet are protected against unauthorised entry, and the Ignition Switch is protected from being switched on. In addition, the vehicle interior is protected using the Alarm Sensor (X213).

Theft Alarm Disarming

(Perimetric and Volumetric Modes)

The theft alarm can only be disarmed with the handset (or EKA code).

NOTE: The theft alarm system cannot be disarmed using the driver's door key.

Partially Armed Mode

The system will enter the "partially armed" mode whenever one of the following conditions is valid during theft alarm arming:

- movement takes place inside the vehicle within 15 seconds of the lock signal being received
- a door, tailgate, or bonnet is open.

The engine will be immobilised and cranking is inhibited. The alarm will sound if ignition is turned to start position. The alarm will protect the following:

- If any of the doors caused partial arming, then opening the tailgate or bonnet will sound the alarm.
- If the tailgate caused partial arming, then the opening of any doors or the bonnet will sound the alarm.
- If the bonnet caused partial arming, then the opening of any doors or tailgate will sound the alarm. Volumetric protection is also armed.
- If two of the above cause partial arming, then the third is still protected.

If the doors, tailgate or bonnet is subsequently closed, after a 5 second delay, the system will fully arm.

Engine Cranking

It is only possible to crank the engine when ignition is ON and alarm disabled.

Alarm Sounder

When an intrusion is detected, the Alarm Sounder (Z171) will sound and the hazard lamps flash (where territorial regulations allow) for 30 seconds. The alarm must be retriggered before the Alarm Sounder will sound again.

Two different types of Alarm Sounders are available:

1. Normal Alarm Klaxon (Alarm Sounder (Z171))
2. Battery Backed Up Alarm Sounder (Z272)

The Battery Backed Up Alarm Sounder (Z272) is an alarm sounder which contains its own internal battery. When the Ignition is on, the internal battery is charged via an Ignition feed. If either the connector is removed or the wires to it are cut, then the sounder will sound for 3 minutes.

To disconnect the Battery Backed Up Alarm Sounder (Z272):

- Turn Ignition On (Pos. II)
- Turn Ignition Off
- Disconnect within 15 seconds

To silence if triggered:

- Connect
- Disarm Alarm
- Turn Ignition On (Pos. II)

Inertia Switch

An inertia switch is incorporated in the Theft Alarm Unit (Z163). If ignition is on and the vehicle receives an impact sufficient to activate the inertia switch, the unit will signal to unlock central locking actuators and flash hazard lights. Central locking will remain disabled for a period of 0 to 5 minutes. To reset, turn ignition off and then on after the time period has elapsed.

Alarm Sensor (X213)

The sensor operates by emitting an air pressure carrier wave and receiving the wave back. Any disturbance within the vehicle which disturbs the wave will be detected, triggering the alarm. When the volumetric sensor is activated, it monitors movement within the vehicle for 15 seconds before detecting and responding to intrusions. If the sensor detects movement within the vehicle, it delays arming until a 15 seconds quiet period has elapsed. If continuous movement is detected, the alarm will not arm volumetrically.

ENGINE IMMobilISATION FUNCTION**(Not on all vehicles!)**

The engine will be immobilised whenever the theft alarm is armed or the Theft Alarm Unit (Z163) enters the Passive Immobilisation mode (regardless of whether or not the theft alarm is armed). There are two methods of Engine Immobilisation featured:

1. Electronic Engine Immobilisation (used on MFI-T16 and 300 Tdi with EDC engines)
2. Remote "Smart Spider" Immobilisation (used on MFI-V8 and 300 Tdi without EDC engines)

The vehicle may only be mobilised by using the handset or entering the correct EKA code.

Electronic Engine Immobilisation**(MFI-V8) (300 Tdi with EDC)**

The electronic engine immobilisation is controlled jointly by the engine management system's Electronic Control Module (ECM) (Z132) and the Theft Alarm Unit (Z163).

When the Theft Alarm Unit (Z163) immobilises the vehicle, it sends a signal to the ECM. The ECM then immobilises the engine management system until a mobilise signal is received from the Theft Alarm Unit (Z163).

Remote "Smart Spider" Immobilisation**(MFI-V8) (300 Tdi without EDC)**

The Remote "Smart Spider" Immobilisation is controlled jointly by the Engine Immobilisation Control Unit (Spider) (Z271) and the Theft Alarm Unit (Z163). When the Theft Alarm Unit (Z163) immobilises the vehicle, it sends a signal to the Engine Immobilisation Control Unit (Spider) (Z271). The "Spider" then interrupts the starter circuit, fuel pump circuit, and Ignition coil circuit for MFI-V8 engines, or the starter circuit and the fuel pump shutoff solenoid circuit for 300 Tdi without EDC engines. These circuits will remain interrupted until the "Spider" receives a mobilise signal from the Theft Alarm Unit (Z163).

Passive Immobilisation

The following conditions will passively immobilise the vehicle:

- 30 seconds after ignition has been turned off and the driver's door has been opened
- 5 minutes after ignition has been turned off
- 5 minutes after disarming the theft alarm

The vehicle can be mobilised by any of the following methods:

- Turn the ignition on (The handset must be functioning properly and within close proximity to the key!)
- Press unlock button on the handset (4 times if out of sync)
- Press lock button on the handset (4 times if out of sync)
- Enter EKA code

NOTE: The vehicle will remain immobilised by attempting to turn the Ignition on with the handset detached from the key ring (or with an improperly functioning handset).

Passive Immobilisation Coil (Z270)

A magnetic field is generated by the passive Immobilisation Coil (Z270) contained in the steering column. This field excites a receiving coil in the handset causing it to transmit a mobilisation signal to the Theft Alarm Unit (Z163). If the Theft Alarm Unit (Z163) does not receive this signal from the handset, the vehicle will remain immobilised.

Vehicle Status Indication

Vehicle status is indicated by up to four devices:

1. Hazard lamps
2. Theft Alarm LED (Contained in the Instrument Cluster (Z142))
3. Engine Immobilised Warning Lamp (EIWL) (Contained in the Instrument Cluster (Z142))
4. Alarm Sounder

Hazard Lamps

When the vehicle arms in either mode, the hazard lamps will flash up to three times when the alarm is armed and one time when disarmed.

Theft Alarm LED

- Slow Flash: Immobilised or immobilised and armed
- Rapid Flash: Volumetrically armed

- Intermittent Rapid Flash: Perimetricaly armed
- No Flash for 10 Seconds: Mislock
- Continuous: Driver's door open (or ignition on) and immobilised

NOTE: The Theft Alarm LED may also be used to indicate other conditions.

Engine Immobilised Warning Lamp (EIWL) (Not on all vehicles!)

- Flashing: Immobilised
- Continuous: Immobilised (Cirrus Fail) or an attempt has been made to start the vehicle without the handset attached to the key ring (or handset battery needs to be replaced).

Handset Transmitter Resynchronisation

The Theft Alarm Unit (Z163) will remain synchronised with the handset unless:

- The handset's batteries have been removed
- The vehicle's battery has been disconnected

NOTE: All handsets must be resynchronised when the vehicle's battery has been disconnected.

To resynchronise a handset the vehicle must be in an unlocked and disarmed state. Resynchronisation consists of 4 presses of either the lock or unlock button.

5. Turn the key to the unlock position to unlock the doors, disarm the alarm, and mobilise the vehicle.

NOTE: The key must be fully turned to the rest and lock/unlock position each time.

If the wrong EKA code has been entered, an audible warning will be heard. After 3 wrong attempts, you must wait 30 minutes. To clear a partially entered code, simply hold the key in the lock position for at least 5 seconds.

Handset Low Battery Warning

When the handset batteries are low, the Theft Alarm Unit (Z163) will enter the "low battery mode". The Theft Alarm LED will flash to indicate "low battery mode", and the hazard lamps will not flash when the alarm is disarmed.

Interior Lamps

The Theft Alarm Unit may be configured to perform full interior Lamp delay and soft-fade functionalities.

Power Up Mode

The alarm system always remembers the state it was left in when power was removed. If the alarm powers up in an alarmed state, it will enter a special "power up mode".

Emergency Key Access (EKA)

EKA is used to disarm the theft alarm and mobilise the vehicle in the event of a handset failure. This is possible through a series of locks and unlocks with the key in the driver's door lock cylinder. With the vehicle locked and the alarm armed, turn the key the required number of times according to the following sequence:

1. To enter the first digit, turn the key the required number of times to the unlock position.
2. To enter the second digit, turn the key the required number of times to the lock position.
3. To enter the third digit, turn the key the required number of times to the unlock position.
4. To enter the fourth digit, turn the key the required number of times to the lock position.

BUILT IN TEST PROCEDURE

The handset should be detached from the key ring to allow perimetric testing. The system will automatically switch to volumetric testing if the handset is in close proximity to the Ignition Switch (X134). The built in test procedure is accessed as follows:

1. Starting conditions: ignition off, doors unlocked, alarm disarmed, bonnet switch depressed.
2. Carry out instructions 3 to 7 within 5 seconds.
3. Release bonnet switch.
4. Switch ignition on.
5. Open driver's door.
6. Switch ignition off.
7. Switch ignition on.

If alarm is correctly accessed, the alarm sounder will sound. The following checks can then be made:

Perimetric Testing

1. Open and close driver's door or tailgate – Theft Alarm LED and Hazard lamps will flash.
2. Depress bonnet switch – Theft Alarm LED and Hazard lamps will flash.
3. Pull the driver's door sill button up – Theft alarm LED and Hazard lamps will flash.
4. Turn driver's door key lock cylinder – Theft Alarm LED and Hazard lamps will flash.

Volumetric Testing

1. Press the unlock button on the handset or move the handset close to the Ignition Switch (X134) to disable perimetric testing and enable volumetric testing.
2. Any movement within the vehicle will be detected by the Alarm Sensor (X213) and indicated by flashing the Theft Alarm LED and hazard lamps.
3. Turn off ignition to end test procedure.

HANDSET INITIALISATION

The Theft Alarm Unit (Z163) must be programmed whenever handsets are replaced. The serial communications line is used to activate the "learn mode" of the Theft Alarm Unit (Z163). Then the handset(s) to be initialised must be made to transmit their coded data to the Theft Alarm Unit (Z163).


NOTE: All handset(s) must be programmed during the same learn mode period. It is not possible to simply add a handset to the Theft Alarm Unit (Z163) which has been programmed to other handsets.


When the "learn mode" of the Theft Alarm Unit (Z163) has been accessed, handsets can be programmed using the following procedure:

1. Starting conditions: Theft Alarm disarmed and vehicle mobilised.
2. Press the handset's Unlock button a minimum of 8 times.
3. If the handset has been correctly programmed, the horn will briefly sound and the hazard lamps will flash once.
4. The next handset, up to a maximum of 4, can now be programmed using the same procedure.


NOTE: It is very important that each handset be programmed separately. If the Theft Alarm Unit (Z163) receives key presses from two handsets, then neither handset will be programmed.

The "learn mode" is terminated using the serial communications line. If the Theft Alarm Unit (Z163) would not accept reprogramming, the original handset(s) will still function.






Not used




Antenna



Antenna

26 C225

1 C2096
R2 C2096
RSR
C274Z270
Passive Immobi-
lisation CoilZ163
Theft Alarm Unit

3 20 C225

WB

BN

20 21 C277

3 1 C335

C335


X213
Alarm Sensor


2 C335


B


S332 ● See Ground Dis-
tribution


E401
















































300Tdi without
EDC













300Tdi with EDC











1 C114

NK


2 C298


R



1 C2068

87


K192
Front Blower
Motor Relay








Except Japan





**See Ground Dis-
tribution**




A black outline of a right-pointing arrow.



← Except Japan


























PW


MFI-V8

3 C216


MFI-T16

300Tdi


Not used







K119
Fuel Pump Relay





Z207
Multi-Function
Relay Unit









































































































GROUND AND SPLICE INDEX


Ground	Page	Slice	Page
E100 (MFI-V8)	Y5-2	S217	Y5-14
E100 (MFI-T16)	Y5-3, 4	S238/HJ3	Y5-30
E100 (300Tdi without EDC)	Y5-5	S244	Y5-30
E100 (300Tdi with EDC)	Y5-6, 7	S253/HJ8	Y5-15
E101	Y5-8	S255/HJ8	Y5-16
E103 (MFI-V8)	Y5-9	S266	Y5-24
E104	Y5-10	S268	Y5-6
E105	Y5-10	S272 (Japan)	Y5-11
E106	Y5-10	S272 (Except Japan)	Y5-13
E108	Y5-10	S277	Y5-14
E109 (MFI-V8)	Y5-2	S288/HJ5	Y5-27
E109 (MFI-T16)	Y5-3	S289	Y5-9
E109 (300Tdi without EDC)	Y5-5	S290/HJ7	Y5-2
E109 (300Tdi with EDC)	Y5-6	S294	Y5-2
E110	Y5-10	S2003/HJ3	Y5-29
E200	Y5-11-20	S2005/H52	Y5-28
E201	Y5-21-30	S2015/HJ11	Y5-22
E203	Y5-31	S2016/HJ10	Y5-19
E204	Y5-31	S2023/HJ11	Y5-23
E301	Y5-32	S2024	Y5-24
E303	Y5-33	S2025	Y5-28
E400	Y5-34, 35	S2031/HJ5	Y5-27
E401	Y5-36, 37	S2032/HJ3	Y5-30
E404	Y5-34	S2051	Y5-31
 Slice	 Page	 S307	 Y5-12
S112 (MFI-T16)	Y5-3	S308	Y5-12
S112 (300Tdi without EDC)	Y5-5	S320	Y5-32
S122	Y5-12	S332	Y5-36
S132	Y5-31	S343 (Japan)	Y5-25
S154	Y5-3	S343 (Except Japan)	Y5-26
S155	Y5-5	S401	Y5-34
S203/HJ10	Y5-20	S402	Y5-37
S204/HJ10	Y5-20	S415	Y5-34
S216	Y5-15	S417	Y5-35
		S418	Y5-37
		S426	Y5-35
		S438	Y5-37
		S501	Y5-21
		S601	Y5-18









MFI-T16 with Air
Conditioning



MFI-T16 with Air
Conditioning




300Tdi without EDC




300Tdi without EDC



300Tdi with EDC




A black outline of a right-pointing arrow, indicating the direction of the next section.




300Tdi with EDC










MFI-V8






























Z148
Multi-Function
Unit (MFU)

Z128
Flasher Unit


K122
Heated Rear
Screen Relay












Except Japan
without Theft
Alarm


Japan and Ex-
cept Japan with
Theft Alarm











































































Component	Location	Manual	View
A.B.S. Booster Unit (Z103) ..	LH rear of engine compartment	70	4
A.B.S. Hydraulic Pump (M102)	LH rear of engine compartment	70	4
A.B.S. Load Relay (K101) ...	behind LH side of fascia on bracket	70	105
A.B.S. Pump Relay (K102) ..	behind LH side of fascia on bracket	70	106
A.B.S. Warning Relay (K103)	behind LH side of fascia on bracket	70	105
A/C Dual Pressure Switch (X102)	RH rear of engine compartment	82	77
A/C Logic Relay (K170)	behind RH footwell trim panel	82	175
Accessory Relay (K174)	behind LH footwell trim panel	86	93
Air Bag Diagnostic Control Module (Z151)	beneath centre console	76	126
Air Recirculation Solenoid (K123)	behind LH side of fascia LH side of heater evaporator unit	82	100
Air Recirculation Solenoid In-Line Fuse (P138)	behind LH side of fascia	82	108
Air Supply Selector Diode (Z208)	Heater Switch Wire Harness near C2067	82	113
Air Supply Selector Switch (X180)	centre of fascia	82	121
Alarm Bonnet Switch (X212) (300Tdi)	RH front of engine compartment	86	44
Alarm Bonnet Switch (X212) (MFI – V8) (MFI – T16)	RH front of engine compartment	86	43
Alarm Sensor (X213)	front centre of roof	86	131
Alarm Sounder (Z171) (300Tdi)	RH front of engine compartment	86	44
Alarm Sounder (Z171) (MFI – V8) (MFI – T16)	RH front of engine compartment	86	43
Anti-Lock Brake System ECU (Z108)	behind LH side of fascia on bracket	70	98
Automatic Transmission Oil Temperature Switch (X108) ..	lower LH front of engine compartment	86	25
Battery Backed Up Alarm Sounder (Z272)	RH front of engine compartment	86	47
Boost Pressure Air Temperature Sensor (X254)	top rear of engine	19	21
Boost Pressure Sensor (X253)	LH rear of engine compartment	19	11
Brake Fluid Level Switch (X111)	RH rear of engine compartment top of brake fluid reservoir	70	79
Brake Switch Vent Valve (X112)	behind RH side of fascia on brake pedal support ..	19	158
Catalyst Overheat Sensor 1 (X299)	beneath centre of vehicle	86	84
Catalyst Overheat Sensor 2 (X300)	beneath centre of vehicle	86	84
Catalyst Warning ECU (Z274)	behind LH side of fascia	86	95
Catalyst Warning Relay (K172)	behind LH side of fascia above glove box	86	
CD Changer (Z114)	beneath RH front seat	86	195

Component	Location	Manual	View
Central Locking Control Unit (Z113)	behind LH side of fascia on bracket	86	102
Clock (Z117)	centre of fascia	86	115
Clutch Pedal Position Switch (X200)	behind RH side of fascia near steering column	86	157
Column Switch Illumination (B104)	top of steering column on Ignition Switch	86	151
Compressor Clutch (K107) (300Tdi with EDC)	RH side of engine on front of A/C compressor	82	57
Compressor Clutch (K107) (300Tdi without EDC)	RH side of engine on front of A/C compressor	82	56
Compressor Clutch (K107) (MFI – T16)	RH side of engine on front of A/C compressor	82	
Compressor Clutch (K107) (MFI – V8)	RH side of engine on front of A/C compressor	82	48
Compressor Clutch Cut-out Switch (X259)	RH front of engine	82	52
Compressor Clutch Relay (K108) (300Tdi with EDC) ...	behind RH footwell trim panel	82	177
Compressor Clutch Relay (K108) (MFI – V8) (MFI – T16) (300Tdi without EDC)	behind RH footwell trim panel	82	174
Condenser Fan Coolant Temperature Switch (X113) (300Tdi with EDC)	RH front of engine on thermostat housing	82	51
Condenser Fan Coolant Temperature Switch (X113) (MFI – V8)	top centre front of engine	82	62
Condenser Fan Coolant Temperature Switch (X113) (300Tdi without EDC)	RH front of engine	82	53
Condenser Fan Relay (K109)	behind LH side of fascia on bracket	86	103
Condenser Fan Control Diode 1 (Z209)	Engine Wire Harness near C217	82	
Condenser Fan Control Diode 2 (Z210)	Main Wire Harness near C2035	82	137
Cooling Fan Motor 1 (M141) (MFI – T16 with Air Conditioning)	front of engine compartment	82	
Cooling Fan Motor 1 (M141) (MFI – T16 without Air Conditioning)	front of engine compartment	82	32
Cooling Fan Motor 2 (M142)	front of engine compartment	82	
Cooling Fan Relay (K190) ...	behind RH footwell trim panel	82	171
Crankshaft Position Sensor (X250)	lower RH rear of engine	19	72
Cruise Control Diode (Z186) ..	Cruise Control Wire Harness near C218	19	106
Cruise Control Disable Relay (K234)	behind RH footwell trim panel	19	177
Cruise Control ECU (Z121) ..	behind LH side of fascia on bracket	19	99

Component	Location	Manual	View
Cruise Control Lockout Relay (K110)	behind LH side of fascia on bracket	19	107
Cruise Control Switch (X115)	centre of fascia	19	116
Cruise Control Vacuum Pump (M103)	LH front corner of engine compartment	19	22
Data Link Connector (EGR) (X219) (300Tdi with EGR) ...	behind RH side of fascia	19	172
Data Link Connector (MFI) (X321) (MFI – T16)	RH rear corner of engine compartment	19	75
Data Link Connector (MFI) (X321) (MFI – V8)	behind RH side of fascia	19	169
Data Link Connector (OBDII) (X318)	behind RH side of fascia	19	135
Data Link Connector (Theft Alarm) (X323) (Early Production)	behind LH side of fascia near Window Lift ECU	86	101
Differential Lock Switch (X238)	top RH side of transfer box	86	90
Dim/Dip Relay 1 (K235)	behind LH side of fascia on bracket	86	104
Dim/Dip Relay 2 (K236)	behind LH footwell trim panel	86	94
Dim/Dip Resistor (K175)	LH rear of engine compartment	86	3
Direction Indicator Diode 1 (Z212)	behind instrument cluster	86	156
Direction Indicator Diode 2 (Z213)	behind instrument cluster	86	155
Direction Indicator Switch (X116)	top of steering column	86	143
Distributor (Z125) (MFI – T16)	top rear of engine	86	
Distributor (Z125) (MFI – V8)	top centre front of engine	86	18
Driver's Seat Buckle Switch (X120)	inside driver's seat belt buckle assembly	86	
Driver's Underseat Fuse Box (P108)	beneath LH front seat	86	191
EGR Control Solenoid (K171)	LH front of engine compartment	19	24
EGR Valve Control Module (Z149)	behind RH side of fascia	19	172
EGR Valve Position Sensor (X218)	LH side of engine	19	7
Electrochromic Rear View Mirror (B110)	front centre of roof	86	133
Engine Compartment Fuse Box (P125) (300Tdi)	RH front of engine compartment	86	42
Engine Compartment Fuse Box (P125) (MFI – V8) (MFI – T16)	RH front of engine compartment	86	41
Engine Control Load Relay (K116) (300Tdi with EDC) ...	behind RH footwell trim panel	19	176
Engine Control Load Relay (K116) (MFI – V8)	behind RH footwell trim panel	19	173
Engine Control Module (ECM) (Z132) (300Tdi with EDC) ...	behind RH side of fascia	19	176

Component	Location	Manual	View
Engine Control Module (ECM) (Z132) (MFI – T16)	RH rear corner of engine compartment	19	76
Engine Control Module (ECM) (Z132) (MFI – V8)	behind RH side of fascia	19	169
Engine Coolant Temperature Gauge Sensor (X114) (300Tdi with EDC)	RH front of engine on thermostat housing	86	51
Engine Coolant Temperature Gauge Sensor (X114) (300Tdi without EDC)	RH front of engine	86	52
Engine Coolant Temperature Gauge Sensor (X114) (MFI – T16)	top LH front of engine	86	15
Engine Coolant Temperature Gauge Sensor (X114) (MFI – V8)	top LH front of engine on intake manifold	86	13
Engine Coolant Temperature Sensor (X126) (300Tdi with EDC)	top centre of engine	19	21
Engine Coolant Temperature Sensor (X126) (300Tdi without EDC)	top centre of engine	19	20
Engine Coolant Temperature Sensor (X126) (MFI – T16) ..	top LH front of engine	19	15
Engine Coolant Temperature Sensor (X126) (MFI – V8) ..	top LH front of engine on intake manifold	19	13
Engine Fuel Temperature Sensor (X128) (MFI – T16) ..	top RH side of engine	19	50
Engine Fuel Temperature Sensor (X128) (MFI – V8) ...	top LH front of engine on fuel rail	19	13
Engine Immobilisation Control Unit (Spider) (Z271)	behind centre of fascia above heater evaporator unit	86	119
Engine Speed Sensor (X255)	RH rear of engine	19	69
Evaporative Emission Canister Purge Valve (K132) (MFI – T16)	RH rear of engine compartment	17	75
Evaporative Emission Canister Purge Valve (K132) (MFI – V8)	RH side of engine compartment	17	74
Fan Control Module (Z118) ..	behind RH footwell trim panel	82	174
Fan Timer Diode (Z211)	Main Wire Harness behind LH side of fascia near HJ11	82	110
Fascia Cigar Lighter (B106) ..	in front of centre console	86	122
Fascia Fuse Box (P126)	behind RH side of fascia	86	160
Flasher Unit (Z128)	behind RH side of fascia on Fascia Fuse Box	86	161
Front A/C Evaporator Temperature Switch (X101)	LH side of heater evaporator unit	82	114
Front A/C Switch (X225)	centre of fascia	82	120
Front Blower Motor (M101) ..	behind LH side of fascia LH side of heater evaporator unit	82	109
Front Blower Motor Relay (K192)	behind LH side of fascia LH side of heater evaporator unit	82	108

Component	Location	Manual	View
Front Blower Resistor Unit (Z214)	behind LH side of fascia LH side of heater evaporator unit	80	113
Front Fan Speed Switch (X247)	centre of fascia	82	120
Front Fog Lamps Relay (K230)	behind LH side of fascia on bracket	86	104
Front Fog Lamps Switch (X270)	centre of fascia	86	116
Front Interior Roof Lamp (B107)	front centre of roof	86	131
Front Screen Wash Pump (M105)	LH rear corner of engine compartment on wash fluid reservoir	84	2
Front Sunroof Motor (M143) ..	front centre of roof	76	134
Front Sunroof Switch (X261) ..	front centre of roof	76	132
Front Wipe/Wash Switch (X124)	top of steering column	84	152
Front Wiper Motor (M107) ...	RH side of bulkhead	84	80
Front Wiper Relay (K185) ...	behind RH footwell trim panel	84	167
Fuel Injector Assembly (K195)	RH side of engine	19	60
Fuel Injectors (K141) (MFI – T16)	top centre of engine	19	19
Fuel Injectors (K141) (MFI – V8)	top centre of engine	19	12
Fuel Pump Assembly (K196) ..	RH side of engine	19	59
Fuel Pump Module (Z134) ...	top of fuel tank	86	221
Fuel Pump Relay (K119)	behind RH footwell trim panel	86	173
Fuel Shut-Off Solenoid (K111) (300Tdi with EGR) ...	RH side of engine on injector pump	19	55
Fuel Shut-Off Solenoid (K111) (300Tdi without EGR)	RH side of engine on injector pump	19	54
Fusible Link (P119)	RH front of engine compartment behind battery	86	42
Generator (Z106) (300Tdi) ..	lower LH side of engine	86	17
Generator (Z106) (MFI – T16 with Air Conditioning)	LH front of engine	86	
Generator (Z106) (MFI – T16 without Air Conditioning)	RH side of engine	86	65
Generator (Z106) (MFI – V8)	top centre front of engine	86	63
Generator Suppression Capacitor (Z182) (300Tdi)	lower LH side of engine on Generator	86	17
Generator Suppression Capacitor (Z182) (MFI – T16 with Air Conditioning)	LH front of engine on Generator	86	
Generator Suppression Capacitor (Z182) (MFI – T16 without Air Conditioning)	RH side of engine on Generator	86	65
Generator Suppression Capacitor (Z182) (MFI – V8) ...	top centre front of engine on Generator	86	63
Glow Plug Timer Unit (Z135) ..	RH side of engine compartment	19	45
Glow Plugs (P120)	RH side of engine	19	58
Handbrake Switch (X191) ...	beneath centre console on handbrake lever	86	128

Component	Location	Manual	View
Hazard Switch (X220)	centre of fascia	86	115
Headlamp Level Switch (X130)	top RH side of fascia right of steering column	86	
Headlamp Wash Pump (M110)	LH rear corner of engine compartment on wash fluid reservoir	86	2
Heated Rear Screen Relay (K122)	behind RH side of fascia on Fascia Fuse Box	86	161
Heated Rear Screen Switch (X132)	top RH side of fascia near Instrument Cluster	86	147
Horn Relay (K189)	behind LH footwell trim panel	86	93
Horn Switches (X258)	in steering wheel	86	142
Idle Air Control Valve (M112) (MFI – T16)	RH front of engine	19	49
Idle Air Control Valve (M112) (MFI – V8)	top rear of engine	19	64
Ignition Coil (Z140) (MFI – V8)	LH front of engine compartment	86	29
Ignition Coil 1 (Z217) (MFI – T16)	top rear of engine	86	
Ignition Coil 2 (Z218) (MFI – T16)	top rear of engine	86	
Ignition Coil Noise Suppressor (Z237)	LH front corner of engine compartment on Ignition Coil	86	31
Ignition Control Module (Z139)	LH front of engine compartment near Ignition Coil ..	86	31
Ignition Key Lock Solenoid (K191)	top of steering column	86	146
Ignition Load Relay (K127) ..	behind RH footwell trim panel	86	168
Ignition Switch (X134)	top of steering column	86	144
Inertia Fuel Shut-Off Switch (X135)	LH rear corner of engine compartment	19	1
Injector Needle Lift Sensor (X256)	RH rear of engine	19	69
Instrument Cluster (Z142)	top RH side of fascia	86	154
Instrument Illumination Rheostat (Z143)	top RH side of fascia near Instrument Cluster	86	
Intake Air Temperature Sensor (X248)	RH rear of engine	19	
Interlock Diode 1 (Z189)	Main Wire Harness near Cruise Control ECU	86	
Interlock Diode 2 (Z190)	Main Wire Harness near Cruise Control ECU	86	
Interlock Relay 1 (K153)	behind LH side of fascia above glove box	86	
Interlock Relay 2 (K151)	behind LH side of fascia above glove box	86	
Key-Barrel Switch (X230)	top of steering column on Ignition Switch	86	145
Key-In Switch (X229) (Without Shift Interlock)	top of steering column on Ignition Switch	86	144
Key-In Switch (X229) (With Shift Interlock)	top of steering column on Ignition Switch	86	145
Knock Sensor (X249)	RH side of engine	19	50
Left Condenser Fan Motor (M113)	behind front grille	86	34

Component	Location	Manual	View
Left Front Door Lock Actuator (M114)	in rear of LH front door	76	182
Left Front Door Switch (X150)	front of LH front door jamb	86	178
Left Front Indicator Lamp (B153)	LH front of vehicle	86	27
Left Front Seat Control Switch (X152)	LH side of centre console	86	129
Left Front Side Lamp (B166)	LH front of vehicle	86	37
Left Front Wheel Speed Sensor (X137)	behind LH front wheel	70	82
Left Front Window Motor (M130)	in front of LH front door	86	183
Left Front Window Switch (X122)	in rear of centre console	86	124
Left Headlamp (B116)	LH front of vehicle	86	36
Left Headlamp Level Unit (Z145)	behind LH headlamp	86	28
Left Heated Oxygen Sensor (X139) (MFI – T16)	lower LH side of engine compartment	19	9
Left Heated Oxygen Sensor (X139) (MFI – V8)	lower LH rear of engine compartment	19	81
Left Horn (K128)	behind LH side of front grille	86	33
Left Mirror Actuator (M115)	top front of LH front door	76	181
Left Rear Door Lock Actuator (M117)	inside front of LH rear door	76	187
Left Rear Door Switch (X142)	in lower part of LH B-post	86	186
Left Rear Indicator Lamp (B163)	LH side of rear bumper	86	222
Left Rear Lamp Assembly (B121)	LH rear of luggage compartment	86	204
Left Rear Side Marker Lamp (B159)	LH side of rear bumper	86	223
Left Rear Wheel Speed Sensor (X140)	behind LH rear wheel	70	83
Left Rear Window Console Switch (X141)	in rear of centre console	86	125
Left Rear Window Door Switch (X188)	inside front of LH rear door	86	188
Left Rear Window Motor (M116)	inside front of LH rear door	86	189
Left Repeater Lamp (B122)	LH front side of vehicle	86	26
Left Seat Power Relay (K113)	beneath LH front seat	86	190
Left Seat Power Relay Diode (Z223)	beneath centre console	86	
Left Tail Lamp (B155)	LH side of rear bumper	86	222
Left Vanity Mirror Lamp (B186)	LH front of roof	86	180
Main Lighting Switch (X145)	top of steering column	86	143
Main Rear A/C Switch (X239)	centre of fascia	82	121
Mass Air Flow Sensor (X105) (300Tdi with EDC)	LH side of engine compartment on air intake assembly	19	11

Component	Location	Manual	View
Mass Air Flow Sensor (X105) (MFI – V8)	LH side of engine compartment on air intake assembly	19	10
Mirror Adjustment Switch (X146a)	top RH side of fascia right of steering column	86	149
Multi–Function Relay Unit (Z207)	behind RH side of fascia	19	170
Multi–Function Unit (MFU) (Z148)	behind RH side of fascia on Fascia Fuse Box	86	163
Multiport Fuel Injection Ignition Resistor 1 (K115)	LH front of engine compartment near Ignition Coil ..	86	29
Multiport Fuel Injection Ignition Resistor 2 (K168)	LH front of engine compartment near Ignition Coil ..	86	29
Neutral Sense Diode (Z273) ..	Main Wire Harness behind LH side of fascia near HJ2	86	110
Neutral Sense Resistor (K166)	Gearbox Wire Harness near C105	86	
Oil Pressure Switch (X149) (300Tdi with EDC)	lower RH side of engine	86	59
Oil Pressure Switch (X149) (300Tdi with EGR)	lower RH side of engine	86	55
Oil Pressure Switch (X149) (300Tdi without EGR)	lower RH side of engine	86	54
Oil Pressure Switch (X149) (MFI – T16)	lower RH side of engine near oil filter	86	40
Oil Pressure Switch (X149) (MFI – V8)	lower RH side of engine near oil filter	86	39
Park/Neutral Position Switch (X167)	LH side of transmission	86	85
Passenger's Rear A/C Switch (X240)	centre of roof	82	196
Passenger's Rear Fan Speed Switch (X246)	centre of roof	82	196
Passenger's Rear Sunroof Switch (X264)	centre of roof	76	198
Passenger's Underseat Fuse Box (P116)	beneath LH front seat	86	190
Passive Immobilisation Coil (Z270)	top of steering column on Ignition Switch	86	153
Phase Tap Resistor (K184) (300Tdi)	lower LH side of engine on Generator	86	17
Phase Tap Resistor (K184) (MFI – T16 with Air Conditioning)	LH front of engine on Generator	86	
Phase Tap Resistor (K184) (MFI – T16 without Air Conditioning)	RH side of engine on Generator	86	65
Phase Tap Resistor (K184) (MFI – V8)	top centre front of engine on Generator	86	63
Power Amplifier Relay (K187)	behind LH side of fascia above glove box	86	
Power Wash Relay (K182) ..	behind LH side of fascia on bracket	86	103
Radio (Z111) (High Line Radio)	centre of fascia	86	118

Component	Location	Manual	View
Radio (Z111) (Low Line)	centre of fascia	86	117
Radio) (Mid Line Radio)	centre of fascia	86	
Radio Amplifier (Z175)	behind LH side of fascia	86	
Radio Tune Resistor (Z235)	Fascia Wire Harness behind instrument cluster near Rear Screen Wipe Switch	86	156
Radio Tune Switch (X233)	top RH side of fascia near Instrument Cluster	86	150
Radio Volume Down Switch (X236)	top RH side of fascia near Instrument Cluster	86	148
Radio Volume Resistor (Z234)	Fascia Wire Harness behind instrument cluster near Heated Rear Screen Switch	86	155
Radio Volume Up Switch (X235)	top RH side of fascia near Instrument Cluster	86	148
Radio Waveband Resistor (Z236)	Fascia Wire Harness behind instrument cluster near Rear Screen Wipe Switch	86	156
Radio Waveband Switch (X234)	top RH side of fascia near Instrument Cluster	86	150
Rear A/C Control Relay (K194)	LH side of luggage compartment on rear A/C evaporator	82	201
Rear A/C Evaporator Temperature Switch (X260)	LH side of luggage compartment on rear A/C evaporator	82	202
Rear A/C Fan Speed Relay (K205)	LH side of luggage compartment on rear A/C evaporator	82	203
Rear A/C Illumination Relay (K204)	LH side of luggage compartment on rear A/C evaporator	82	202
Rear A/C Refrigerant Control Valve (K207)	LH side of luggage compartment on rear A/C evaporator	82	201
Rear A/C Refrigerant Control Valve Diode (Z228)	LH rear of luggage compartment near C448	82	205
Rear A/C Relay Diode (Z275)	LH rear of luggage compartment near C448	82	205
Rear A/C Switch Amplifier (Z216)	LH side of luggage compartment on rear A/C evaporator	82	200
Rear A/C Switch Amplifier In-Line Fuse (P140)	LH rear of luggage compartment behind trim panel	82	204
Rear Blower Motor (M145)	LH side of luggage compartment on rear A/C evaporator	82	200
Rear Blower Motor Relay (K193)	LH side of luggage compartment on rear A/C evaporator	82	203
Rear Blower Resistor Unit (Z215)	LH side of luggage compartment on rear A/C evaporator	82	
Rear End Door Switch (X265)	in RH side of tailgate door jamb	86	211
Rear Fog Guard Lamps Switch (X154)	top RH side of fascia near Instrument Cluster	86	147
Rear Fog Lamps Relay (K231)	behind LH side of fascia on bracket	86	104
Rear Interior Roof Lamp (B124)	centre of roof	86	197
Rear Screen Wash Pump (M119)	LH rear corner of engine compartment on wash fluid reservoir	86	2
Rear Screen Wash Switch (X222)	top RH side of fascia near Instrument Cluster	86	149
Rear Screen Wipe Switch (X221)	top RH side of fascia near Instrument Cluster	86	149

Component	Location	Manual	View
Rear Sunroof Lockout Switch (X263)	front centre of roof	76	133
Rear Sunroof Motor (M144)	centre of roof	76	199
Rear Sunroof Switch (X262)	front centre of roof	76	132
Rear Window Isolation Switch (X187)	in rear of centre console	86	125
Rear Wiper Motor (M120)	RH side of tailgate	84	213
Rear Wiper Relay (K183)	behind LH footwell trim panel	86	94
Reverse Switch (X157)	LH side of transmission	86	87
Right Condenser Fan Motor (M121)	behind front grille	82	35
Right Front Seat Control Switch (X121)	RH side of centre console	86	130
Right Front Door Key Switch (X202)	in top rear of RH front door at door handle	86	185
Right Front Door Lock Actuator (M122)	in rear of RH front door	76	184
Right Front Door Switch (X118)	front of RH front door jamb	86	178
Right Front Indicator Lamp (B154)	RH front of vehicle	86	27
Right Front Side Lamp (B167)	RH front of vehicle	86	37
Right Front Wheel Speed Sensor (X158)	behind RH front wheel	70	82
Right Front Window Motor (M133)	in front of RH front door	86	183
Right Front Window Switch (X151)	in rear of centre console	86	124
Right Headlamp (B130)	RH front of vehicle	86	36
Right Headlamp Level Unit (Z155)	behind RH headlamp	86	28
Right Heated Oxygen Sensor (X160)	lower RH rear of engine compartment	19	73
Right Horn (K134)	behind RH side of front grille	86	33
Right Mirror Actuator (M123)	top front of RH front door	86	181
Right Rear Door Lock Actuator (M125)	inside front of RH rear door	76	187
Right Rear Door Switch (X163)	in lower part of RH B-post	86	186
Right Rear Indicator Lamp (B165)	RH side of rear bumper	86	224
Right Rear Lamp Assembly (B136)	RH rear of luggage compartment	86	209
Right Rear Side Marker Lamp (B160)	RH side of rear bumper	86	223
Right Rear Wheel Speed Sensor (X161)	behind RH rear wheel	70	83
Right Rear Window Console Switch (X162)	in rear of centre console	86	125
Right Rear Window Door Switch (X189)	inside front of RH rear door	86	188

Component	Location	Manual	View
Right Rear Window Motor (M124)	inside front of RH rear door	86	189
Right Repeater Lamp (B137)	RH front side of vehicle	86	26
Right Seat Power Relay (K131)	beneath LH front seat	86	191
Right Seat Power Relay Diode (Z222)	beneath centre console	86	86
Right Tail Lamp (B156)	RH side of rear bumper	86	224
Right Vanity Mirror Lamp (B187)	RH front of roof	86	180
Rotary Coupler (Z119)	top of steering column	76	144
Satellite Fuse Box 1 (P127) ..	behind RH side of fascia on Fascia Fuse Box	86	160
Satellite Fuse Box 2 (P128) ..	behind RH side of fascia on Fascia Fuse Box	86	160
Saudi Junction Connector (X241)	behind RH side of fascia near Fascia Fuse Box	86	165
Seat Base Motor (M126)	underside of respective front seat	86	193
Seat Height (Front) Motor (M127)	underside of respective front seat	86	192
Seat Height (Rear) Motor (M128)	underside of respective front seat	86	193
Seat Recline Motor (M129) ..	underside of respective front seat	86	192
Sounder Relay (K160)	behind LH footwell trim panel	86	94
Speed Trip Module (Z164) ...	behind LH side of fascia on bracket	19	107
Starter (M134) (300Tdi with EDC)	lower LH side of engine	86	8
Starter (M134) (300Tdi without EDC)	lower LH side of engine	86	7
Starter (M134) (MFI – T16) ..	lower RH side of engine	86	71
Starter (M134) (MFI – V8) ..	lower RH side of engine	86	70
Starter Relay Diode (Z158) ..	Main Wire Harness near Starter Solenoid Relay	86	171
Starter Solenoid (K136) (300Tdi with EDC)	lower LH side of engine	86	8
Starter Solenoid (K136) (300Tdi without EDC)	lower LH side of engine	86	7
Starter Solenoid (K136) (MFI – T16)	lower RH side of engine	86	71
Starter Solenoid (K136) (MFI – V8)	lower RH side of engine	86	70
Starter Solenoid Relay (K137)	behind RH footwell trim panel	86	168
Steering Wheel Cruise Switches (X266)	in steering wheel	19	142
Stop Lamp Switch (X168) ...	behind RH side of fascia on brake pedal support ..	86	159
Stop Lamp Switch Suppressor (Z206)	behind RH side of fascia near steering column	86	159
Subwoofer (K146)	LH side of tailgate	86	216
Subwoofer Amplifier (Z176) ..	LH side of tailgate on Subwoofer	86	216
Sunroof Control Unit (Z162) ..	front centre of roof	76	134
Tailgate Lock Actuator (M132)	LH side of tailgate	76	214
Theft Alarm Unit (Z163)	behind LH side of fascia on bracket	86	102

Component	Location	Manual	View
Throttle Position Sensor (X257) (300Tdi with EDC)	behind RH side of fascia	19	141
Throttle Position Sensor (X171) (300Tdi with EGR)	RH side of engine on injector pump	19	55
Throttle Position Sensor (X171) (MFI – T16)	RH front of engine	19	49
Throttle Position Sensor (X171) (MFI – V8)	top LH front of engine	19	14
Trailer Auxiliary Socket (X172)	RH rear of luggage compartment behind trim panel	86	225
Transfer Box Oil Temperature Switch (X174)	LH side of transfer box	86	88
Transfer Box Position Switch (X175)	top RH side of transfer box	86	91
Transfer Box Solenoid (K161)	top RH side of transfer box	86	91
Transfer Box Solenoid Diode (Z232)	Gearbox Wire Harness near Differential Lock Switch	86	
Transmission Range Selector Switch (Z110)	beneath centre console near transmission range selector	86	123
Tune Select Resistor (K140)	behind RH side of fascia	19	140
Vehicle Speed Sensor (X190)	LH side of transfer box	86	89
Window Lift ECU (Z147)	behind LH side of fascia on bracket	86	101
Connector	Location		View
C100 (3–W)	RH front of engine compartment on Engine Compartment Fuse Box	46	
C101 (4–W)	RH front of engine compartment on Engine Compartment Fuse Box	46	
C103 (3–B)	RH front of engine compartment on Right Headlamp	36	
C104 (3–B)	LH front of engine compartment on Left Headlamp	36	
C105 (13–B)	LH rear corner of engine compartment	1	
C109 (2–B)	LH front of engine compartment on Left Front Side Lamp	37	
C110 (2–B)	RH front of engine compartment on Right Front Side Lamp	37	
C112 (3–W) (MFI – V8)	LH rear corner of engine to Left Heated Oxygen Sensor	81	
C112 (4–B) (MFI – T16)	lower LH side of engine to Left Heated Oxygen Sensor	9	
C113 (3–W)	RH rear corner of engine to Right Heated Oxygen Sensor	64	
C114 (2–W)	RH front of engine compartment on Engine Compartment Fuse Box	46	
C115 (3–W)	RH front of engine compartment on Engine Compartment Fuse Box	46	
C116 (1–W)	RH front of engine compartment on Engine Compartment Fuse Box	46	
C120 (2–W)	LH rear corner of engine compartment on Rear Screen Wash Pump	2	
C123 (2–B)	RH front side of vehicle on Right Repeater Lamp	26	
C124 (2–B)	LH front side of vehicle on Left Repeater Lamp	26	
C125 (2–B)	LH rear of engine compartment to A.B.S. Hydraulic Pump	4	
C127 (3–B)	RH rear of engine compartment on Brake Fluid Level Switch	79	
C129 (13–B)	LH rear of engine compartment on A.B.S. Booster Unit	4	
C130 (2–WB)	LH rear of engine compartment to Left Front Wheel Speed Sensor	4	
C131 (2–WB)	RH side of engine compartment to Right Front Wheel Speed Sensor	67	
C132 (4–B) (MFI – V8)	top rear of engine on Idle Air Control Valve	64	
C132 (6–B) (MFI – T16)	RH front of engine on Idle Air Control Valve	49	
C133 (5–B) (300Tdi with EDC)	LH side of engine compartment on Mass Air Flow Sensor	11	

Connector	Location	View
C133 (6-B) (MFI – V8)	LH side of engine compartment on Mass Air Flow Sensor	10
C134 (2-B) (MFI – V8)	top LH side of engine on Fuel Injectors	12
C134 (2-B) (MFI – T16)	top centre of engine on Fuel Injectors	19
C135 (2-B) (MFI – V8)	top RH side of engine on Fuel Injectors	61
C135 (2-B) (MFI – T16)	top centre of engine on Fuel Injectors	19
C136 (2-B) (MFI – V8)	top LH side of engine on Fuel Injectors	12
C136 (2-B) (MFI – T16)	top centre of engine on Fuel Injectors	19
C137 (2-B) (MFI – V8)	top RH side of engine on Fuel Injectors	61
C137 (2-B) (MFI – T16)	top centre of engine on Fuel Injectors	19
C138 (2-B) (MFI – V8)	top LH side of engine on Fuel Injectors	12
C139 (2-B) (MFI – V8)	top RH side of engine on Fuel Injectors	61
C140 (2-B) (MFI – V8)	top LH rear of engine on Fuel Injectors	5
C141 (2-B) (MFI – V8)	top RH side of engine on Fuel Injectors	64
C142 (2-N) (MFI – T16)	lower RH side of engine on Oil Pressure Switch	40
C144 (2-B) (MFI – V8)	RH side of engine compartment on Evaporative Emission Canister Purge Valve	74
C144 (2-B) (MFI – T16)	RH rear of engine compartment on Evaporative Emission Canister Purge Valve	75
C145 (2-W) (MFI – V8)	top RH side of engine to Compressor Clutch	48
C145 (2-W) (MFI – T16)	RH side of engine to Compressor Clutch	
C145 (2-W) (300Tdi with EDC)	RH side of engine to Compressor Clutch	57
C145 (2-W) (300Tdi without EDC)	RH side of engine to Compressor Clutch	56
C146 (2-B) (MFI – V8)	top centre front of engine on Condenser Fan Coolant Temperature Switch	62
C146 (2-B) (300Tdi with EDC)	RH front of engine on Condenser Fan Coolant Temperature Switch	51
C146 (2-B) (300Tdi without EDC)	RH front of engine on Condenser Fan Coolant Temperature Switch	53
C148 (2-B)	top centre front of engine to Distributor	18
C149 (3-B) (MFI – V8)	top LH front of engine to Throttle Position Sensor	14
C149 (3-B) (MFI – T16)	RH front of engine on Throttle Position Sensor	49
C150 (2-S) (MFI – V8)	top LH front of engine on Engine Fuel Temperature Sensor	13
C150 (2-S) (MFI – T16)	RH side of engine on Engine Fuel Temperature Sensor	50
C152 (2-N) (MFI – V8)	top LH front of engine on Engine Coolant Temperature Sensor	13
C152 (2-N) (MFI – T16)	top LH front of engine on Engine Coolant Temperature Sensor	15
C152 (2-N) (300Tdi with EDC)	top centre of engine on Engine Coolant Temperature Sensor	21
C152 (2-N) (300Tdi without EDC)	top centre of engine on Engine Coolant Temperature Sensor	20
C153 (1-B)	LH front of engine compartment on Ignition Coil	30
C154 (1-W)	LH front of engine compartment on Ignition Coil	30
C155 (1-B)	LH front of engine compartment on Ignition Coil	30
C156 (1-W)	LH front of engine compartment on Ignition Coil	30
C159 (6-B)	RH side of engine compartment on Glow Plug Timer Unit	45
C160 (3-B)	RH side of engine to Throttle Position Sensor	66

Connector	Location	View
C161 (1-W) (300Tdi without EGR)	RH side of engine to Fuel Shut-Off Solenoid	54
C162 (2-B)	RH front of engine on Compressor Clutch Cut-out Switch	52
C164 (3-B)	LH side of engine on EGR Valve Position Sensor	7
C165 (2-B) (300Tdi without EDC)	LH front of engine compartment on EGR Control Solenoid	24
C165 (2-S) (300Tdi with EDC)	LH front of engine compartment on EGR Control Solenoid	24
C166 (2-B)	lower LH front of engine compartment on Automatic Transmission Oil Temperature Switch	25
C167 (3-W)	LH front corner of engine compartment on Cruise Control Vacuum Pump	22
C168 (2-B)	behind LH side of front grille on Left Horn	33
C169 (2-B)	behind RH side of front grille on Right Horn	33
C170 (2-R)	LH rear corner of engine compartment on Front Screen Wash Pump ..	2
C171 (3-B)	LH rear corner of engine compartment on Inertia Fuel Shut-Off Switch ..	1
C173 (2-B)	LH rear corner of engine compartment on Headlamp Wash Pump ..	2
C177 (2-B)	LH rear of engine compartment to Dim/Dip Resistor	3
C178 (2-B) (MFI – V8) (MFI – T16)	RH front of engine compartment to Alarm Bonnet Switch	43
C178 (2-B) (300Tdi)	RH front of engine compartment to Alarm Bonnet Switch	44
C181 (2-S)	RH rear of engine compartment on A/C Dual Pressure Switch	77
C182 (2-B)	behind front grille to Right Condenser Fan Motor	35
C183 (2-B)	behind front grille to Left Condenser Fan Motor	34
C190 (3-B)	behind LH headlamp on Left Headlamp Level Unit	28
C191 (3-B)	behind RH headlamp on Right Headlamp Level Unit	28
C195 (4-W)	RH rear of engine compartment	78
C196 (2-NU)	RH rear of engine to Injector Needle Lift Sensor	69
C197 (3-B)	RH rear of engine to Engine Speed Sensor	69
C198 (3-W) (300Tdi with EDC)	RH side of engine to Fuel Injector Assembly	60
C198 (6-B) (MFI – T16)	top rear of engine to Fuel Injectors	68
C199 (8-W)	RH side of engine to Fuel Pump Assembly	59
C2000 (2-G) (MFI – T16) ...	RH rear of engine on Intake Air Temperature Sensor	
C2000 (2-G) (300Tdi with EDC)	top rear of engine on Boost Pressure Air Temperature Sensor	21
C2001 (3-B)	LH rear of engine compartment on Boost Pressure Sensor	11
C2002 (3-B)	top rear of engine on Ignition Coil 1	
C2003 (3-B)	top rear of engine on Ignition Coil 2	
C2004 (2-U)	lower RH rear of engine to Crankshaft Position Sensor	72
C2005 (2-W)	RH side of engine on Knock Sensor	50
C2006 (3-W)	RH rear corner of engine compartment Data Link Connector (MFI)	75
C2007 (36-B)	RH rear corner of engine compartment on Engine Control Module (ECM)	76
C2008 (18-B)	RH rear corner of engine compartment on Engine Control Module (ECM)	76
C2009 (2-B)	LH front of vehicle on Left Front Indicator Lamp	27
C2010 (2-B)	RH front of vehicle on Right Front Indicator Lamp	27

Connector	Location	View
C1011 (2-W) (MFI – T16 with Air Conditioning)	front of engine compartment to Cooling Fan Motor 1	
C1011 (2-W) (MFI – T16 without Air Conditioning)	front of engine compartment to Cooling Fan Motor 1	32
C1012 (2-W)	front of engine compartment to Cooling Fan Motor 2	
C1018 (1-W)	LH front of engine compartment on Ignition Coil	30
C1024 (2-B)	LH front of engine compartment to Left Front Fog Lamp	36
C1025 (2-B)	RH front of engine compartment to Right Front Fog Lamp	36
C1031 (4-N)	RH front of engine compartment on Battery Backed Up Alarm Sounder .	47
C1035 (3-B)	LH front of engine compartment on Ignition Control Module	31
C1036 (3-B)	LH front of engine compartment to Ignition Control Module	31
C201 (7-W)	top of steering column on Main Lighting Switch	143
C203 (7-W)	behind RH side of fascia on Fascia Fuse Box	163
C204 (24-W)	behind RH side of fascia on Fascia Fuse Box	164
C205 (24-B)	behind RH side of fascia on Multi–Function Unit (MFU)	163
C206 (4-W)	behind RH side of fascia on Fascia Fuse Box	165
C207 (10-B)	on Instrument Cluster	154
C208 (18-W)	behind RH side of fascia on Fascia Fuse Box	162
C209 (20-R)	behind RH side of fascia left of steering column	136
C211 (10-W)	behind RH side of fascia on Fascia Fuse Box	164
C212 (14-W)	behind LH side of fascia	97
C214 (3-BU)	top RH side of fascia to Instrument Illumination Rheostat	
C215 (24-Y)	behind RH side of fascia left of steering column	136
C216 (7-N)	behind RH side of fascia right of heater evaporator unit	139
C217 (24-W)	behind RH side of fascia right of heater evaporator unit	139
C218 (8-W)	behind LH side of fascia on bracket	107
C219 (4-W)	behind RH side of fascia on Fascia Fuse Box	162
C220 (3-N)	behind RH side of fascia to Ignition Switch	158
C221 (10-W)	on Instrument Cluster	156
C222 (10-W)	on Instrument Cluster	154
C223 (5-U)	on Instrument Cluster	154
C224 (6-W)	behind RH side of fascia to Front Wiper Motor	138
C225 (26-S) (Japan)	behind LH side of fascia on Central Locking Control Unit	102
C225 (26-S) (Except Japan)	behind LH side of fascia on Theft Alarm Unit	102
C226 (3-W)	behind RH side of fascia on Fascia Fuse Box	165
C227 (4-B)	behind RH side of fascia on Stop Lamp Switch	159
C228 (8-B)	behind RH side of fascia on Mirror Adjustment Switch	149
C229 (1-W)	behind RH side of fascia on Fascia Fuse Box	163
C230 (8-S) (High Line Radio)	centre of fascia on Radio	118
C230 (8-S) (Low Line Radio) (Mid Line Radio)	centre of fascia on Radio	117
C232 (2-S)	RH A–post to Right Front Tweeter	179
C238 (5-Y) (MFI – T16)	behind RH footwell trim panel on Cooling Fan Relay	171
C238 (9-B) (MFI – V8)	behind RH footwell trim panel on Fan Control Module	174
C239 (5-B) (MFI – V8)	behind RH footwell trim panel on Engine Control Load Relay	173
C239 (5-Y) (300Tdi with EDC)	behind RH footwell trim panel on Engine Control Load Relay	176

Connector	Location	View
C240 (5-U)	behind RH footwell trim panel on Fuel Pump Relay	173
C241 (5-Y) (300Tdi with EDC)	behind RH footwell trim panel on Compressor Clutch Relay	177
C241 (5-Y) (MFI – V8) (MFI – T16) (300Tdi without EDC)	behind RH footwell trim panel on Compressor Clutch Relay	174
C242 (5-Y)	behind RH footwell trim panel on A/C Logic Relay	175
C243 (40-B) (MFI – V8)	behind RH side of fascia on Engine Control Module (ECM)	169
C243 (55-B) (300Tdi with EDC)	behind RH side of fascia on Engine Control Module (ECM)	176
C245 (5-W)	behind RH side of fascia Data Link Connector (MFI)	169
C246 (2-U)	behind RH side of fascia on Tune Select Resistor	140
C247 (16-B)	behind RH side of fascia on EGR Valve Control Module	172
C248 (3-W)	behind RH side of fascia Data Link Connector (EGR)	172
C249 (5-G)	top RH side of fascia on Rear Screen Wash Switch	149
C250 (5-W)	top RH side of fascia on Rear Screen Wipe Switch	149
C252 (6-R)	behind RH side of fascia near steering column	136
C254 (1-W)	behind RH side of fascia on Fascia Fuse Box	162
C255 (1-B)	on Instrument Cluster	154
C259 (6-W)	behind RH side of fascia on Headlamp Level Switch	161
C260 (10-R)	centre of fascia on Radio	117
C262 (5-U)	centre of fascia on Cruise Control Switch	116
C263 (5-B)	top RH side of fascia on Rear Fog Guard Lamps Switch	147
C264 (5-U)	top RH side of fascia on Heated Rear Screen Switch	147
C267 (10-W)	centre of fascia on Hazard Switch	115
C268 (8-N) (High Line Radio)	centre of fascia on Radio	118
C268 (8-N) (Low Line Radio) (Mid Line Radio)	centre of fascia on Radio	117
C270 (4-B)	centre of fascia on Clock	115
C274 (12-W) (Japan)	behind LH side of fascia on Central Locking Control Unit	102
C274 (12-W) (Except Japan)	behind LH side of fascia on Theft Alarm Unit	102
C277 (23-W)	behind LH side of fascia	97
C280 (5-W)	behind LH footwell trim panel on Sounder Relay	94
C281 (5-G)	behind LH footwell trim panel on Rear Wiper Relay	94
C282 (5-Y)	behind LH footwell trim panel on Accessory Relay	93
C283 (5-Y)	behind LH footwell trim panel on Horn Relay	93
C284 (15-B)	behind LH side of fascia on Cruise Control ECU	99
C285 (4-W)	behind LH side of fascia on Catalyst Warning ECU	96
C286 (4-W)	behind LH side of fascia on Catalyst Warning ECU	95
C287 (10-W)	behind LH side of fascia on Window Lift ECU	101
C288 (8-W)	behind LH side of fascia on Window Lift ECU	101
C292 (5-Y)	behind LH side of fascia on Condenser Fan Relay	103
C293 (5-U)	behind LH side of fascia on Dim/Dip Relay 1	104
C298 (3-W)	behind LH side of fascia	109
C299 (5-Y)	behind LH side of fascia on Catalyst Warning Relay	
C2000 (5-Y)	behind LH side of fascia on Interlock Relay 1	
C2001 (5-Y)	behind LH side of fascia on Interlock Relay 2	


Connector	Location	View
C2005 (2-W)	behind RH side of fascia on Brake Switch Vent Valve	158
C2006 (5-Y)	behind RH footwell trim panel on Starter Solenoid Relay	168
C2007 (5-Y)	behind RH footwell trim panel on Ignition Load Relay	168
C2008 (5-G)	behind RH footwell trim panel on Front Wiper Relay	167
C2009 (4-W)	top of steering column on Direction Indicator Switch	143
C2010 (6-W)	top of steering column to Rotary Coupler	144
C2011 (6-W)	top of steering column on Front Wipe/Wash Switch	152
C2012 (8-W)	top of steering column	145
C2013 (4-B)	top of steering column	151
C2014 (2-B)	top of steering column on Ignition Key Lock Solenoid	146
C2015 (8-W)	top of steering column on Front Wipe/Wash Switch	152
C2016 (1-W)	behind RH side of fascia on Fascia Fuse Box	162
C2021 (5-B) (Manual Transmission)	behind LH side of fascia on Speed Trip Module	107
C2021 (5-G) (Automatic Transmission)	behind LH side of fascia on Cruise Control Lockout Relay	107
C2022 (5-W)	behind heater and A/C control panel on Front Fan Speed Switch	120
C2023 (4-W)	behind heater and A/C control panel	120
C2024 (5-U)	behind heater and A/C control panel on Main Rear A/C Switch	121
C2025 (5-W)	behind heater and A/C control panel on Front A/C Switch	120
C2026 (5-B)	behind heater and A/C control panel on Air Supply Selector Switch	121
C2027 (5-W)	behind LH side of fascia LH side of heater evaporator unit	112
C2028 (6-W)	behind RH footwell trim panel on E200	167
C2029 (6-W)	behind LH footwell trim panel on E201	92
C2035 (2-W)	behind RH side of fascia on Clutch Pedal Position Switch	157
C2036 (7-BW)	in steering wheel to Rotary Coupler	142
C2051 (8-B)	behind RH side of fascia on Multi-Function Relay Unit	170
C2052 (6-B)	behind RH side of fascia on Multi-Function Relay Unit	170
C2053 (5-Y)	behind LH side of fascia on Power Amplifier Relay	
C2054 (18-W)	behind LH side of fascia on Radio Amplifier	
C2055 (13-W)	behind RH side of fascia left of steering column	136
C2056 (5-B)	top RH side of fascia on Radio Tune Switch	150
C2057 (5-U)	top RH side of fascia on Radio Waveband Switch	150
C2058 (5-W)	top RH side of fascia on Radio Volume Up Switch	148
C2059 (5-G)	top RH side of fascia on Radio Volume Down Switch	148
C2060 (5-W)	centre of fascia to Radio	117
C2061 (7-B)	centre of fascia on Radio	118
C2062 (1-B)	behind RH side of fascia Saudi Junction Connector	165
C2063 (2-B)	behind RH side of fascia to Stop Lamp Switch Suppressor	159
C2064 (2-W)	behind LH side of fascia on Catalyst Warning ECU	96
C2065 (2-W)	behind LH side of fascia on Catalyst Warning ECU	95
C2066 (8-W)	behind LH side of fascia LH side of heater evaporator unit	111
C2067 (10-W)	behind LH side of fascia LH side of heater evaporator unit	112
C2068 (5-W)	behind LH side of fascia on Front Blower Motor Relay	108
C2069 (2-B)	behind LH side of fascia on Front Blower Motor	109
C2070 (4-B)	behind LH side of fascia on Front Blower Resistor Unit	113

Connector	Location	View
C2071 (2-B)	behind LH side of fascia on Air Recirculation Solenoid In-Line Fuse ..	108
C2072 (4-Y)	behind LH side of fascia on Air Recirculation Solenoid ..	100
C2073 (10-W)	behind RH side of fascia right of heater evaporator unit ..	139
C2074 (5-Y)	behind LH side of fascia on Power Wash Relay ..	103
C2079 (2-B)	centre of fascia on Radio ..	117
C2080 (-B)	centre of fascia on Radio ..	118
C2082 (6-W)	behind LH side of fascia ..	97
C2083 (16-S)	behind RH side of fascia Data Link Connector (OBDII) ..	135
C2084 (35-B)	behind LH side of fascia on Anti-Lock Brake System ECU ..	98
C2085 (3-W)	behind RH footwell trim panel ..	171
C2090 (5-Y)	behind LH side of fascia on Front Fog Lamps Relay ..	104
C2091 (5-G)	behind LH side of fascia on Rear Fog Lamps Relay ..	104
C2092 (5-G)	behind LH side of fascia on A.B.S. Warning Relay ..	105
C2093 (5-Y)	behind LH side of fascia on A.B.S. Load Relay ..	105
C2094 (4-B)	behind LH side of fascia on A.B.S. Pump Relay ..	106
C2095 (9-B) (With Immobilisation)	behind centre of fascia on Engine Immobilisation Control Unit (Spider)	119
C2095 (9-B) (Without Immobilisation)	behind centre of fascia above heater evaporator unit ..	119
C2096 (2-B)	top of steering column to Passive Immobilisation Coil ..	153
C2097 (4-W)	behind RH side of fascia near steering column ..	137
C2098 (5-G)	centre of fascia on Front Fog Lamps Switch ..	116
C2100 (2-W)	behind LH footwell trim panel ..	92
C2101 (13-W)	behind LH footwell trim panel ..	92
C2102 (2-W)	behind LH footwell trim panel ..	92
C2103 (2-W)	behind RH footwell trim panel ..	166
C2104 (13-W)	behind RH footwell trim panel ..	166
C2105 (2-W)	behind RH footwell trim panel ..	166
C2107 (5-W)	behind RH footwell trim panel on Cruise Control Disable Relay ..	177
C2108 (4-B) (Early Production)	behind LH side of fascia Data Link Connector (Theft Alarm) ..	101
C2109 (5-Y)	behind LH footwell trim panel on Dim/Dip Relay 2 ..	94
C2110 (2-S)	LH A-post to Left Front Tweeter ..	179
C300 (4-B)	centre of roof to Rear Interior Roof Lamp ..	197
C301 (6-W)	beneath centre console ..	127
C306 (3-W)	beneath centre console ..	127
C316 (6-B)	RH side of centre console on Right Front Seat Control Switch ..	130
C317 (6-B)	RH side of centre console on Right Front Seat Control Switch ..	130
C318 (9-R)	beneath RH front seat ..	195
C319 (6-B)	LH side of centre console on Left Front Seat Control Switch ..	129
C320 (6-B)	LH side of centre console on Left Front Seat Control Switch ..	129
C321 (9-U)	beneath LH front seat ..	191
C323 (5-B)	LH side of transmission to Park/Neutral Position Switch ..	85
C334 (3-B)	front centre of roof to Electrochromic Rear View Mirror ..	133
C335 (4-B)	front centre of roof on Alarm Sensor ..	131
C337 (7-W)	in rear of centre console on Left Front Window Switch ..	124


Connector	Location	View
C338 (7-G)	in rear of centre console on Right Front Window Switch	124
C339 (7-Y)	in rear of centre console on Left Rear Window Console Switch	125
C340 (7-R)	in rear of centre console on Right Rear Window Console Switch	125
C343 (7-N)	in rear of centre console on Rear Window Isolation Switch	125
C344 (6-B)	beneath centre console to Transmission Range Selector Switch	123
C346 (2-U)	beneath centre console to Automatic Gear Selector Illumination	123
C348 (5-Y)	beneath LH front seat on Left Seat Power Relay	190
C350 (3-W)	front centre of roof on Front Interior Roof Lamp	131
C351 (2-B)	RH front of roof to Right Vanity Mirror Lamp	180
C352 (2-B)	LH front of roof to Left Vanity Mirror Lamp	180
C353 (2-W)	beneath centre console on Fascia Cigar Lighter	122
C354 (29-R)	beneath centre console on Air Bag Diagnostic Control Module	126
C356 (1-B)	beneath centre console on Fascia Cigar Lighter	122
C358 (5-Y)	beneath LH front seat on Right Seat Power Relay	191
C368 (3-B)	top RH side of transfer box to Transfer Box Position Switch	91
C369 (2-B)	top RH side of transfer box to Transfer Box Solenoid	91
C370 (3-B)	LH side of transfer box on Vehicle Speed Sensor	89
C371 (2-B)	LH side of transfer box on Transfer Box Oil Temperature Switch	88
C372 (2-B)	on top of transmission	86
C378 (2-B)	beneath centre console to Driver's Seat Buckle Switch	122
C381 (3-W)	beneath RH front seat on CD Changer	194
C382 (8-W)	front centre of roof on Sunroof Control Unit	134
C383 (10-W)	front centre of roof on Sunroof Control Unit	134
C384 (7-G)	front centre of roof on Front Sunroof Switch	132
C385 (7-W)	front centre of roof on Rear Sunroof Switch	132
C386 (5-S)	front centre of roof on Rear Sunroof Lockout Switch	133
C387 (4-W)	front centre of roof to Front Sunroof Motor	134
C388 (4-W)	centre of roof to Rear Sunroof Motor	199
C389 (3-W)	centre of roof on Passenger's Rear Sunroof Switch	198
C391 (5-W)	centre of roof on Passenger's Rear Fan Speed Switch	196
C392 (5-U)	centre of roof on Passenger's Rear A/C Switch	196
C3000 (1-B)	on top of transmission to Reverse Switch	86
C3001 (1-B)	on top of transmission to Reverse Switch	86
C3003 (6-W)	beneath centre console on E303	128
C3004 (3-W)	in lower part of LH B-post	186
C3005 (2-W)	in lower part of LH B-post	186
C3006 (3-W)	in lower part of RH B-post	186
C3007 (2-W)	in lower part of RH B-post	186
C400 (7-B)	RH rear of luggage compartment Trailer Auxiliary Socket	225
C402 (1-B)	LH side of tailgate to Number Plate Lamps	215
C403 (6-W)	LH rear of luggage compartment on Left Rear Lamp Assembly	204
C404 (1-B)	LH side of tailgate to Number Plate Lamps	215
C406 (6-W)	RH rear of luggage compartment on Right Rear Lamp Assembly	209
C407 (6-B)	beneath LH rear of vehicle	217
C408 (3-B)	RH side of tailgate on Rear Wiper Motor	213
C412 (6-W)	LH side of tailgate on Subwoofer Amplifier	216

Connector	Location	View
C413 (4-W)	LH side of tailgate on Subwoofer Amplifier	216
C414 (2-W)	LH side of tailgate to Tailgate Lock Actuator	214
C415 (8-W)	in RH side of tailgate door jamb	211
C424 (1-B)	RH rear of luggage compartment Trailer Auxiliary Socket	210
C425 (1-B)	RH rear of luggage compartment Trailer Auxiliary Socket	210
C434 (4-B)	top of fuel tank to Fuel Pump Module	221
C437 (6-W)	in RH side of tailgate door jamb	211
C438 (2-W)	in RH side of tailgate door jamb	211
C441 (2-R)	behind LH side of rear bumper on Left Tail Lamp	222
C442 (2-B)	behind LH side of rear bumper on Left Rear Indicator Lamp	222
C443 (2-B)	behind LH side of rear bumper on Left Rear Side Marker Lamp	223
C444 (2-R)	behind RH side of rear bumper on Right Tail Lamp	224
C445 (2-B)	behind RH side of rear bumper on Right Rear Indicator Lamp	224
C446 (2-B)	behind RH side of rear bumper on Right Rear Side Marker Lamp	223
C447 (2-W)	LH rear of luggage compartment	205
C448 (16-W)	LH rear of luggage compartment	205
C453 (1-B)	LH side of tailgate	215
C454 (1-B)	RH side of tailgate to Rear Screen	212
C455 (1-B)	RH side of tailgate	212
C456 (1-B)	LH side of tailgate	215
C457 (5-W)	LH side of luggage compartment on Rear Blower Motor Relay	203
C458 (2-B)	LH side of luggage compartment on Rear Blower Motor	200
C459 (4-B)	LH side of luggage compartment on Rear Blower Resistor Unit	
C462 (2-B)	LH rear of luggage compartment on Rear A/C Switch Amplifier In-Line Fuse	204
C463 (4-W)	LH side of luggage compartment on Rear A/C Control Relay	201
	LH side of luggage compartment on Rear A/C Refrigerant Control Valve	201
C464 (2-S)		201
C465 (4-W)	LH side of luggage compartment on Rear A/C Illumination Relay	202
C466 (4-W)	LH side of luggage compartment on Rear A/C Fan Speed Relay	203
C467 (6-W)	LH side of luggage compartment on Rear A/C Switch Amplifier	200
C485 (2-W)	beneath RH rear of vehicle to Left Rear Wheel Speed Sensor	219
C486 (2-W)	beneath LH rear of vehicle to Right Rear Wheel Speed Sensor	218
C487 (6-W)	RH rear of luggage compartment on E401	208
C489 (2-)	RH side of tailgate on Rear Wiper Motor	213
C500 (2-B)	in front of LH front door to Left Front Window Motor	183
C503 (6-W)	top front of LH front door to Left Mirror Actuator	181
C507 (2-W) (Except Japan) (Without Theft Alarm)	in rear of LH front door to Left Front Door Lock Actuator	182
C507 (4-W) (Japan)	in rear of LH front door to Left Front Door Lock Actuator	182
C507 (6-W) (Except Japan) (With Theft Alarm)	in rear of LH front door to Left Front Door Lock Actuator	182
C600 (2-B)	in front of RH front door to Right Front Window Motor	183
C603 (6-W)	top front of RH front door to Right Mirror Actuator	181
C604 (4-W)	in top rear of RH front door to Right Front Door Key Switch	185
C607 (4-W) (Japan)	in rear of RH front door to Right Front Door Lock Actuator	184


Connector	Location	View
C607 (4-W) (Except Japan) (Without Theft Alarm)	in rear of RH front door to Right Front Door Lock Actuator	184
C607 (6-W) (Except Japan) (With Theft Alarm)	in rear of RH front door to Right Front Door Lock Actuator	184
C703 (2-B)	inside front of LH rear door to Left Rear Window Motor	189
C706 (2-W)	inside front of LH rear door to Left Rear Door Lock Actuator	187
C709 (5-W)	inside front of LH rear door on Left Rear Window Door Switch	188
C803 (2-B)	inside front of RH rear door to Right Rear Window Motor	189
C806 (2-W)	inside front of RH rear door to Right Rear Door Lock Actuator	187
C809 (5-W)	inside front of RH rear door on Right Rear Window Door Switch	188
Ground	Location	View
E100 (300Tdi)	RH front of engine compartment behind battery	42
E100 (MFI – V8) (MFI – T16)	RH front of engine compartment behind battery	41
E101 (300Tdi)	LH front of engine compartment on fender well	24
E101 (MFI – V8) (MFI – T16)	LH front of engine compartment on fender well	23
E103 (MFI – V8)	LH rear corner of engine below valve cover	6
E104	lower LH rear of engine compartment on frame rail	
E105	LH front of engine compartment on Ignition Coil	29
E106	lower LH side of engine	16
E108	near Starter	
E109	lower RH side of engine compartment on frame rail	38
E110	RH side of bulkhead	80
E200	behind RH footwell trim panel	167
E201	behind LH footwell trim panel	92
E203	behind LH side of fascia	98
E204	behind LH footwell trim panel	92
E301	beneath LH front seat	190
E303	beneath centre console	128
E400	LH rear of luggage compartment	208
E401	RH rear of luggage compartment	208
E404	beneath RH rear of vehicle near fuel filler pipe	220
Splice	Location	View
HJ1 (20-S)	behind RH side of fascia near C2035	158
HJ2 (20-U)	behind LH side of fascia	110
HJ3 (20-S)	behind LH side of fascia	111
HJ4 (20-S)	behind LH side of fascia	111
HJ5 (20-S)	behind LH side of fascia	110
HJ6 (20-G)	behind LH side of fascia	111
HJ7 (20-U)	behind RH side of fascia near Engine Control Module (ECM)	140
HJ8 (20-S)	behind instrument cluster	156
HJ9 (20-S)	behind instrument cluster	155
HJ10 (20-S)	behind RH footwell trim panel	166
HJ11 (20-S)	behind LH side of fascia	110
HJ12 (20-G)	LH rear of roof behind trim panel	207




1. LH rear corner of engine compartment
X135 Inertia Fuel Shut-Off Switch
C105 (13-B)
C171 (3-B)




2. LH rear corner of engine compartment
M105 Front Screen Wash Pump
M110 Headlamp Wash Pump
M119 Rear Screen Wash Pump
C120 (2-W)
C170 (2-R)
C173 (2-B)



3. LH rear of engine compartment
K175 Dim/Dip Resistor
C177 (2-B)




4. LH rear of engine compartment
M102 A.B.S. Hydraulic Pump
Z103 A.B.S. Booster Unit
C125 (2-B)
C129 (13-B)
C130 (2-WB)



5. LH rear of engine (MFI-V8)


K141 Fuel Injectors

C140 (2-B)



6. LH rear of engine (MFI-V8)

E103




7. lower LH side of engine (300Tdi without EDC)

K136 Starter Solenoid

M134 Starter

X218 EGR Valve Position Sensor


C164 (3-B)



8. lower LH side of engine (300Tdi with EDC)

K136 Starter Solenoid


M134 Starter



9. lower LH side of engine (MFI-T16)

X139 Left Heated Oxygen Sensor


C112 (4-B)



10. LH side of engine compartment (MFI-V8)

X105 Mass Air Flow Sensor

C133 (6-B)




11. (LH side of engine compartment) (300Tdi with EDC)

X105 Mass Air Flow Sensor

X253 Boost Pressure Sensor

C133 (5-B)

C1001 (3-B)




12. top LH side of engine (MFI-V8)

K141 Fuel Injectors

C134 (2-B)

C136 (2-B)

C138 (2-B)



13. top LH front of engine (MFI-V8)


X114 Engine Coolant Temperature Gauge Sensor

X126 Engine Coolant Temperature Sensor

X128 Engine Fuel Temperature Sensor

C150 (2-S)


C152 (2-N)



14. top LH front of engine (MFI-V8)

X171 Throttle Position Sensor

C149 (3-B)




15. top LH front of engine (MFI-T16)

X114 Engine Coolant Temperature Gauge Sensor


X126 Engine Coolant Temperature Sensor

C152 (2-N)



16. LH front of engine (MFI-V8)

E106




17. lower LH side of engine (300Tdi)

K184 Phase Tap Resistor

Z106 Generator


Z182 Generator Suppression Capacitor



18. top centre front of engine (MFI-V8)

Z125 Distributor

C148 (2-B)



19. top centre front of engine (MFI-T16)

K141 Fuel Injectors

C134 (2-B)

C135 (2-B)

C136 (2-B)


C137 (2-B)




20. top centre front of engine (300Tdi without EDC)

X126 Engine Coolant Temperature Sensor


C152 (2-N)




21. top centre front of engine (300Tdi with EDC)
X126 Engine Coolant Temperature Sensor
X254 Boost Pressure Air Temperature Sensor
C152 (2-N)
C1000 (2-G)




22. LH front corner of engine compartment ((MFI-V8 shown; others similar))
M103 Cruise Control Vacuum Pump
C167 (3-W)



23. LH front of engine compartment (MFI-V8)
(MFI-T16)
E101



24. LH front of engine compartment (300Tdi)
K171 EGR Control Solenoid
C165 (2-B) (300Tdi without EDC)
C165 (2-S) (300Tdi with EDC)
E101



25. lower LH front of engine compartment (MFI-V8 shown; others similar)

X108 Automatic Transmission Oil Temperature Switch

C166 (2-B)




26. LH front side of vehicle (RH similar)

B122 Left Repeater Lamp

B137 Right Repeater Lamp

C123 (2-B) (Right)

C124 (2-B) (Left)




27. LH front of vehicle (RH similar)

B153 Left Front Indicator Lamp

B154 Right Front Indicator Lamp

C1009 (2-B) (Left)

C1010 (2-B) (Right)




28. LH front of engine compartment (RH similar)

Z145 Left Headlamp Level Unit

Z155 Right Headlamp Level Unit

C190 (3-B) (Left)

C191 (3-B) (Right)




29. LH front of engine compartment (MFI-V8)

K115 Multiport Fuel Injection Ignition Resistor 1

K168 Multiport Fuel Injection Ignition Resistor 2

Z140 Ignition Coil

E105



30. LH front of engine compartment (MFI-V8)


C153 (1-B)

C154 (1-W)

C155 (1-B)

C156 (1-W)

C1018 (1-W)




31. LH front of engine compartment (MFI-V8)

Z139 Ignition Control Module

Z237 Ignition Coil Noise Suppressor

C1035 (3-B)


C1036 (3-B)



32. front of engine compartment (MFI-T16 without Air Conditioning)

M141 Cooling Fan Motor 1

C1011 (2-W)




33. LH front of vehicle (RH similar)

K128 Left Horn

K134 Right Horn

C168 (2-B) (Left)


C169 (2-B) (Right)



34. behind front grille

M113 Left Condenser Fan Motor


C183 (2-B)



35. behind front grille

M121 Right Condenser Fan Motor

C182 (2-B)



36. RH front of vehicle (LH similar)

B116 Left Headlamp


B130 Right Headlamp

C103 (3-B) (Right)

C104 (3-B) (Left)

C1024 (2-B) (Left)

C1025 (2-B) (Right)




37. RH front of vehicle (LH similar)

B166 Left Front Side Lamp

B167 Right Front Side Lamp


C109 (2-B) (Left)

C110 (2-B) (Right)



38. lower RH front of engine compartment behind
RH front wheel

E109



39. lower RH side of engine (MFI-V8)


X149 Oil Pressure Switch



40. lower RH side of engine (MFI-T16)


X149 Oil Pressure Switch

C142 (2-N)



41. RH front of engine compartment (MFI-V8)
(MFI-T16)


P125 Engine Compartment Fuse Box
E100



42. RH front of engine compartment (300Tdi)


P119 Fusible Link

P125 Engine Compartment Fuse Box
E100



43. RH front of engine compartment (MFI-V8)
(MFI-T16)

X212 Alarm Bonnet Switch
Z171 Alarm Sounder
C178 (2-B)




44. RH front of engine compartment (300Tdi)

X212 Alarm Bonnet Switch

Z171 Alarm Sounder


C178 (2-B)



45. RH front of engine compartment (300Tdi)

Z135 Glow Plug Timer Unit

C159 (6-B)



46. RH front of engine compartment

C100 (3-W)

C101 (4-W)

C114 (2-W)

C115 (3-W)


C116 (1-W)



47. RH side of engine compartment

Z272 Battery Backed Up Alarm Sounder


C1031 (4-N)



48. RH side of engine (MFI-V8)

K107 Compressor Clutch

C145 (2-W)




49. RH front of engine (MFI-T16)

M112 Idle Air Control Valve

X171 Throttle Position Sensor

C132 (6-B)

C149 (3-B)




50. RH side of engine (MFI-T16)

X128 Engine Fuel Temperature Sensor

X249 Knock Sensor

C150 (2-S)

C1005 (2-W)




51. RH front of engine (300Tdi with EDC)

X113 Condenser Fan Coolant Temperature Switch

X114 Engine Coolant Temperature Gauge Sensor

C146 (2-B)




52. RH front of engine (300Tdi without EDC)


X114 Engine Coolant Temperature Gauge Sensor

X259 Compressor Clutch Cut-out Switch


C162 (2-B)




53. RH front of engine (300Tdi without EDC)
X113 Condenser Fan Coolant Temperature Switch
C146 (2-B)




54. RH side of engine (300Tdi without EGR)
K111 Fuel Shut-Off Solenoid
X149 Oil Pressure Switch
C161 (1-W)



55. RH side of engine (300Tdi with EGR)
K111 Fuel Shut-Off Solenoid
X149 Oil Pressure Switch
X171 Throttle Position Sensor




56. RH side of engine (300Tdi without EDC)
K107 Compressor Clutch
C145 (2-W)



57. RH side of engine (300Tdi with EDC)


K107 Compressor Clutch

C145 (2-W)



58. RH side of engine (300Tdi)

P120 Glow Plugs




59. RH side of engine (300Tdi with EDC)

K196 Fuel Pump Assembly

X149 Oil Pressure Switch


C199 (8-W)



60. RH side of engine (300Tdi with EDC)

K195 Fuel Injector Assembly

C198 (3-W)




61. RH side of engine (MFI-V8)

K141 Fuel Injectors

C135 (2-B)

C137 (2-B)


C139 (2-B)



62. RH front of engine (MFI-V8)

X113 Condenser Fan Coolant Temperature Switch

C146 (2-B)




63. RH front of engine (MFI-V8)

K184 Phase Tap Resistor

Z106 Generator

Z182 Generator Suppression Capacitor



64. RH side of engine (MFI-V8)


K141 Fuel Injectors

M112 Idle Air Control Valve

C113 (3-W)

C132 (4-B)

C141(2-B)




65. RH side of engine (MFI-T16 without Air Conditioning)

K184 Phase Tap Resistor


Z106 Generator

Z182 Generator Suppression Capacitor



66. RH side of engine (300Tdi with EGR)

C160 (3-B)




67. RH side of engine compartment

C131 (2-WB)



68. RH rear corner of engine compartment
(MFI-T16)

C198 (6-B)




69. RH rear of engine (300Tdi with EDC)

X255 Engine Speed Sensor

X256 Injector Needle Lift Sensor

C196 (2-NU)


C197 (3-B)



70. lower RH side of engine (MFI-V8)

K136 Starter Solenoid


M134 Starter



71. lower RH side of engine (MFI-T16)

K136 Starter Solenoid


M134 Starter



72. lower RH side of engine (MFI-T16)


X250 Crankshaft Position Sensor

C1004 (2-U)



73. lower RH side of engine (MFI-V8)


X160 Right Heated Oxygen Sensor



74. RH side of engine compartment (MFI-V8)

K132 Evaporative Emission Canister Purge Valve

C144 (2-B)




75. RH rear corner of engine compartment (MFI-T16)

K132 Evaporative Emission Canister Purge Valve

X321 Data Link Connector (MFI)

C144 (2-B)

C1006 (3-W)




76. RH rear corner of engine compartment (MFI-T16)

Z132 Engine Control Module (ECM)

C1007 (36-B)


C1008 (18-B)



77. RH rear of engine compartment


X102 A/C Dual Pressure Switch

C181 (2-S)



78. RH rear of engine compartment


C195 (4-W)



79. RH rear of engine compartment

X111 Brake Fluid Level Switch


C127 (3-B)



80. RH rear of engine compartment

M107 Front Wiper Motor


E110



81. lower LH rear of engine compartment (MFI-V8)

X139 Left Heated Oxygen Sensor


C112 (3-W)



82. behind LH front wheel on handbrake lever (RH front wheel similar)

X137 Left Front Wheel Speed Sensor


X158 Right Front Wheel Speed Sensor



83. behind LH rear wheel (RH rear wheel similar)

X140 Left Rear Wheel Speed Sensor


X161 Right Rear Wheel Speed Sensor



84. beneath centre of vehicle

X299 Catalyst Overheat Sensor 1


X300 Catalyst Overheat Sensor 2



85. LH side of transmission

X167 Park/Neutral Position Switch

C323 (5-B)




86. LH side of transmission

C372 (2-B)


C3000 (1-B)

C3001 (1-B)



87. LH side of transmission


X157 Reverse Switch




88. LH side of transfer box

X174 Transfer Box Oil Temperature Switch


C371 (2-B)




89. LH side of transfer box
X190 Vehicle Speed Sensor
C370 (3-B)




90. top RH side of transfer box
X238 Differential Lock Switch



91. top RH side of transfer box
K161 Transfer Box Solenoid
X175 Transfer Box Position Switch
C368 (3-B)
C369 (2-B)



92. behind LH footwell trim panel
C2029 (6-W)
C2100 (2-W)
C2101 (13-W)
C2102 (2-W)
E201
E204



93. behind LH footwell trim panel


K174 Accessory Relay

K189 Horn Relay

C282 (5-Y)

C283 (5-Y)

51115082



94. behind LH footwell trim panel

K160 Sounder Relay

K183 Rear Wiper Relay


K236 Dim/Dip Relay 2

C280 (5-W)

C281 (5-G)

C2109 (5-Y)

51126025




95. behind LH side of fascia

Z274 Catalyst Warning ECU

C286 (4-W)

C2065 (2-W)

51126027




96. behind LH side of fascia

Z274 Catalyst Warning ECU

C285 (4-W)

C2064 (2-W)

51126028




97. behind LH side of fascia

C212 (14-W)

C277 (23-W)

C2082 (6-W)




98. behind LH side of fascia

Z108 Anti-Lock Brake System ECU

C2084 (35-B)


E203



99. behind LH side of fascia

Z121 Cruise Control ECU


C284 (15-B)




100. behind LH side of fascia

K123 Air Recirculation Solenoid


C2072 (4-Y)




101. behind LH side of fascia
X323 Data Link Connector (Theft Alarm)
Z147 Window Lift ECU
C287 (10-W)
C288 (8-W)
C2108 (4-B) (Early Production)




102. behind LH side of fascia
Z113 Central Locking Control Unit (Japan)
Z163 Theft Alarm Unit (Except Japan)
C225 (26-S)
C274 (12-W)



103. behind LH side of fascia
K109 Condenser Fan Relay
K182 Power Wash Relay
C292 (5-Y)
C2074 (5-Y)




104. behind LH side of fascia
K230 Front Fog Lamps Relay
K231 Rear Fog Lamps Relay
K235 Dim/Dip Relay 1
C293 (5-U)
C2090 (5-Y)
C2091 (5-G)




105. behind LH side of fascia

K101 A.B.S. Load Relay
K103 A.B.S. Warning Relay
C2092 (5-G)
C2093 (5-Y)




106. behind LH side of fascia

K102 A.B.S. Pump Relay
Z186 Cruise Control Diode
C2094 (4-B)




107. behind LH side of fascia

K110 Cruise Control Lockout Relay (Automatic Transmission)
Z164 Speed Trip Module (Manual Transmission)
C218 (8-W)
C2021 (5-G) (Automatic Transmission)
C2021 (5-B) (Manual Transmission)



108. behind LH side of fascia

K192 Front Blower Motor Relay
P138 Air Recirculation Solenoid In-Line Fuse
C2068 (5-W)
C2071 (2-B)




109. behind LH side of fascia

M101 Front Blower Motor

C298 (3-W)

C2069 (2-B)



110. behind LH side of fascia


Z211 Fan Timer Diode

Z273 Neutral Sense Diode

HJ2 (20-U)

HJ5 (20-S)

HJ11 (20-S)




111. behind LH side of fascia

C2066 (8-W)

HJ3 (20-S)

HJ4 (20-S)


HJ6 (20-G)




112. behind LH side of fascia

C2027 (5-W)

C2067 (10-W)



113. behind LH side of fascia
Z208 Air Supply Selector Diode
Z214 Front Blower Resistor Unit
C2070 (4-B)




114. LH side of heater evaporator unit
X101 Front A/C Evaporator Temperature Switch



115. centre of fascia
X220 Hazard Switch
Z117 Clock
C267 (10-W)
C270 (4-B)



116. centre of fascia
X115 Cruise Control Switch
X270 Front Fog Lamps Switch
C262 (5-U)
C2098 (5-G)



117. centre of fascia (Low Line Radio) (Mid Line Radio)

Z111 Radio


C230 (8-S)

C260 (10-R)

C268 (8-N)

C2060 (5-W)

C2079 (2-B)



118. centre of fascia (High Line Radio)

Z111 Radio

C230 (8-S)

C268 (8-N)

C2061 (7-B)

C2079 (2-B)


C2080 DIN CABLE



119. behind centre of fascia

Z271 Engine Immobilisation Control Unit (Spider)

C2095 (9-B)



120. behind heater and A/C control panel


X247 Front Fan Speed Switch

X225 Front A/C Switch

C2022 (5-W)

C2023 (4-W)

C2025 (5-W)




121. behind heater and A/C control panel

X180 Air Supply Selector Switch

X239 Main Rear A/C Switch

C2024 (5-U)

C2026 (5-B)




122. beneath centre console

B106 Fascia Cigar Lighter

C353 (2-W)

C356 (1-B)

C378 (2-B)




123. beneath centre console

Z110 Transmission Range Selector Switch

C344 (6-B)

C346 (2-U)




124. in rear of centre console

X122 Left Front Window Switch


X151 Right Front Window Switch

C337 (7-W)


C338 (7-G)




125. in rear of centre console
 X141 Left Rear Window Console Switch
 X162 Right Rear Window Console Switch
 X187 Rear Window Isolation Switch
 C339 (7-Y)
 C340 (7-R)
 C343 (7-N)




126. beneath centre console
 Z151 Air Bag Diagnostic Control Module
 C354 (29-R)




127. beneath centre console
 C301 (6-W)
 C306 (3-W)




128. beneath centre console
 X191 Handbrake Switch
 C3003 (6-W)
 E303




129. LH side of centre console
X152 Left Front Seat Control Switch
C319 (6-B)
C320 (6-B)




130. RH side of centre console
X121 Right Front Seat Control Switch
C316 (6-B)
C317 (6-B)



131. front centre of roof
B107 Front Interior Roof Lamp
X213 Alarm Sensor
C335 (4-B)
C350 (3-W)



132. front centre of roof
X261 Front Sunroof Switch
X262 Rear Sunroof Switch
C384 (7-G)
C385 (7-W)




133. front centre of roof

B110 Electrochromic Rear View Mirror

X263 Rear Sunroof Lockout Switch

C334 (3-B)

C386 (5-S)



134. front centre of roof

Z162 Sunroof Control Unit

M143 Front Sunroof Motor

C382 (8-W)

C383 (10-W)


C387 (4-W)



135. behind RH side of fascia left of steering column

X318 Data Link Connector (OBDII)

C2083 (16-S)



136. behind RH side of fascia left of steering column

C209 (20-R)

C215 (24-Y)

C252 (6-R)

C2055 (13-W)



137. behind RH side of fascia left of steering column


Z210 Condenser Fan Control Diode 2

C2097 (4-W)



138. behind RH side of fascia left of steering column

C224 (6-W)




139. behind RH side of fascia right of heater evaporator unit

Z210 Condenser Fan Control Diode 2

C216 (7-N)

C217 (24-W)

C2073 (10-W)




140. behind RH side of fascia

K140 Tune Select Resistor


C246 (2-U)

HJ7 (20-U)



141. behind RH side of fascia right of steering column

X257 Throttle Position Sensor




142. in steering wheel

X258 Horn Switches

X266 Steering Wheel Cruise Switches

C2036 (7-BW)




143. underside of steering column

X116 Direction Indicator Switch

X145 Main Lighting Switch

C201 (7-W)

C2009 (4-W)




144. underside of steering column

X134 Ignition Switch

X229 Key-In Switch

Z119 Rotary Coupler

C2010 (6-W)




145. underside of steering column

X229 Key-In Switch

X230 Key-Barrel Switch


C2012 (8-W)



146. underside of steering column

K191 Ignition Key Lock Solenoid

C2014 (2-B)




147. top RH side of fascia

X132 Heated Rear Screen Switch

X154 Rear Fog Guard Lamps Switch

C263 (5-B)

C264 (5-U)




148. top RH side of fascia

X235 Radio Volume Up Switch


X236 Radio Volume Down Switch

C2058 (5-W)


C2059 (5-G)




149. top RH side of fascia
X146a Mirror Adjustment Switch
X221 Rear Screen Wipe Switch
X222 Rear Screen Wash Switch
C228 (8-B)
C249 (5-G)
C250 (5-W)




150. top RH side of fascia
X233 Radio Tune Switch
X234 Radio Waveband Switch
C2056 (5-B)
C2057 (5-U)



151. top of steering column
B104 Column Switch Illumination
C2013 (4-B)




152. top of steering column
X124 Front Wipe/Wash Switch
C2011 (6-W)
C2015 (8-W)



153. top of steering column

Z270 Passive Immobilisation Coil

C2096 (2-B)



154. behind instrument cluster


Z142 Instrument Cluster

C207 (10-B)

C222 (10-W)

C223 (5-U)

C255 (1-B)




155. behind instrument cluster

Z213 Direction Indicator Diode 2

Z234 Radio Volume Resistor

HJ9 (20-S)



156. behind instrument cluster


Z212 Direction Indicator Diode 1

Z235 Radio Tune Resistor


Z236 Radio Waveband Resistor

C221 (10-W)


HJ8 (20-S)




157. behind RH side of fascia
X200 Clutch Pedal Position Switch
C2035 (2-W)




158. behind RH side of fascia
X112 Brake Switch Vent Valve
C220 (3-N)
C2005 (2-W)
HJ1 (20-S)



159. behind RH side of fascia
X168 Stop Lamp Switch
Z206 Stop Lamp Switch Suppressor
C227 (4-B)
C2063 (2-B)




160. behind RH side of fascia right of steering column
P126 Fascia Fuse Box
P127 Satellite Fuse Box 1
P128 Satellite Fuse Box 2




161. behind RH side of fascia right of steering column

K122 Heated Rear Screen Relay
Z128 Flasher Unit
C259 (6-W)




162. behind RH side of fascia right of steering column

C208 (18-W)
C219 (4-W)
C254 (1-W)
C2016 (1-W)




163. behind RH side of fascia rear of Fascia Fuse Box

Z148 Multi-Function Unit (MFU)
C203 (7-W)
C205 (24-B)
C229 (1-W)



164. behind RH side of fascia rear of Fascia Fuse Box

C204 (24-W)
C211 (10-W)




165. behind RH side of fascia rear of Fascia Fuse Box

X241 Saudi Junction Connector

C206 (4-W)

C226 (3-W)

C2062 (1-B)




166. behind RH footwell trim panel

C2103 (2-W)

C2104 (13-W)

C2105 (2-W)

HJ10 (20-S)




167. behind RH footwell trim panel

K185 Front Wiper Relay

C2008 (5-G)

C2028 (6-W)

E200




168. behind RH footwell trim panel

K127 Ignition Load Relay

K137 Starter Solenoid Relay


C2006 (5-Y)

C2007 (5-Y)




169. behind RH footwell trim panel (MFI-V8)

X321 Data Link Connector (MFI)
 Z132 Engine Control Module (ECM)
 C243 (40-B)
 C245 (5-W)




170. behind RH footwell trim panel (MFI-T16)

Z207 Multi-Function Relay Unit
 C2051 (8-B)
 C2052 (6-B)




171. behind RH footwell trim panel (MFI-T16)

K190 Cooling Fan Relay
 Z158 Starter Relay Diode
 C238 (5-Y)
 C2085 (3-W)



172. behind RH footwell trim panel (300Tdi without EDC)

X219 Data Link Connector (EGR)
 Z149 EGR Valve Control Module
 C247 (16-B)
 C248 (3-W)




173. behind RH footwell trim panel (MFI-V8 shown; others similar)

K116 Engine Control Load Relay

K119 Fuel Pump Relay

C239 (5-B)

C240 (5-U)




174. behind RH footwell trim panel (MFI-V8 shown; others similar)

K108 Compressor Clutch Relay

Z118 Fan Control Module

C238 (9-B)


C241 (5-Y)



175. behind RH footwell trim panel ((MFI-V8 shown; others similar))

K170 A/C Logic Relay

C242 (5-Y)




176. behind RH footwell trim panel (300Tdi with EDC)

K116 Engine Control Load Relay

Z132 Engine Control Module (ECM)

C239 (5-Y)

C243 (55-B)




177. behind RH footwell trim panel (300Tdi with EDC)

K108 Compressor Clutch Relay

K234 Cruise Control Disable Relay

C241 (5-Y)


C2107 (5-W)



178. front of RH front door jamb (LH similar)

X118 Right Front Door Switch


X150 Left Front Door Switch



179. RH A-post (LH similar)

C232 (2-S) (Right)

C2110 (2-S) (Left)




180. RH front of roof (LH similar)

B186 Left Vanity Mirror Lamp

B187 Right Vanity Mirror Lamp

C351 (2-B) (Right)

C352 (2-B) (Left)




181. top front of LH front door (RH similar)

M115 Left Mirror Actuator

M123 Right Mirror Actuator

C503 (6-W) (Left)

C603 (6-W) (Right)




182. in rear of LH front door

M114 Left Front Door Lock Actuator

C507 (2-W) (Except Japan) (Without Theft Alarm)

C507 (4-W) (Japan)

C507 (6-W) (Except Japan) (With Theft Alarm)




183. in front of LH front door (RH similar)

M130 Left Front Window Motor

M133 Right Front Window Motor

C500 (2-B) (Left)

C600 (2-B) (Right)




184. in rear of RH front door (LH similar)

M122 Right Front Door Lock Actuator

C607 (4-W) (Except Japan) (Without Theft Alarm)
(Japan)


C607 (6-W) (Except Japan) (With Theft Alarm)



185. in rear of RH front door (LH similar)

X202 Right Front Door Key Switch

C604 (4-W)



186. in lower part of LH B-post (RH similar)

X142 Left Rear Door Switch


X163 Right Rear Door Switch

C3004 (3-W) (Left)

C3005 (2-W) (Left)

C3006 (3-W) (Right)

C3007 (2-W) (Right)




187. inside front of LH rear door (RH similar)

M117 Left Rear Door Lock Actuator

M125 Right Rear Door Lock Actuator

C706 (2-W) (Left)

C806 (2-W) (Right)




188. inside front of LH rear door (RH similar)

X188 Left Rear Window Door Switch

X189 Right Rear Window Door Switch

C709 (5-W) (Left)

C809 (5-W) (Right)




189. inside front of LH rear door (RH similar)

M116 Left Rear Window Motor

M124 Right Rear Window Motor

C703 (2-B) (Left)

C803 (2-B) (Right)




190. beneath LH front seat

K113 Left Seat Power Relay

P116 Passenger's Underseat Fuse Box

C348 (5-Y)

E301




191. beneath LH front seat

K131 Right Seat Power Relay

P108 Driver's Underseat Fuse Box

C321 (9-U)

C358 (5-Y)




192. underside of LH front seat (RH similar)

M127 Seat Height (Front) Motor

M129 Seat Recline Motor

C318 (9-R) (Right)


C321 (9-U) (Left)



193. underside of LH front seat (RH similar)

M126 Seat Base Motor


M128 Seat Height (Rear) Motor



194. beneath RH front seat

X DIN CABLE


C381 (3-W)



195. beneath RH front seat

Z114 CD Changer

C318 (9-R)




196. centre of roof

X240 Passenger's Rear A/C Switch

X246 Passenger's Rear Fan Speed Switch

C391 (5-W)


C392 (5-U)



197. centre of roof

B124 Rear Interior Roof Lamp


C300 (4-B)



198. centre of roof

X264 Passenger's Rear Sunroof Switch


C389 (3-W)



199. centre of roof

M144 Rear Sunroof Motor

C388 (4-W)




200. LH side of luggage compartment behind trim panel

M145 Rear Blower Motor

Z216 Rear A/C Switch Amplifier

C458 (2-B)

C467 (6-W)




201. LH side of luggage compartment behind trim panel

K194 Rear A/C Control Relay

K207 Rear A/C Refrigerant Control Valve

C463 (4-W)

C464 (2-S)




202. LH side of luggage compartment behind trim panel

X260 Rear A/C Evaporator Temperature Switch

K204 Rear A/C Illumination Relay

C465 (4-W)




203. LH side of luggage compartment behind trim panel

K193 Rear Blower Motor Relay

K205 Rear A/C Fan Speed Relay

C457 (5-W)

C466 (4-W)




204. LH rear of luggage compartment behind trim panel

B121 Left Rear Lamp Assembly

P140 Rear A/C Switch Amplifier In-Line Fuse

C403 (6-W)

C462 (2-B)




205. LH rear of luggage compartment behind trim panel

Z228 Rear A/C Refrigerant Control Valve Diode

Z275 Rear A/C Relay Diode


C447 (2-W)

C448 (16-W)




206. LH rear of luggage compartment behind trim panel

E400



207. LH rear of roof behind trim panel


HJ12 (20-G)



208. RH rear of luggage compartment behind trim panel


C487 (6-W)

E401




209. RH rear of luggage compartment behind trim panel

B136 Right Rear Lamp Assembly
C406 (6-W)




210. RH rear of luggage compartment behind trim panel

X172 Trailer Auxiliary Socket
C400 (7-B)
C424 (1-B)
C425 (1-B)




211. in RH side of tailgate door jamb

X265 Rear End Door Switch
C415 (8-W)
C437 (6-W)
C438 (2-W)



212. RH side of tailgate

C454 (1-B)
C455 (1-B)




213. RH side of tailgate

M120 Rear Wiper Motor

C408 (3-B)


C489 (2-)



214. LH side of tailgate

M132 Tailgate Lock Actuator

C414 (2-W)




215. LH side of tailgate

C402 (1-B)

C404 (1-B)

C453 (1-B)

C456 (1-B)




216. LH side of tailgate rear of Subwoofer

K146 Subwoofer


Z176 Subwoofer Amplifier

C412 (6-W)


C413 (4-W)




217. beneath LH rear of vehicle
C407 (6-B)




218. beneath LH rear of vehicle
C486 (2-W)



219. beneath RH rear of vehicle
C485 (2-W)




220. beneath LH rear of vehicle
E404



221. top of fuel tank

Z134 Fuel Pump Module

C434 (4-B)



222. behind LH side of rear bumper

B155 Left Tail Lamp

B163 Left Rear Indicator Lamp

C441 (2-R)

C442 (2-B)




223. behind LH side of rear bumper (RH similar)

B159 Left Rear Side Marker Lamp

B160 Right Rear Side Marker Lamp

C443 (2-B) (Left)

C446 (2-B) (Right)



224. behind RH side of rear bumper

B165 Right Rear Indicator Lamp

B156 Right Tail Lamp


C444 (2-R)

C445 (2-B)




225. centre rear of vehicle
X172 Trailer Auxiliary Socket
C400 (7-B)

R030036

C100


1	NLG
2	PW
3	OK

R030005

C103


1	UO
2	UB
3	B

R040031

C101


1	PN	3	NG
2	-	4	OS

R030005

C104


1	US
2	UK
3	B

R130001

C105

1	BU	6	SB	11	BO/BY
2	BR	7	BK	12	RY
3	GN	8	BG	13	-
4	GY	9	YB		
5	B	10	BY		

R130002



1	BO	6	SB	11	BO
2	BR	7	BK	12	-
3	GN	8	BLG	13	-
4	GY	9	BY		
5	B	10	BY		

C109


R020058



1	RB
2	B

C113

R030039



1	WO
2	B
3	CORE

C110


R020058



1	RO
2	B

C114

R020065




1	NK
2	NW


C112

R030039

R040001




1	WO
2	B
3	CORE




1	UY	3	B
2	UW	4	NU

R030035

C115


1	NP
2	NP
3	NO

R020061

C124


1	GR
2	B

R020037

C120


1	B
2	LGS

R020070

C125


1	NR
2	B

R020061

C123


1	GW
2	B

R030037

C127


1	LGK
2	B
3	-

R130002

C129


1	SR	6	B	11	SW
2	SY	7	SU	12	SP
3	-	8	SN	13	B
4	SG	9	B		
5	SK	10	B		

R020007

C131


1	G
2	G

R020007

C130


1	G
2	G

R040019

C132

A	O	C	GW
B	US	D	RG


R060016




1	OS	4	OU
2	NK	5	-
3	KU	6	OG

R060025

R050023

C133


1	-	4	-
2	RB	5	NO
3	UG	6	UR




1	YB	4	B
2	UG	5	-
3	UR		

R020060

R020060

C134

1	YU/NK
2	NO/YU




1	YU/NK
2	NO/YW


C135

R020060

R020060


C137

1	YW/NK
2	NO/YG




1	YW/NK
2	NO/YB

R020060

C138


1	YU
2	NO

R020060

C141


1	YW
2	NO

R020060

C139


1	YW
2	NO

R020060

C142


1	WN
2	-

R020060

C140


1	YU
2	NO

R020045

C144


1	WP/NK
2	SY/RS

R020063

C145


1	BG
2	B

R020037

C148


1	U
2	R

R020058

C146


1	BP
2	B

R030003

C149


1	Y
2	R
3	RB

R030041




1	KP
2	GY
3	KB

R020060

C150


1	RB/YU
2	SW/KB

R030041

C160

1	KB
2	R
3	RB

R020060

C152


1	RB/GU/KB/GU
2	GU/KB/KG/B

R020058

C162


1	YB
2	G

R060023

C159


1	B/WR	4	B
2	BY	5	NO
3	B/WG	6	YB

R030041

C164


1	RB
2	KB
3	RU

R020060

C165

1	B/NO
2	BO/SR

R020037

C168


1	B
2	PG

R020058

C166


1	B
2	BLG

R020037

C169


1	B
2	PG

R030042

C167

81	BY
81a	BR
82a	WU


R020037

C170

1	B
2	LGB

C171


R030003



1	WP
2	-
3	WP

C178


R020037



1	B
2	PO

C173


R020015



1	LGR
2	B

C181


R020064



1	YB
2	ON

C177


R020037



1	NP
2	NO


C182

R020063




1	BN
2	B

R020063

C183


1	BN
2	B

R030002

C191


1	B
2	UY
3	RB

R030002

C190


1	B
2	UY
3	RB

R040032

C195


1	WS	3	WP
2	B	4	WG

R040041




1	S	3	K
2	N	4	W

R020060

C196


1	NB
2	B

R030041


C197

1	Y
2	B
3	B

R060016


C198

1	NK	4	YG
2	YB	5	YU
3	WB	6	-



1	NK	4	YG
2	YB	5	YU
3	YW	6	-


R030034




1	NS
2	NO
3	W

R080021

R030041

C199

1	-	5	B
2	WS	6	GK
3	WP	7	R
4	NO	8	GO


C1002

1	-
2	NK
3	YU


C1000

R020060

R030041

C1003

1	KO/KS
2	KB/B




1	-
2	NK
3	WB


C1001

R030041

R020060


C1004

1	YU
2	YG
3	B




1	WU
2	UP

R020060


C1005

1	KB
2	LGS

C1006


1	KB
2	BO
3	BG

R030038


C1007

1	YU	7	UY	13	BK	19	BS	25	YU	31	UP
2	KU	8	GY	14	B	20	UP	26	YG	32	WU
3	OS	9	KP	15	BG	21	RS	27	OU	33	KG
4	YN	10	BO	16	KO	22	OG	28	NK	34	YU
5	—	11	WG	17	LGS	23	WB	29	B	35	BN
6	BP	12	—	18	UW	24	YB	30	KB	36	U

R180007

C1008


1	—	6	—	11	B	16	—
2	—	7	—	12	—	17	—
3	—	8	—	13	—	18	WB
4	—	9	—	14	—		
5	B	10	—	15	—		

C1009

1	GR
2	B


R020037

R020037

C1010


1	GW
2	B

R020037

C1024


1	UP
2	B

R020063

C1011

1	US/BR
2	B

R020037

C1025


1	UP
2	B

R020063

C1012


1	BR
2	B

R040040

C1031


1	B	3	B
2	B	4	B

R030041

C1035

1	W
2	-
3	W


R070015

C203

1	UR	5	LGW
2	U	6	W
3	R	7	NP
4	W		


C1036

R030003



1	U
2	B
3	R


R240008

C204

1	UB	7	-	13	UK	19	-
2	-	8	G	14	LGP	20	GY
3	GW	9	WR	15	LGN	21	RB
4	RB	10	GO	16	WN	22	LGP
5	GR	11	UO	17	P	23	GS
6	-	12	RO	18	GLG	24	US


C201

R070013



1	U	5	UW
2	UB	6	NP
3	NG	7	PO
4	R		


R240003

C205


1	PU	7	RW	13	LGB	19	-
2	G	8	WLG	14	Y	20	PW
3	-	9	LGG	15	OU	20	WP
4	-	10	BK	16	LGS	22	NS
5	PW	11	B	17	UB	23	NP
6	B	12	WR	18	PG	24	-

R040013

R180008


C206

1	R	3	B
2	OS	4	UW

C208

1	-	6	WN	11	G	16	-
2	-	7	-	12	-	17	GW
3	-	8	-	13	-	18	GR
4	UW	9	B	14	RO		
5	UR	10	BO	15	LG		


R100023

C207


1	-	4	G	6	LGU	8	P
2	BS	5	WS	7	RN	9	LGG
3	UW					10	BLG

R200002

R200011


C209

1	RN	6	BY/WR	11	BP	16	G
2	RS	7	SW	12	WY	17	YK
3	-	8	BU	13	LGO	18	Y
4	RW	9	BK	14	GO	19	-
5	BR	10	BN	15	GLG	20	BS




1	RN	6	PO	11	BP	16	G
2	RS	7	SW	12	WY	17	YK
3	-	8	BU	13	LGO	18	-
4	RW	9	BK	14	GO	19	-
5	BR	10	BN	15	GLG	20	BS

R100020


C211

1	GW	4	-	6	-	8	-
2	RB	5	-	7	RO	9	NP
3	GR					10	-


C214

1	RN
2	RO
3	B

R140008



C212

1	SCR	6	BY	11	NG
2	B	7	BO	12	BU
3	R	8	YU	13	PY
4	PN	9	WG	14	BG
5	BG	10	YO		



1	SCR	6	BY	11	NG
2	B	7	BO	12	BU
3	R	8	W	13	PY
4	PN	9	WG	14	BG
5	BG	10	UW		

R240008


C215

1	PN	7	-	13	KO	19	BLG
2	WS	8	UY	14	OU	20	LGN
3	G	9	PN	15	GU	21	UP/UB
4	BY/UP	10	WR	16	GLG	22	LGK
5	LGP	11	RY	17	LGS	23	UP
6	GB	12	BG	18	BO	24	NY


1	PN	7	-	13	KO	19	BLG
2	WS	8	UY	14	OU	20	LGN
3	G	9	PN	15	GU	21	UP
4	BY	10	WR	16	GY	22	LGK
5	LGP	11	RY	17	LGS	23	UP
6	GB	12	NP	18	BO	24	NY

R070012

R070014

C216



1	NLG/-	5	BR/-/NG
2	B/-/WP	6	BG
3	PW/-	7	WG/B
4	B/NR		



1	NLG	5	BN/NG
2	WP	6	BG
3	PW	7	WG
4	NR		

R240007

R240008



C217

1	GW/-	7	-/GP	13	PY/-/WLG	19	WS
2	PB/-	8	-/LGP	14	-/WK	20	GU
3	WG/-	9	-/BY	15	-/B	21	-/BK/BS
4	NY	10	YB	16	WU/-	22	GLG
5	NG	11	OB/-	17	BP	23	GLG/GY
6	RS/-	12	YK/-	18	WN	24	B/-

1	GW	7	GP	13	KR	19	WG
2	PB,PB	8	-	14	LGR	20	GU
3	WG	9	BY	15	-	21	B
4	NY	10	YB	16	WU	22	GLG
5	NG	11	OB	17	BP	23	GY
6	RS	12	YK	18	WN	24	BK

R080026


R080030

C218

1	WU	5	PY
2	BY	6	P
3	PW	7	B
4	WY	8	-


1	WU/-	5	P/PY
2	-/BY	6	P/-
3	PW/-	7	B/-
4	WY	8	-

R040013

C219


1	-	3	W
2	Y	4	WR

R100022

C222


1	RS	4	-	6	RW	8	GU
2	LG	5	WN	7	-	9	RN
3	KO					10	-

R030016

C220


1	NW
2	LG
3	-

R050025

C223


1	G	4	-
2	-	5	S
3	P		

R100016


C221

1	B	4	YK	6	BO	8	LG
2	BR	5	NY	7	PO	9	WR
3	GB					10	BY


R060028

C224

1	B	4	GS
2	NLG	5	RLG
3	ULG	6	-



R260001

C228

R080022

1	PW	8	UG	15	B	22	-
2	-	9	PO	16	PW	23	-
3	WB	10	GK	17	KB	24	-
4	-	11	RS	18	-	25	P
5	PG	12	-	19	-	26	Y
6	-	13	-	20	BN		
7	YK	14	BK	21	BS		



1	BK	5	BP
2	BN	6	GLG
3	SW	7	BU
4	B	8	-

C226

R030036

C230

R080025



1	LGW
2	WY
3	-



1	-	5	UY
2	B	6	RN
3	U	7	LGO
4	P	8	B

C227

R040038

C232

R020066





1	GP	3	WR
2	GO	4	WS

1	BK
2	BR

R090002

R050001



C238

1	-	4	BR	7	-
2	NO	5	BG	8	GW
3	-	6	B	9	PB

30	NG	87	US
85	BP	87a	-
86	WG		

R050001

R050001

C239



30	NLG	87	NO
85	UR	87a	NO/-
86	NO/NLG		

30	NG	87	BG
85	BS/WG	87a	-/BG
86	WG/G/BS		

C240

R050001


R050001



30	PW	87	B,WP
85	UP	87a	WO,WO
86	WG		


30	WG/BN/NG/YG	87	GY/B/BG/WG
85	WG/YB	87a	-
86	YB/WG/G		

R400001

C243


1	RG	7	GU	13	YU	19	WG	25	RB	31	-	37	-
2	NO	8	PY	14	B	20	R	26	GW	32	SW	38	-
3	Y	9	WLG	15	NO	21	GY	27	BS	33	BS	39	WU
4	B	10	RS	16	UP	22	UR	28	US	34	OB	40	B
5	SB	11	YW	17	SY	23	CORE	29	O	35	UG		
6	YK	12	UR	18	WK	24	CORE	30	-	36	BG		

R550002


C243

1	WP	8	-	15	UR	22	-	29	YK	36	KS	43	-	50	-
2	WP	9	BS	16	NO	23	-	30	-	37	WG	44	YB	51	YU
3	W	10	NS	17	NO	24	-	31	LGP	38	UG	45	BS	52	YB
4	RS	11	-	18	B	25	WS	32	-	39	GK	46	-	53	GU
5	NB	12	B	19	B	26	GP	33	WP	40	-	47	Y	54	YG
6	SR	13	B	20	-	27	WK	34	UR	41	-	48	-	55	WG
7	-	14	R	21	GO	28	OB	35	WS	42	WLG	49	-		

R050013

C245

1	WK	4	WLG
2	-	5	BS
3	-		




1	BS
2	SB


R020069

C246

R160003

C247


R050024

C249


1	KB	25	R	29	B	33	WK
22	-	26	GU	30	-	34	RU
23	-	27	-	31	-	35	RB
24	BO	28	B	32	WLG	36	WS

1	GLG	4	LGS
2	RN	5	B
3	-		

R030038


C248

1	KB
2	WLG
3	WK

C250


1	GLG	4	OU
2	RN	5	B
3	-		

R060017

C252


1	P	4	B
2	LGP	5	G
3	S	6	G

R060016




1	P	4	B
2	LG	5	G
3	S	6	G

R060028

C259


1	B	4	RN
2	UY	5	RO
3	-	6	-

R050024

C263


1	UR/UP	4	RY
2	RN	5	B
3	-		

R100015

C260


1	R	4	B	6	B	8	B
2	B	5	Y	7	U	9	R
3	G					10	B

R050024

C264


1	BO	4	B
2	RN	5	BG
3	-		

R050024

C262

1	GLG	4	WY
2	RN	5	B
3	-		


R100017

C267

1	GO	4	RN	6	LGN	8	LGG
2	PN	5	B	7	GR	9	GW
3	LGP					10	-

C268


R080025



1	NY/BG	5	B/BW
2	U/BU	6	BN
3	UG/BK	7	BY
4	RG/BR	8	BO

C274


R120005



1	GW	5	OB	9	WR
2	O	6	GR	10	BO
3	K	7	SR	11	BO
4	RW	8	PN	12	PK


C270

R040008



1	PN	3	RN
2	B	4	LG


R230004

C277

1	GN	7	K	13	-	19	RB
2	PW	8	O	14	-	20	WB
3	WP	9	GP	15	-	21	BN
4	NG	10	PU	16	RO	22	RY
5	GLG	11	GR	17	GW	23	GB
6	-	12	LGO	18	NP		

C277

R230003





1	GN	7	K	13	-	19	RB
2	PW	8	O	14	-	20	WB
3	WP	9	GP	15	-	21	BN
4	NG	10	PU	16	RO	22	RY
5	GLG	11	GR	17	GW	23	GB
6	-	12	LGO	18	NP		

C280

R050001

C281


R050001



30	P	86	P
85	OB	87	PB
87a	-		


30	NG	86	GLG
85	NP	87	GLG
87a	B		

R050001

C282


30	NW	86	B
85	LG	87	LGW
87a	-		

R040036

C285


1	B	3	GLG
2	BW	4	UW

R050001

C283


30	PN	86	PO
85	PN	87	PG
87a	-		

R040036

C286


1	B	3	GLG
2	BW	4	UW

R150001

C284


1	WU	6	BY	11	YK
2	-	7	BR	12	-
3	RW	8	B	13	-
4	UW	9	PG	14	-
5	GP	10	WY	15	-

R100021

C287


1	BU	4	-	6	-	8	-
2	WG	5	BK	7	BS	9	PG
3	LGP					10	BR

R080027

C288


1	SU	5	PS
2	SK	6	B
3	SR	7	SB
4	WK	8	PN

R050001

C293


30	UR	86	B
85	NP	87	NO
87a	-		

R050001

C292


30	NG	86	BP
85	GW	87	BN
87a	-		

R030043

C298


1	-
2	NK
3	B

R030004




1	-
2	R
3	WB

R050001

C299


30	WR	86	B
85	UW,UW	87	B
87a	-		

R020032

C2005


1	PY
2	PG

R050001

C2000

30	WP	86	WP
85	BK	87	RB
87a	-		


R050001

C2006

30	NW	86	BO
85	WR	87	NR
87a	-		


C2001

R050001




30	WY	86	BR
85	YB	87	SB
87a	-		

R050001

C2007


30	NG	86	B
85	LGP	87	WG
87a	-		

R050001

C2008


30	LGP	86	NS
85	GS	87	GS
87a	NLG		

R060029

C2011


1	-	4	B
2	-	5	-
3	-	6	WLG

R040037

C2009


1	GR	3	-
2	LGN	4	GW

R080023

C2012


1	-	5	BR
2	-	6	WP
3	OW	7	P
4	P	8	PU

R060030

C2010


1	WY	4	RW
2	-	5	PO
3	UW	6	-

R040001

C2013


1	P	3	P
2	PU	4	WP

R020057

C2014


1	OW
2	B

R050006

C2022

1	WB	4	PU
2	BO	5	N
3	G		

R080024

C2015


1	GS	5	GS
2	LGG	6	-
3	ULG	7	LGP
4	RLG	8	LGB

R040004

C2023


1	S	3	WB
2	UR	4	LG

R050001

C2021


30	WS/WU	86	WS
85	BY/B	87	-/PW
87a	PY/-		

R050024

C2024


1	W	4	WB
2	LG	5	UW
3	-		

R050024

C2025


1	N	4	NW
2	LG	5	UR
3	WB		

R050024

C2026


1	WB	4	RG
2	LG	5	UR
3	UB		

R050003

C2027


1	WB	4	G
2	N	5	BO
3	PU		

R050027




1	WB	4	G
2	N	5	BO
3	PU		

R060028

C2028


1	B	4	B
2	B	5	B
3	B	6	B

R060028

C2029

1	B	4	B
2	B	5	B
3	B	6	B

R020032


C2035

1	PW
2	P

R070001


C2036

R070016



7 6 5 4 3 2 1

1	PB	5	YB
2	W	6	PB
3	R	7	PB
4	GR		




1 2 3 4 5 6 7

1	PB	5	YB
2	PB	6	PB
3	-	7	-
4	GR		


R080019

C2051

R060016


C2052

1	NK	5	NU
2	-	6	NLG
3	NK	7	PW
4	WP	8	NK




1	UP	4	U
2	WG	5	-
3	YN	6	-

R050001

C2053


30	NK	86	B
85	LGO	87	LGP
87a	-		

R180006

C2054


1	R	6	BK	11	B	16	BR
2	G	7	BW	12	B	17	BN
3	Y	8	BY	13	R	18	BO
4	U	9	LGP	14	PY		
5	BG	10	B	15	BU		

R130009

C2055


1	G/BG	6	BN	11	SCR
2	B/BU	7	U/BY	12	UY
3	R/BK	8	BO	13	B
4	BR	9	R		
5	Y/YB	10	B		

R130010




1	G/BG	6	BN	11	SCR
2	B/BU	7	U/BY	12	PY
3	R/BK	8	BO	13	B
4	BR	9	R		
5	Y/BW	10	B		

R050024

C2056


1	UG	4	B
2	RN	5	B
3	-		

R050024

C2057


1	RG/RK	4	B
2	RN	5	B
3	-		

R050024

C2058


1	NY	4	B
2	RN	5	B
3	-		

R070002

C2061


1	-	5	-
2	-	6	R
3	B	7	-
4	-		

R050024

C2059


1	U	4	B
2	RN	5	B
3	-		

R020069

C2063

1	GO
2	GP



R050019

C2060

1	U	4	B
2	NY	5	UG
3	RK		

R080001

R080002



C2066

1	BO	5	UR
2	G	6	UB
3	PU	7	WB
4	N	8	RG

1	BO	5	UR
2	G	6	UB
3	PU	7	WB
4	N	8	RG

R100003

R100001

C2067


1	NW	4	S	6	UB	8	WB
2	N	5	RG	7	UW	9	W
3	LG			10	UR		

1	NW	4	S	6	UB	8	WB
2	N	5	RG	7	UW	9	W
3	LG			10	UR		


C2068

R050016

R020049


C2069

1	R	4	WB
2	WR	5	UR
3	N		




1	BO
2	WR


R040022

C2070

R030015

C2072



R020046

C2071

R100019

C2073


R100001



1	YO	4	PB	6	-	8	ON
2	RN	5	YU	7	WG	9	YB
3	B			10	-		

1	UW	4	NW	6	-	8	U
2	LG	5	W	7	UR	9	OG
3	P					10	S

R050001



C2074

30	PU	86	BK
85	PU	87	LGR
87a	-		

R060029

C2082

R060027




1	-	4	BN
2	-	5	BW
3	LGW	6	BS

1	-	4	BN
2	-	5	BW
3	LGW	6	-


C2083

R160006




1	-	5	B	9	-	13	YK
2	-	6	-	10	-	14	YLG
3	-	7	KR	11	-	15	LGR
4	B	8	KB	12	-	16	WR

R350003


C2084

1	NK	6	SR	11	WO	16	W	21	SG	26	BS	31	B
2	-	7	SU	12	-	17	G	22	SP	27	B	32	G
3	-	8	BG	13	KR	18	W	23	SK	28	-	33	W
4	SY	9	WR	14	LGR	19	NK	24	SN	29	-	34	G
5	SW	10	WS	15	G	20	-	25	GP	30	NR	35	W

R030033

C2085

1	B
2	WG
3	NR




1	B
2	WG
3	NR

R030007

C2090


R050001



30	UP	86	B
85	UP	87	BN
87a	-		


C2091

R050001




30	UP	86	U
85	B	87	NG
87a	UP		

R050001

C2092


30	BS	87	-
86	NK	85	B
87a	B		

R100018

C2095


1	B	4	B	6	B	8	B
2	B/-	5	B	7	-	9	B
3	B/-					10	B

R050001

C2093


30	OK	86	BG
85	B	87	NK
87a	-		

R020037

C2096

1	PK
2	SR

R040033



C2094

1	NR	3	NO
2	B	4	WO

R040036

C2097


R040021



1	YLG	3	-
2	YK	4	-

1	YLG	3	-
2	YK	4	-

R050024


C2098

1	RO/UB	4	UP
2	RN	5	B
3	-		


R020067

C2100

R020021





1	SB
2	SR



1	SU
2	SK

R130010

R130009


C2101

1	-	6	-	11	NP
2	B	7	-	12	K
3	-	8	-	13	O
4	-	9	BU		
5	SW	10	BK		


1	-	6	-	11	BG
2	B	7	-	12	K
3	-	8	-	13	O
4	-	9	BU		
5	SW	10	BK		

R020062

R020028.00

C2102


1	BN, BN
2	BW, BW



1	BW
2	B

R020067

R020021

C2103



1	SK
2	SU



1	SK
2	SU

R130010

R130009


C2104

1	-	6	YK	11	NP
2	B	7	PN	12	K
3	UG	8	NK	13	O
4	-	9	BP		
5	SW	10	BN		


1	-	6	YK	11	BG
2	B	7	-	12	K
3	UG	8	NK	13	O
4	-	9	BU		
5	SW	10	BK		

R020062

R020028.00

C2105

1	BR, BR
2	BK, BK




1	BW
2	B


C2107

R050001

R040001




30	GLG	87	-
85	GLG	87a	GY
86	RS		



1	-	3	B
2	KB	4	WR

C2109


R050001



30	NP	86	B
85	UB	87	UR
87a	-		

C300


R040039



1	PN	3	B
2	PU	4	-

C2110


R020066




1	BW
2	BN

C301

R060006



1	SG	4	SW
2	SG	5	SN
3	SO	6	S




1	SG	4	SW
2	SG	5	SN
3	SO	6	S


R030044

C306

R030009



1	PW
2	O
3	K




1	PW
2	O
3	K

C316


R060014

C317

R060015



1	SU	4	-
2	SN	5	SR
3	WR	6	SP




1	SG	4	WY
2	SB	5	SW
3	B	6	SY


R090001

C318

R090004




1	SB	4	SR	7	SY
2	SG	5	SN	8	SW
3	SP	6	SU	9	-



1	Y	4	G	7	Y
2	G	5	Y	8	G
3	Y	6	G	9	-

C319


R060014



1	WU	4	WO
2	WN	5	WG
3	-	6	WP

C320

R060015





1	WS	4	BP
2	WLG	5	WB
3	WU	6	WK

R090001

C321

R090004



1	WS	4	WP	7	WK
2	WLG	5	WN	8	WB
3	WG	6	WU	9	-


1	G	4	Y	7	Y
2	Y	5	Y	8	G
3	G	6	G	9	-

C323


R050009

C334

R030003




1	-	4	BO
2	GY	5	BY
3	GN		




1	LGO
2	B
3	GN

R040034

C335


1	BN	3	WB
2	B	4	-

R060026

C339


1	SW	4	B
2	SO	5	WK
3	WK	6	RN

R060026


C337

1	BU	4	B
2	BK	5	-
3	-	6	RN

R060026


C340

1	S	4	B
2	SN	5	WK
3	WK	6	RN

C338


1	BS	4	B
2	BR	5	-
3	-	6	RN

R080029

C343


1	B	5	-
2	SG	6	-
3	-	7	-
4	-	8	-

R060016

C344


1	P	4	BR
2	GP	5	KS
3	B	6	KS

R030040

C350


1	PU
2	-
3	PN

R020069

C346


1	B
2	GLG

R020057

C351


1	LGW
2	B

R050001

C348

30	B	86	LGW
87	BP	30	B
87a	-		


R020057

C352

1	LGW
2	B

C353


R020015



1	B
2	LGW

C369


R020037



1	SB
2	B

C358


R050001



85	PU,PU	86	NP
87	WIN	30	NP
87a	-		

C370


R030003



1	GY
2	-
3	BR

C368


R030021



1	-
2	B
3	BK


C371

R020003




1	BG
2	B

R020037

C372


1	GN
2	GY

R080008

C382


1	-	5	-
2	-	6	GW
3	GO	7	GU
4	OG	8	OU

R020005

C378

1	RW
2	B


R100006

C383

A	P	D	B	F	WG	H	GK
B	U	E	W	G	GB	I	GR
C	NR					J	O


C381

R030018




1	P
2	-
3	B

R070008

C384


1	GO	5	-
2	GR	6	-
3		7	-
4	B		

R070008

C385


1	GU	5	-
2	GK	6	-
3	-	7	-
4	B		

R040018

C388


1	O	3	B
2	OG	4	U

R050024

C386


1	B	4	BS
2	-	5	-
3	-		

R030027

C389


1	GW
2	GB
3	BS

R040018

C387


1	W	3	B
2	OU	4	P

R050026

C391


1	BR	4	GR
2	N	5	B
3	Y		

R050024

C392


1	LGW	4	B
2	RB	5	UW
3	-		

R060028

C3003


1	B	4	B
2	B	5	B
3	B	6	-

R030006

C3004

1	SG
2	SW
3	SO

R030007




1	SG
2	SW
3	SO


R020012

C3005

R020028.01




1	O
2	K




1	O
2	K

R030006

R030007

C3006


1	SG
2	SN
3	S




1	SG
2	SN
3	S

R020012

R020028.01

C3007


1	O
2	K




1	O
2	K

R070003

R060024


C400

1	RO	5	B
2	GP	6	RY
3	GW	7	RB
4	GR		



1	GR	4	B
2	GP	5	RY
3	RB	6	GN


R060024

C406


1	GW	4	B
2	GP	5	RY
3	RO	6	GN

R060017

R060016

C407

1	WP	4	-
2	GB	5	-
3	B	6	-




1	WP	4	-
2	GB	5	-
3	B	6	-

C408


R030003

C412

R060012




1	NY
2	GO
3	NG




1	SCR	4	LGO
2	R	5	PY
3	B	6	B

R040037

C413


1	BW	3	BW
2	B	4	B

R020031

C414


1	K
2	O

R080014

C415


1	K	5	GP
2	RB	6	B
3	NG	7	O
4	GLG	8	B

R080013



1	K	5	GP
2	RB	6	B
3	NG	7	O
4	GO	8	B



R040001

C434

1	GB	3	B
2	B	4	WP

R060031

R060029


C437

1	SCR	4	-
2	B	5	PY
3	R	6	LGO

1	SCR	4	GP
2	B	5	PY
3	R	6	LGO

R020041

R020056


C438

1	NP
2	B


1	NP
2	B

R020037

R020037


C441

1	GR
2	B




1	RB
2	B

R020061

C443


1	RB
2	B

R020037

C445


1	GW
2	B

R020037

C444


1	RO
2	B

R020061

C446


1	RO
2	B

R020050

C447


1	B
2	YG

R020059




1	B
2	NG

R160001

C448

1	-	5	-	9	P	13	BG
2	Y	6	YL	10	-	14	UW
3	G	7	N	11	-	15	LGW
4	UB	8	-	12	WLG	16	BR


R160007



1	-	5	-	9	P	13	BG
2	Y	6	W	10	-	14	UW
3	GR	7	N	11	-	15	LGW
4	UB	8	-	12	WLG	16	BR

C457


R050016



1	YG	4	B
2	NR	5	WG
3	PG		

C459


R040022



1	B	3	Y
2	N	4	G

C458


R020047



1	NR
2	G


C462

R020046




1	R
2	YG

R040023

C463


1	WG	3	G
2	S	4	B

R040023

C466


1	WG	3	S
2	PG	4	BR

R020048

C464


1	BG
2	RG

R060020

C467


1	WG	4	LGW
2	R	5	B
3	YL	6	G

R040023

C465

1	WG	3	S
2	WG	4	UW


R020007

C485

1	W
2	W

C486


R020007



1	W
2	W

C500


R020037



1	SU
2	SK

C487


R060028



1	B	4	B
2	B	5	B
3	B	6	B

C503


R060008



1	2	3
4	5	6

C489


R020071




1	B
2	NY

R020053

R040011

C507


1	O
2	K



1	O	3	NK
2	K	4	B

C507

R060009




1	O	4	-
2	K	5	YK
3	B	6	-


C600

R020037

R060008


C603

1	SU
2	SK




1	B	4	SW
2	BG	5	SW
3	BU	6	BK

R040016

C604


1	UG	3	-
2	-	4	B

R060009

C607


1	O	4	-
2	K	5	YK
3	B	6	-

R040011




1	O	3	NK
2	K	4	B

R020037

C703

1	SW
2	SO


R020029

C706

1	O
2	K

C709


R050008



1	SO	4	SW
2	SO	5	SW
3	SG		

C806


R020029



1	O
2	K

C803


R020037



1	SW
2	SO

C809


R050008



1	SW	4	SN
2	S	5	SO
3	SG		

HJ1

R200001

**S2042**

1	GO
2	GO
3	GO
4	GO
5	GO
6	GO
7	-
8	-


S2045

9	LGP
10	-
11	LGP
12	LGP

S274

13	GLG
14	GLG
15	GLG
16	GLG
17	GLG
18	GLG
19	GLG
20	GLG

R200008

HJ2**S2074**

1	RN
2	RN
3	RN
4	RN
5	-
6	RN

S2005

7	BY
8	BY
9	BY
10	BY


S2030

11	YK
12	Y
13	YK
14	YK

S2095

15	LGW
16	LGW
17	LGW
18	LGW
19	-
20	-

R200001

HJ3**S238**

1	B
2	-
3	B
4	B
5	B
6	-
7	B
8	B


S2032

9	B
10	BO
11	B
12	B

S2003

13	B
14	-
15	B
16	B
17	B
18	B
19	B
20	B

R200001

HJ4**S2055**

1	GP
2	-
3	GP
4	GP
5	GP
6	GP
7	GP
8	GP

S2014


9	WP
10	WP
11	WP
12	WP

S2011

13	-
14	GP
15	GP
16	GP
17	GP
18	GP
19	GP
20	GP

HJ5

R200001

**S2031**

1	B
2	B
3	-
4	B
5	B
6	B
7	B
8	-

S2017


9	-
10	B
11	GK
12	GK

S288

13	B
14	B
15	B
16	B
17	-
18	B
19	B
20	B

HJ6

R200009

**S2019**

1	GW
2	GW
3	GW
4	GW

S2020

5	GR
6	GR
7	GR
8	GR

S2018


9	BR
10	BR
11	BR
12	BR

S2021

13	P
14	P
15	P
16	P
17	P
18	-
19	-
20	-

HJ7

R200008

**S290**

1	BS
2	B
3	BS
4	-
5	-
6	BS

S291

7	NO
8	NO
9	NO
10	NO


S292

11	WG
12	B
13	WG
14	WG

S293

15	RB
16	RB
17	RB
18	RB
19	RB
20	-

R200001

HJ8

S253

1	B
2	B
3	B
4	B
5	B
6	B
7	B
8	B


S255

9	RO
10	RO
11	RO
12	RO

S252

13	B
14	B
15	B
16	B
17	B
18	B
19	B
20	B

R200001

HJ9

S256

1	RO/RN
2	RN
3	RN
4	RN
5	RN
6	RN
7	RN
8	RN


S251

9	LG
10	LG
11	LG
12	LG

S214

13	RN
14	RN
15	RN
16	RN
17	RN
18	RN
19	RN
20	-

R200001

HJ10

S204

1	B
2	B
3	B
4	B
5	B
6	B
7	B
8	B


S2016

9	B
10	B
11	-
12	-

S203

13	B
14	B
15	B
16	B
17	B
18	B
19	B
20	B

R200001

HJ11**S2023**

1	B
2	B
3	B
4	B
5	B
6	B
7	B
8	B


S2015

13	B
14	B
15	B
16	B
17	-
18	B
19	B
20	B

S2013

9	PG
10	PG
11	PG
12	PG

R200009

HJ12**S420**

13	RB
14	RB
15	RB
16	RB
17	RB
18	RB
19	RB
20	RB

S434

1	RY
2	RY
3	RY
4	RY

S440

5	RO
6	RO
7	-
8	RO

S409


9	GP
10	GP
11	GP
12	-

P126
Fascia Fuse Box

P127
Satellite Fuse
Box 1

P128
Satellite Fuse
Box 2

P125
Engine Compartment Fuse Box



MAIN HARNESS (PARTIAL)

