

MODEL	ODKUPNA CENA
Brother	
Brother DR-1030 OPC	0.1
Brother DR-1090 OPC	0.1
Brother DR-130 cmyk OPC	0.02
Brother DR-2100 OPC	0.02
Brother DR-2200 OPC	0.2
Brother DR-2300 OPC	0.5
Brother DR-2400 OPC drum	1
Brother DR-2401 OPC drum	1.2
Brother DR-241 bl OPC	0.3
Brother DR-241 cmy OPC	0.3
Brother DR-243 black OPC	0.4
Brother DR-243 cmy OPC	0.4
Brother DR-3100 OPC	0.02
Brother DR-320 cmyk OPC	1.2
Brother DR-3200 OPC	0.05
Brother DR-321 cmyk OPC	1.2
Brother DR-3400 OPC	0.05
Brother DR-421 cmyk OPC	1.2
Brother DR-6000 OPC	0.02
Brother TN-1030	0.3
Brother TN-2000	0.06
Brother TN-2000 START	0.06
Brother TN-2005	0.2
Brother TN-2005 START	0.2
Brother TN-2010	0.1
Brother TN-2110/2120	0.24
Brother TN-2210/2220	0.3
Brother TN-2210/2220 START	0.1
Brother TN-230 START	0.12
Brother TN-230 black	0.2
Brother TN-230 cyan	0.2
Brother TN-230 magenta	0.2
Brother TN-230 yellow	0.2
Brother TN-2310	0.2
Brother TN-2320	0.2
Brother TN-241 START	0.2
Brother TN-241 black	0.3
Brother TN-241 cyan	0.3
Brother TN-241 magenta	0.3
Brother TN-241 yellow	0.3
Brother TN-2410	0.2
Brother TN-2411	0.2
Brother TN-242 black	0.3
Brother TN-242 cyan	0.3
Brother TN-242 magenta	0.3
Brother TN-242 yellow	0.3
Brother TN-2420	0.2
Brother TN-2421	0.2

Brother TN-243 START	0.2
Brother TN-243 black	0.6
Brother TN-243 cyan	0.6
Brother TN-243 magenta	0.6
Brother TN-243 yellow	0.6
Brother TN-245 cyan	0.3
Brother TN-245 magenta	0.3
Brother TN-245 yellow	0.3
Brother TN-246 black	0.26
Brother TN-246 cyan	0.26
Brother TN-246 magenta	0.26
Brother TN-246 yellow	0.26
Brother TN-247 START	0.2
Brother TN-247 black	0.6
Brother TN-247 cyan	0.6
Brother TN-247 magenta	0.6
Brother TN-247 yellow	0.6
Brother TN-3130/3170	0.02
Brother TN-320 / TN-325 cmyk S1	0.1
Brother TN-320 black	0.24
Brother TN-320 cyan	0.24
Brother TN-320 magenta	0.24
Brother TN-320 yellow	0.24
Brother TN-321 / TN-326 cmyk S1	0.1
Brother TN-321 black	0.24
Brother TN-321 cyan	0.24
Brother TN-321 magenta	0.24
Brother TN-321 yellow	0.24
Brother TN-3230/3280	0.02
Brother TN-325 black	0.24
Brother TN-325 cyan	0.24
Brother TN-325 magenta	0.24
Brother TN-325 yellow	0.24
Brother TN-326 black	0.24
Brother TN-326 cyan	0.24
Brother TN-326 magenta	0.24
Brother TN-326 yellow	0.24
Brother TN-328 black	0.24
Brother TN-328 cyan	0.24
Brother TN-328 magenta	0.24
Brother TN-328 yellow	0.24
Brother TN-329 START	0.08
Brother TN-329 black	0.08
Brother TN-329 cyan	0.08
Brother TN-329 magenta	0.08
Brother TN-329 yellow	0.08
Brother TN-3480	0.1
Brother TN-421 / 423 START	0.1
Brother TN-421 black	0.4
Brother TN-421 cyan	0.4

Brother TN-421 magenta	0.4
Brother TN-421 yellow	0.4
Brother TN-423 black	0.4
Brother TN-423 cyan	0.4
Brother TN-423 magenta	0.4
Brother TN-423 yellow	0.4
Brother TN-426 black	0.3
Brother TN-426 cyan	0.3
Brother TN-426 magenta	0.3
Brother TN-426 yellow	0.3
Brother TN-6300/6600	0.05

CANON

Canon 039	0.1
Canon 039H	0.2
Canon 040 black	0.5
Canon 040 cyan	0.6
Canon 040 magenta	0.6
Canon 040 yellow	0.6
Canon 040H black	0.5
Canon 040H cyan	0.6
Canon 040H magenta	0.6
Canon 040H yellow	0.6
Canon 041	0.5
Canon 041 START	0.4
Canon 041H	1.2
Canon 045 cmyk START	0.2
Canon 045 black	0.4
Canon 045 cyan	0.4
Canon 045 magenta	0.4
Canon 045 yellow	0.4
Canon 045H black	0.4
Canon 045H cyan	0.4
Canon 045H magenta	0.4
Canon 045H yellow	0.4
Canon 046 cmyk START	0.08
Canon 046 black	0.2
Canon 046 cyan	0.2
Canon 046 magenta	0.2
Canon 046 yellow	0.2
Canon 046H black	0.2
Canon 046H cyan	0.8
Canon 046H magenta	0.8
Canon 046H yellow	0.8
Canon 051	0.8
Canon 051 START	0.8
Canon 051H	1.2
Canon 052	0.4
Canon 052 START	0.4
Canon 052H	1
Canon 055 black	0.4

Canon 055 cyan	0.4
Canon 055 magenta	0.4
Canon 055 yellow	0.4
Canon 055H black	0.6
Canon 055H cyan	0.6
Canon 055H magenta	0.6
Canon 055H yellow	0.6
Canon 057	0.6
Canon 057 START	0.6
Canon 057H	0.6
Canon 703/103/303	0.08
Canon 707 black	0.26
Canon 707 cyan	0.26
Canon 707 magenta	0.26
Canon 707 yellow	0.26
Canon 708H	0.03
Canon 716 cmyk START	0.16
Canon 716 black	0.32
Canon 716 cyan	0.32
Canon 716 magenta	0.32
Canon 716 yellow	0.32
Canon 718 black	0.17
Canon 718 cyan	0.17
Canon 718 magenta	0.17
Canon 718 yellow	0.17
Canon 719A	0.02
Canon 719H	0.02
Canon 723 black	0.4
Canon 723 cyan	0.4
Canon 723 magenta	0.4
Canon 723 yellow	0.4
Canon 723H black	0.4
Canon 724	0.02
Canon 724H	0.02
Canon 725	0.25
Canon 726	0.02
Canon 728	0.08
Canon 729 cmyk START	0.1
Canon 729 black	0.2
Canon 729 cyan	0.2
Canon 729 magenta	0.2
Canon 729 yellow	0.2
Canon 731 cmyk START	0.16
Canon 731 black	0.32
Canon 731 cyan	0.32
Canon 731 magenta	0.32
Canon 731 yellow	0.32
Canon 731H black	0.32
Canon 732 black	0.4
Canon 732 cyan	0.4

Canon 732 magenta	0.4
Canon 732 yellow	0.4
Canon 732H black	0.4
Canon 737	0.2
Canon C-EXV 47	0.02
Canon C-EXV 49	0.02
Canon C-EXV 51 black	0.02
Canon C-EXV 51 cyan	0.02
Canon C-EXV 51 magenta	0.02
Canon C-EXV 51 yellow	0.02
Canon EP-27	0.05
Canon EP-P	0.02
Canon FX-10	0.02

DELL

Dell 1815	0.02
Dell 3110/3115/3130 cmyk	0.17
Dell 5210/5310	0.2
Dell 5230 cmyk	0.2
Dell B2360 / B3460	0.2
Dell C2660/2665 cmyk	0.05
Dell C2660/3760 cmyk DRUM	0.02
Dell H 625 / 825	0.1

EPSON

Epson EPL 6200 S051099 OPC	0.02
Epson M4000 S051173 S05117	0.4
Epson N2550 S050290	0.2
Epson N3000 S051111	0.2

HP

HP 1010 Q2612A 12A	0.08
HP 1100 C4092A 92A	0.01
HP 1150 Q2624A 24A	0.01
HP 1320 Q5949X 49X	0.02
HP 2420 Q6511X 11X	0.1
HP 2600 Q6000A black 124A	0.26
HP 2600 Q6001A cyan 124A	0.26
HP 2600 Q6002A yellow 124A	0.26
HP 2600 Q6003A magenta 124A	0.26
HP 4200 Q1338A 38A	1.2
HP 4250 Q5942A 42A	0.6
HP 4250 Q5942X 42X	0.5
HP 4700 Q5950/1/2/3 643A	0.4
HP 4700 Q5950A black 643A	1.6
HP 4700 Q5951A cyan 643A	1.6
HP 4700 Q5952A yellow 643A	1.6
HP 4700 Q5953A magenta 643A	1.6
HP 4730 Q6460/1/2/3 644A	0.4
HP 4730 Q6460A black 644A	1.6
HP 4730 Q6461A cyan 644A	1.6
HP 4730 Q6462A yellow 644A	1.6

HP 4730 Q6463A magenta 644A	1.6
HP 4L 92274A 74A	0.02
HP 5025 Q7570A 70A	0.5
HP 5200 Q7516A 16A	0.4
HP 5500 C9730/1/2/3A 645A	0.2
HP 5500 C9730A black 645A	1.3
HP 5500 C9731A cyan 645A	1.3
HP 5500 C9732A yellow 645A	1.3
HP 5500 C9733A magenta 645A	1.3
HP 5P C3903A 03A	0.15
HP 5Si C3909A/X 09A/X	0.2
HP 9000 C8543X 43X	1
HP CB400A black 642A	1.6
HP CB401A cyan 642A	1.6
HP CB402A yellow 642A	1.6
HP CB403A magenta 642A	1.6
HP CB435A 35A	0.02
HP CB540/1/2/3 125A START	0.16
HP CB540A black 125A	0.32
HP CB541A cyan 125A	0.32
HP CB542A yellow 125A	0.32
HP CB543A magenta 125A	0.32
HP CC364A 64A	0.3
HP CC364X 64X	0.7
HP CC530A black 304A	0.17
HP CC531A cyan 304A	0.17
HP CC532A yellow 304A	0.17
HP CC533A magenta 304A	0.17
HP CE250/1/2/3 504A START	0.3
HP CE250A black 504A	0.4
HP CE250X black 504X	0.4
HP CE251A cyan 504A	0.4
HP CE252A yellow 504A	0.4
HP CE253A magenta 504A	0.4
HP CE254A TONER COLLECTION U	0.02
HP CE255A 55A	0.02
HP CE255X 55X	0.02
HP CE260A black 647A	0.4
HP CE260X black 649X	0.4
HP CE261A cyan 648A	0.4
HP CE262A yellow 648A	0.4
HP CE263A magenta 648A	0.4
HP CE270/1/2/3 650A NV	0.2
HP CE270A black 650A	1.3
HP CE271A cyan 650A	1.3
HP CE272A yellow 650A	1.3
HP CE273A magenta 650A	1.3
HP CE285A 85A	0.2
HP CE310A black 126A	0.2
HP CE311A cyan 126A	0.2

HP CE312A yellow	126A	0.2
HP CE313A magenta	126A	0.2
HP CE320/1/2/3	128A START	0.16
HP CE320A black	128A	0.32
HP CE321A cyan	128A	0.32
HP CE322A yellow	128A	0.32
HP CE323A magenta	128A	0.32
HP CE340A black	651A	0.7
HP CE341A cyan	651A	0.9
HP CE342A yellow	651A	0.9
HP CE343A magenta	651A	0.9
HP CE390A	90A	0.2
HP CE390X	90X	0.2
HP CE400/1/2/3	507A START	0.4
HP CE400A black	507A	0.4
HP CE400X black	507X	0.4
HP CE401A cyan	507A	0.4
HP CE402A yellow	507A	0.4
HP CE403A magenta	507A	0.4
HP CE410A black	305A	0.17
HP CE410X black	305X	0.17
HP CE411A cyan	305A	0.17
HP CE412A yellow	305A	0.17
HP CE413A magenta	305A	0.17
HP CE505A	05A	0.02
HP CE505X	05X	0.02
HP CE740/1/2/3	307A NV	0.2
HP CE740A black	307A	1.3
HP CE741A cyan	307A	1.3
HP CE742A yellow	307A	1.3
HP CE743A magenta	307A	1.3
HP CF031A cyan	646A	0.2
HP CF032A yellow	646A	0.2
HP CF033A magenta	646A	0.2
HP CF210/1/2/3	131A START	0.16
HP CF210A black	131A	0.2
HP CF210X black	131X	0.32
HP CF211A cyan	131A	0.32
HP CF212A yellow	131A	0.32
HP CF213A magenta	131A	0.32
HP CF217A	17A	0.2
HP CF219A	19A DRUM	0.6
HP CF226A	26A	0.5
HP CF226X	26X	1
HP CF228A	28A	1.2
HP CF228X	28X	2.6
HP CF230X	30X	0.4
HP CF232A	32A DRUM	0.4
HP CF233A	33A	0.4
HP CF234A	34A DRUM	0.4

HP CF237A	37A	0.5
HP CF237X	37X	2.4
HP CF237Y	37Y	2.4
HP CF244A	44A	0.6
HP CF259A	59A	1.6
HP CF259X	59X	2.8
HP CF280A	80A	0.02
HP CF280X	80X	0.02
HP CF281X	81X	0.1
HP CF283A	83A	0.1
HP CF283X	83X	0.1
HP CF287A	87A	0.5
HP CF287X	87X	1.2
HP CF289A	89A START	1.2
HP CF289A	89A	1.2
HP CF289X	89X	1.2
HP CF289Y	89Y	1.2
HP CF310A	black 826A	0.1
HP CF311A	cyan 826A	0.1
HP CF312A	yellow 826A	0.1
HP CF313A	magenta 826A	0.1
HP CF320A	black 652A	0.2
HP CF320X	black 653X	0.2
HP CF321A	cyan 653A	0.2
HP CF322A	yellow 653A	0.2
HP CF323A	magenta 653A	0.2
HP CF330X	black 654X	0.2
HP CF331A	cyan 654A	0.2
HP CF332A	yellow 654A	0.2
HP CF333A	magenta 654A	0.2
HP CF350A	black 130A	0.2
HP CF351A	cyan 130A	0.2
HP CF352A	yellow 130A	0.2
HP CF353A	magenta 130A	0.2
HP CF360A	black 508A	0.5
HP CF360X	black 508X	0.5
HP CF361A	cyan 508A	0.7
HP CF361X	cyan 508X	0.6
HP CF362A	yellow 508A	0.7
HP CF362X	yellow 508X	0.6
HP CF363A	magenta 508A	0.7
HP CF363X	magenta 508X	0.6
HP CF380A	black 312A	0.17
HP CF380X	black 312X	0.17
HP CF381A	cyan 312A	0.17
HP CF382A	yellow 312A	0.17
HP CF383A	magenta 312A	0.17
HP CF400A	black 201A	0.32
HP CF400X	black 201X	0.3
HP CF401A	cyan 201A	0.4

HP CF401X cyan	201X	0.4
HP CF402A yellow	201A	0.4
HP CF402X yellow	201X	0.4
HP CF403A magenta	201A	0.4
HP CF403X magenta	201X	0.4
HP CF410A black	410A	0.2
HP CF410X black	410X	0.2
HP CF411A cyan	410A	0.24
HP CF411X cyan	410X	0.8
HP CF412A yellow	410A	0.24
HP CF412X yellow	410X	0.8
HP CF413A magenta	410A	0.24
HP CF413X magenta	410X	0.8
HP CF450A black	655A	1
HP CF451A cyan	655A	1
HP CF452A yellow	655A	1
HP CF453A magenta	655A	1
HP CF460X black	656X	0.3
HP CF461X cyan	656X	1
HP CF462X yellow	656X	1
HP CF463X magenta	656X	1
HP CF470X black	657X	1
HP CF471X cyan	657X	1
HP CF472X yellow	657X	1
HP CF473X magenta	657X	1
HP CF500A black	202A	0.6
HP CF500X black	202X	0.6
HP CF501A cyan	202A	0.6
HP CF501X cyan	202X	0.8
HP CF502A yellow	202A	0.6
HP CF502X yellow	202X	0.8
HP CF503A magenta	202A	0.6
HP CF503X magenta	202X	0.8
HP CF510A black	204A	0.6
HP CF511A cyan	204A	0.6
HP CF512A yellow	204A	0.6
HP CF513A magenta	204A	0.6
HP CF530A black	205A	0.1
HP CF531A cyan	205A	0.2
HP CF532A yellow	205A	0.2
HP CF533A magenta	205A	0.2
HP CF540A black	203A	0.1
HP CF540X black	203X	0.2
HP CF541A cyan	203A	0.4
HP CF541X cyan	203X	0.7
HP CF542A yellow	203A	0.4
HP CF542X yellow	203X	0.7
HP CF543A magenta	203A	0.4
HP CF543X magenta	203X	0.7
HP W1106A	106A	0.5

HP W2030A black	415A	0.5
HP W2030X black	415X	0.5
HP W2031A cyan	415A	0.5
HP W2031X cyan	415X	0.5
HP W2032A yellow	415A	0.5
HP W2032X yellow	415X	0.5
HP W2033A magenta	415A	0.5
HP W2033X magenta	415X	0.5

KYOCERA

Kyocera DK-130 OPC		0.2
Kyocera DK-150 OPC		0.2
Kyocera DK-170 OPC		0.2
Kyocera PU-120 OPC		0.4
Kyocera TK-1115		0.2
Kyocera TK-1140		0.1
Kyocera TK-1150		0.2
Kyocera TK-1170 high	7200 p	0.2
Kyocera TK-1170 small	3600 p	0.05
Kyocera TK-130		0.02
Kyocera TK-140		0.02
Kyocera TK-150		0.7
Kyocera TK-160		0.02
Kyocera TK-170		0.02
Kyocera TK-3060		0.5
Kyocera TK-3150		0.1
Kyocera TK-3160		0.1
Kyocera TK-3190		0.1
Kyocera TK-5220C/TK-5230C cyan		0.2
Kyocera TK-5220K/TK-5230K black		0.2
Kyocera TK-5220M/TK-5230M magenta		0.2
Kyocera TK-5220Y/TK-5230Y yellow		0.2
Kyocera TK-5240C cyan		0.2
Kyocera TK-5240K black		0.2
Kyocera TK-5240M magenta		0.2
Kyocera TK-5240Y yellow		0.2
Kyocera TK-5270C cyan		0.2
Kyocera TK-5270K black		0.2
Kyocera TK-5270M magenta		0.2
Kyocera TK-5270Y yellow		0.2
Kyocera TK-5280C cyan		0.2
Kyocera TK-5280K black		0.2
Kyocera TK-5280M magenta		0.2
Kyocera TK-5280Y yellow		0.2
Kyocera TK-7105		0.1

LEXMARK

Lexmark C734 black big		0.1
Lexmark C734 cyan big		0.1
Lexmark C734 magenta big		0.1
Lexmark C734 yellow big		0.1
Lexmark C736 black big		0.1

Lexmark C736 cyan big	0.1
Lexmark C736 magenta big	0.1
Lexmark C736 yellow big	0.1
Lexmark C746 black big	0.1
Lexmark C746 cyan big	0.1
Lexmark C746 magenta big	0.1
Lexmark C746 yellow big	0.1
Lexmark C748 black	0.1
Lexmark C748 cyan	0.1
Lexmark C748 magenta	0.1
Lexmark C748 yellow	0.1
Lexmark C792 X792 cyan	0.1
Lexmark C792 X792 magenta	0.1
Lexmark C792 X792 yellow	0.1
Lexmark C950 X950 cmyk	0.1
Lexmark C950 X950 drum OPC	0.4
Lexmark CS310 CX410 black	0.3
Lexmark CS310 CX410 cyan	0.3
Lexmark CS310 CX410 magenta	0.3
Lexmark CS310 CX410 yellow	0.3
Lexmark CS317 CX317 black	0.3
Lexmark CS317 CX317 cyan	0.3
Lexmark CS317 CX317 magenta	0.3
Lexmark CS317 CX317 yellow	0.3
Lexmark CS421 CX421 black	0.3
Lexmark CS421 CX421 cyan	0.3
Lexmark CS421 CX421 magenta	0.3
Lexmark CS421 CX421 yellow	0.3
Lexmark CS820/CS827 CX820/CX827	0.1
Lexmark CS820/CS827 CX820/CX827	0.1
Lexmark CS820/CS827 CX820/CX827	0.1
Lexmark CS820/CS827 CX820/CX827	0.1
Lexmark CS820/CS827 CX820/CX827	0.1
Lexmark E120 OPC 12026XW dr	0.1
Lexmark E260/360/460 OPC E260	0.02
Lexmark MS 310/410/510/610	0.2
Lexmark MS 310/410/510/610 N	0.02
Lexmark MS 310/410/510/610 O	0.05
Lexmark MS 310/410/510/610 S	0.2
Lexmark MS 317/417/517/617	0.2
Lexmark MS 317/417/517/617 S	0.2
Lexmark MS 421	0.2
Lexmark MS 421 START	0.2
Lexmark MS 710/810	0.2
Lexmark MS 710/810 NV	0.1
Lexmark MS 710/810 START	0.2
Lexmark MS 720/725/825 STAR	0.2
Lexmark MS 720/725/825 58D2U	0.2
Lexmark MS 720/725/825 drum 5	0.1
Lexmark T420 12A7410/15	0.02

Lexmark T430 12A8420/25	0.02
Lexmark T640	0.2
Lexmark T650	0.2
Lexmark W840 W84030H X850/ε	0.4

KONICA MINOLTA

Minolta 1400	0.4
Minolta 5550 cmyk toner	0.05
Minolta IU210 C250/252 OPC	0.2
Minolta IU211 C203-253 OPC cyan	0.2
Minolta IU211 C203-253 OPC mag	0.2
Minolta IU211 C203-253 OPC yell	0.2
Minolta IU612 C452/552/652 OPC	0.1
Minolta TNP-34/35/36 toner	0.2
Minolta TNP-54/63 toner	0.1

OKI

Okı B2500 MB260	0.6
Okı B401 44992401/44992402 to	0.02
Okı B410/430 43979002 OPC	0.2
Okı B411/431 44574702/4457480	0.02
Okı B411/431/451 44574302	0.6
Okı B411/431/451 44574302 O	0.4
Okı B412/432 45807106 toner	0.02
Okı B432/B512 45807111 toner	0.02
Okı B6200/6300 00904078	0.6
Okı B6500 09004461, 0900	0.6
Okı B710/720/730 01279001 01:	0.4
Okı B721/731 45435104 fuser	0.08
Okı B721/B731 only DRUM	0.1
Okı B721/B731 only toner	0.1
Okı B721/B731 toner + drum	2
Okı B840 44661802 toner + dru	0.6
Okı C301/310 44472202 transfer	0.2
Okı C301/310 44472603 fuser	0.08
Okı C532 ES5432 46394902 trans	0.2
Okı C5600/5800 43363412 trans	0.2
Okı C610/711 44289103 fuser	0.08
OKI C811/831/841 44846204 trar	0.2
Okı C110 toner 44250717, 442507	0.05
Okı C110 toner 44250718, 442507	0.05
Okı C110 toner 44250719, 442507	0.05
Okı C110 toner 44250724 black	0.05
Okı C301 toner 44973533 yellow	0.08
Okı C301 toner 44973534 magent	0.08
Okı C301 toner 44973535 cyan	0.08
Okı C301 toner 44973536 black	0.08
Okı C301/310 drum 44968301 44:	0.1
Okı C310 toner 44469704 yellow	0.08
Okı C310 toner 44469705 magent	0.08
Okı C310 toner 44469706 cyan	0.08
Okı C310 toner 44469803 black	0.08

Oki C510 toner 44469704, 444697	0.08
Oki C510 toner 44469706, 444697	0.08
Oki C510 toner 44469805, 444697	0.08
Oki C510/C511 ton 44973508, 444	0.08
Oki C532 drum 46484105 yellow C	0.02
Oki C532 drum 46484106 magent:	0.02
Oki C532 drum 46484107 cyan OP	0.02
Oki C532 drum 46484108 black OI	0.02
Oki C532 toner 46490401, 464906	0.2
Oki C532 toner 46490402, 464906	0.2
Oki C532 toner 46490403, 464906	0.2
Oki C532 toner 46490404, 464906	0.2
Oki C5600 drum 43381705 yellow	0.1
Oki C5600 drum 43381706 magen	0.1
Oki C5600 drum 43381707 cyan C	0.1
Oki C5600 drum 43381708 black C	0.1
Oki C5600 toner 43324405, 43324	0.07
Oki C5600 toner 43324406, 43324	0.07
Oki C5600 toner 43324407, 43324	0.07
Oki C5600 toner 43324408, 43324	0.07
Oki C610 drum 44315105 yellow C	0.1
Oki C610 drum 44315106 magent:	0.1
Oki C610 drum 44315107 cyan OP	0.1
Oki C610 drum 44315108 black OI	0.1
Oki C610 toner 44315305 yellow	0.07
Oki C610 toner 44315306 magent:	0.07
Oki C610 toner 44315307 cyan	0.07
Oki C610 toner 44315308 black	0.07
Oki C612 drum 46507305 yellow C	0.03
Oki C612 drum 46507306 magent:	0.03
Oki C612 drum 46507307 cyan OP	0.03
Oki C612 drum 46507308 black OI	0.03
Oki C612 toner 46507505 yellow	0.08
Oki C612 toner 46507506 magent:	0.08
Oki C612 toner 46507507 cyan	0.08
Oki C612 toner 46507508 black	0.08
Oki C710 drum 43913805 yellow C	0.05
Oki C710 drum 43913806 magent:	0.05
Oki C710 drum 43913807 cyan OP	0.05
Oki C710 drum 43913808 black OI	0.05
Oki C822 toner 44844613 yellow	0.1
Oki C822 toner 44844614 magent:	0.1
Oki C822 toner 44844615 cyan	0.1
Oki C823 toner 46471101, 464431	0.2
Oki C823 toner 46471102, 464431	0.2
Oki C823 toner 46471103, 464431	0.2
Oki C823 toner 46471104, 464431	0.2
Oki C8600 toner 43487709 yellow	0.02
Oki C8600 toner 43487710 magen	0.02
Oki C8600 toner 43487711 cyan	0.02

Oki C8600 toner 43487712 black	0.02
Oki C9600 drum 42918105 yellow	0.04
Oki C9600 drum 42918106 magen	0.04
Oki C9600 drum 42918107 cyan C	0.04
Oki C9600 drum 42918108 black C	0.04
Oki MC853 toner 45862814, 4586	0.2
Oki MC853 toner 45862815, 4586	0.2
Oki MC853 toner 45862816, 4586	0.2
Oki MC853 toner 45862818, 4586	0.2

PANASONIC

Panasonic UG-3220 OPC	0.2
Panasonic UG-3221 toner	0.1
Panasonic UG-3350	0.5
Panasonic UG-3380	0.5

RICOH

Ricoh SP 201/203	0.1
Ricoh SP 311 3,5K	0.6
Ricoh SP 311 6.4K	0.6
Ricoh SP1000 SP1100 FAX1140 /	0.5
Ricoh SP3400	0.6
Ricoh SP4100 15 K	0.2
Ricoh SP4500E toner	0.2
Ricoh SP4510E toner	0.4
Ricoh SP5200	0.4
Ricoh SPC 220 black	0.8
Ricoh SPC 220 cyan	0.8
Ricoh SPC 220 magenta	0.8
Ricoh SPC 220 yellow	0.8
Ricoh SPC 250 black	0.8
Ricoh SPC 250 cyan	0.8
Ricoh SPC 250 magenta	0.8
Ricoh SPC 250 yellow	0.8
Ricoh SPC 310 black	0.8
Ricoh SPC 310 cyan	0.8
Ricoh SPC 310 magenta	0.8
Ricoh SPC 310 yellow	0.8
Ricoh SPC 340 black	0.8
Ricoh SPC 340 cyan	0.8
Ricoh SPC 340 magenta	0.8
Ricoh SPC 340 yellow	0.8

SAMSUNG

Samsung CLP-310 drum CLT-R409	0.5
Samsung CLP-320 drum CLT-R407	0.5
Samsung CLP-360 CLT-R406 OPC	1
Samsung CLP-415 CLT-504 START	0.2
Samsung CLP-415 CLT-C504S cyan	0.3
Samsung CLP-415 CLT-K504S black	0.3
Samsung CLP-415 CLT-M504S magenta	0.3
Samsung CLP-415 CLT-Y504S yellow	0.3

Samsung CLP-620 CLT-C5082 cya	0.1
Samsung CLP-620 CLT-K5082 blac	0.1
Samsung CLP-620 CLT-M5082 ma	0.1
Samsung CLP-620 CLT-Y5082 yell	0.1
Samsung CLP-680 CLT-C506L cya	0.1
Samsung CLP-680 CLT-K506L blac	0.1
Samsung CLP-680 CLT-M506L ma	0.1
Samsung CLP-680 CLT-Y506L yell	0.1
Samsung CLP-770 CLT-C6092S cy	0.07
Samsung CLP-770 CLT-K6092S bla	0.07
Samsung CLP-770 CLT-M6092S m	0.07
Samsung CLP-770 CLT-Y6092S ye	0.07
Samsung CLT-404S CLT-C404S cy	0.1
Samsung CLT-404S CLT-K404S bla	0.1
Samsung CLT-404S CLT-M404S m	0.1
Samsung CLT-404S CLT-Y404S yel	0.1
Samsung CLT-505L CLT-C505L cy	0.1
Samsung CLT-505L CLT-K505L bla	0.1
Samsung CLT-505L CLT-M505L m	0.1
Samsung CLT-505L CLT-Y505L yel	0.1
Samsung CLT-804S CLT-C804S cy	0.05
Samsung CLT-804S CLT-K804S bla	0.05
Samsung CLT-804S CLT-M804S m	0.05
Samsung CLT-804S CLT-Y804S yel	0.05
Samsung CLT-808S CLT-C808S cy	0.05
Samsung CLT-808S CLT-K808S bla	0.05
Samsung CLT-808S CLT-M808S m	0.05
Samsung CLT-808S CLT-Y808S yel	0.05
Samsung CLT-809S CLT-C809S cy	0.1
Samsung CLT-809S CLT-M809S m	0.1
Samsung CLT-809S CLT-Y809S yel	0.1
Samsung CLT-R804 drum CLT-R8C	0.1
Samsung CLT-R808 drum OPC	0.1
Samsung CLT-R809 drum CLT-R8C	0.1
Samsung M2020 MLT-D111S 11	0.1
Samsung M2625 MLT-D116L 11	0.1
Samsung M2625 MLT-D116S 11	0.1
Samsung M2625 MLT-R116 R11	0.05
Samsung M3320 MLT-D203 20	0.2
Samsung M3320 MLT-D203E 20	0.2
Samsung M3320 MLT-D203L 20	0.2
Samsung M3320 MLT-D203S 20	0.2
Samsung M3325 MLT-R204 R2C	0.2
Samsung M4030 MLT-D201L 20	0.3
Samsung ML-1210	0.02
Samsung ML-1630	0.2
Samsung ML-1630 START	0.2
Samsung ML-1660 MLT-D1042S 1	0.1
Samsung ML-1710	0.02
Samsung ML-1910 MLT-D1052L 1	0.07

Samsung ML-1910 MLT-D1052S 1	0.07
Samsung ML-2010	0.08
Samsung ML-2160 MLT-D101S 1	0.1
Samsung ML-2950 MLT-D103 1	0.2
Samsung ML-2950 MLT-D103L 1	0.2
Samsung ML-2950 MLT-D103S 1	0.2
Samsung ML-3750 MLT-D305L 3	0.2
Samsung ML-3750 MLT-D305S 3	0.2
Samsung ML-4510 MLT-R307 R3	0.2
Samsung ML-5510 MLT-R309 3i	0.2
Samsung MLT-D119S	0.05
Samsung SCX-4100	0.4
Samsung SCX-4200/4300 MLT-D	0.8

TOSHIBA

Toshiba Estudio 385	0.2
Toshiba Estudio 448s/478p	0.1
Toshiba Estudio 520p/525p	0.1

XEROX

Xerox 3020/3025 106R02773	0.6
Xerox 3100 106R01379	0.6
Xerox 3117 106R01159	0.05
Xerox 3119 013R00625	0.5
Xerox 3140 108R00909	0.07
Xerox 3260 650N05409 101R004	0.05
Xerox 3330/35/45 101R00555 OI	0.2
Xerox 3335 650N05434 106R036	0.4
Xerox 3610/15 106R02732 2721	0.4
Xerox 3610/15 113R00773 drum	0.05
Xerox 3655 106R02736/38/40	0.4
Xerox 4250 113R00770 113R007	0.05
Xerox 4600 113R00762 OPC	0.05
Xerox 5019 006R01573	0.02
Xerox 5020 OPC	0.02
Xerox 5222/5500 101R00434/113	0.3
Xerox 5325/5330 006R01158 to	0.2
Xerox 5325/5330 013R00591 OF	0.3
Xerox 6510/6515 105R03488 cr	0.1
Xerox 6600 106R02233 - 52 cmyl	0.02
Xerox 6600 108R01121 cmyk OP	0.02
Xerox 7120 drum 013R00657 bla	0.02
Xerox 7120 drum 013R00658 ye	0.02
Xerox 7120 drum 013R00659 ma	0.02
Xerox 7120 drum 013R00660 cy	0.02
Xerox 7120 toner 006R01461 bl	0.08
Xerox 7120 toner 006R01462 ye	0.08
Xerox 7120 toner 006R01463 m	0.08
Xerox 7120 toner 006R01464 cy	0.08
Xerox 7425 drum 013R00647 O	0.2
Xerox 7500 106R01446/445/444/	0.08
Xerox 7500 108R00861 OPC	0.2

Xerox 7525 drum 013R00662 O	0.2
Xerox 7525 toner 006R01513 bl	0.08
Xerox 7525 toner 006R01514 ye	0.08
Xerox 7525 toner 006R01515 m	0.08
Xerox 7525 toner 006R01516 cy	0.08
Xerox B400 106R03582	0.4
Xerox B600 106R03946	0.4
Xerox B600 DRUM 101R00582	0.4
Xerox C400/405 cmyk	0.03
Xerox C500 black 106R03887	0.05
Xerox C500 cyan 106R03884	0.05
Xerox C500 magenta 106R03885	0.05
Xerox C500 yellow 106R03886	0.05
Xerox C600/605 cmyk 106R03928	0.05