

TECHNICAL INFO Nr. 65


August 5 2015

Bulletin of technical information reserved for Installers and Retailers Landi Renzo

Subject: Directive to install pressure regulator LI10

The installation of the pressure regulator LI10 must observe the following provisions:

- The axis of the solenoid valve of the regulator must be orthogonal to the ground
- The axis of the solenoid valve of the regulator must always be positioned upwards



As shown in the figure, the regulator can be rotated on the axis of the solenoid valve, but it must always be facing upwards.

This technical information integrates and replaces all the provisions of installation schemes and manuals and all new installations must follow this directive

Technical assistance LR remains at your disposal for clarifications.