

# RZ67

## Digital Back Adapter HX701 デジタルバックアダプター HX701



### Instructions 使用説明書

#### ⚠ Caution

- Make sure to install the Adapter to the body securely. If it is loose, the camera may drop and injure you or become damaged.

# Mamiya

100% Recycled Paper

Mamiya Digital Imaging Co., Ltd.

仕様外観は品質向上のために予告なく変更する場合があります。  
Specifications and appearances are subject to change without prior notice.


Printed in Japan  
524320-KL-01-JE

Thank you for purchasing a Mamiya product.

The Digital Back Adapter HX701 allows you to mount and use the Digital Back for Mamiya 645AFDII which is compatible with the MSCE communication system, on the RZ67ProIID camera.

#### Names of the parts


- ① Alignment mark
- ② Back installation bracket (lower)
- ③ Lock knob
- ④ Lock release lever




#### Specifications

The adapter is compatible with the Mamiya Digital Communication System (MSCE). The installation can be either vertical or horizontal -- switch between the vertical and horizontal positions using the rotating mechanism.  
Dimensions: 114 x 114 x 15.4 mm  
Weight: 106g

#### How to attach the Digital Back Adapter HX701



**Before installing**  
Slide the lock release lever ④ on the Digital Back Adapter toward the front and let the lock knob ③ drop down as far as it will go.




Match the orange circle ① on the rotation ring on the back of the body with the film holder alignment mark ② on the camera body.

- ★ When the mark is aligned with the film holder alignment mark ②, the camera will have a horizontal format screen. When the mark is aligned with the position ③, the camera will have a vertical format screen. (See page 39 of the camera manual.)
- ★ The Digital Back Adapter can also be installed when the mark is aligned with the film holder mark ②.

このたびは、マミヤ製品をお買い上げいただきありがとうございます。このデジタルバックアダプターHX701は、RZ67PROIIDのデジタル通信システム(MSCE)に対応し、645AFDIIIに装着可能なMamiya ZD BackをRZ67PROIIDで使用するためのアダプターです。

#### 各部の名称


- ① 取り付け指標
- ② バック取り付け金具 (下)
- ③ ロックつまみ
- ④ ロック解除レバー




#### 仕様

マミヤデジタル通信システム (MSCE) に対応  
タテ、ヨコ位置の切り換え: レボルピング機構によるタテ位置・ヨコ位置の切り換え  
寸法: 114 x 114 x 15.4 mm  
重量: 106g

#### デジタルバックアダプターHX701の取り扱い方




**取り付ける前に**  
デジタルバックアダプターのロック解除レバー④を手前方向にスライドさせて、ロックつまみ③を下方向へいっっぱいに寄せます。



ボディの背面にある回転リング上のオレンジ色の○印①をボディのフィルムホルダー取り付け指標②の位置に合わせます。


- ★ フィルムホルダー取り付け指標②の位置で合わせたときはヨコ画面、③の位置で合わせたときはタテ画面になります。(本冊:P39参照)
- ★ フィルムホルダー取り付け指標②の位置でもデジタルバックアダプターを取り付けることができます。

#### How to install



1. After matching the alignment mark ① (orange circle) on the Digital Back Adapter with the film holder alignment mark ② (orange circle) on the body, adjust the four Digital Back Adapter pins on the camera body.


★ Never touch the light baffle inside the camera with your fingers. If you touch it, you may cause a light leak or faulty operation.



2. While pressing the Digital Back Adapter against the camera body, slide the lock knob ③ in the direction shown by the arrow to lock it in place.

★ Make sure that the Digital Back Adapter is securely installed on the body. If it is not firmly attached, light leaks may occur.


#### How to remove the Digital Back Adapter



Slide the lock release lever on the Digital Back Adapter toward the front and then slide the lock knob on the Digital Back Adapter in the direction shown by the arrow. Then remove the adapter.

★ Hold the Digital Back Adapter firmly in your hand when removing, in order not to drop it.


#### How to install the Digital Back and how to take photos




Match the Digital Back Adapter's installation bracket (lower) with the groove in the corresponding bracket on the lower edge of the Mamiya ZD Back, and press the Mamiya ZD Back against the camera body to secure it. To take a photograph, turn the R-M lever to the M position (multiple exposure) on the camera body.

- ★ To rotate the camera, turn the R-M lever on the body to the R position.
- ★ The HM401 120/220 Roll Film Holder for 645AFDII cannot be used.
- ★ To set up a Digital Back before use, see the Instruction Manual for the Mamiya ZD Back.

#### 取り付け方




1. デジタルバックアダプターの取り付け指標①(オレンジ印)をボディのフィルムホルダー取り付け指標②(オレンジ印)に合わせながら、デジタルバックアダプターの4本のピンに合わせます。  
★カメラ内部の遮光板には、絶対に手を触れないでください。遮光板を指で押したりすると、光モレや作動不良の原因となります。




2. デジタルバックアダプターをボディ側に押し付けながら、ロックつまみ③を矢印方向へスライドさせて固定します。  
★デジタルバックアダプターがボディに確実に接合しているかを必ず、確認してください。浮いた状態で取り付けると撮影すると、光モレの原因となります。

#### 取り外し方



デジタルバックアダプターのロック解除レバーを手前にスライドさせながら、デジタルバックアダプターのロックつまみを矢印方向へスライドさせて取り外します。  
★デジタルバックアダプターを取り外すときは、デジタルバックアダプターに手を添え、落とさないように注意してください。

#### デジタルバックの取り付け方/撮影



アダプターのバック取り付け金具(下)にMamiya ZD Back下部の取り付け金具の溝を合わせて、Mamiya ZD Backをボディ側に押し付けて固定します。撮影するときは、ボディのRM切り換えレバーをM位置(多重露光)にセットして撮影します。

- ★レボルピングするときは、ボディのRM切り換えレバーをR位置にします。
- ★645AFDII用の120/220ロールフィルムホルダーHM401は使用できません。
- ★ご使用になるデジタルバックの設定等は、デジタルバックの説明書をご覧ください。

100% Recycled Paper

Mamiya Digital Imaging Co., Ltd.

仕様外観は品質向上のために予告なく変更する場合があります。  
Specifications and appearances are subject to change without prior notice.

Printed in Japan  
524320-KL-01-JE

# Mamiya

### 使用説明書 Instructions

#### ⚠ 注意

- デジタルバックアダプターの取り付けは確実に行ってください。きちんと止まっていないと落下による製品の破損の原因になります。