



SWITCHES

Plug	Pin	Description
A	b/c	ENG1 FIRE SW
C	b/c	ENG2 FIRE SW
F	R/S	APU FIRE SW
A	F/G	AGENT 1 ENG1 SW
B	F/G	AGENT 2 ENG1 SW
D	F/G	AGENT 1 ENG2 SW
C	F/G	AGENT 2 ENG2 SW
E	F/G	AGENT APU SW
A	M/N	ENG1 TEST SW
D	M/N	ENG2 TEST SW
E	M/N	APU TEST SW

LIGHTS

Plug	Pin	Description
E	Z/a	BACKLIGHT
A/B	A/B	ENG1 FIRE LT
C/D	A/B	ENG2 FIRE LT
E/F	A/B	APU FIRE LIGHT

The following Pin-Out for the Plugs A/B/C/D/E are the same!

5VDC Power for all AGENT Korrswitches!

Pin	Description
C	+5VDC
D	GND
L	GND for LIGHTTEST (will light booth Korrylights)

28VDC Power for Relays-Logic of all AGENT Korrswitches

Pin	Description
M	+28VDC DISCH LT
H	+28VDC SQUIB LT*. ->FOR PLUG E not necessary
E	GND

*Will light only with popped „FIRE PUSH“ Button!