ABOUT THE

FOLDABLE
Moravian Star

For many years, the Moravian Star has been a favorite decoration appropriate for the Advent and Christmas Seasons, the first having been made in the Moravian settlement of Niesky, Germany around 1850. Today, these stars shine in homes, schools, and churches in many parts of the world.

The Moravian Star is a reminder of the star that led the Wise Men from their home in the distant east to Bethlehem, where they presented gifts to the baby Jesus.


CAUTION

- Only use an LED bulb with Moravian Star.

- As with most electrical appliances, electrical parts in this star are electrically live. Please use caution.

- Minimize exposure to water. Be aware of sharp points. Keep out of reach of children.

- If hanging star unsupported from overhead socket, it may be necessary to secure the fixture with heavy twine to prevent weight of the star from pulling the plug from the socket.

- E12 lampholder, G50 LED 1.5W, warm white color bulb.

Elf Logic ®

FOLDABLE
Moravian Star

WITH BATTERY TIMER

www.elflogic.com

FOLDABLE
Moravian Star

WITH BATTERY TIMER

PARTS LIST

A - Moravian star

B - Light bulb socket

C - Fastener

D - Bulb

E - Battery timer

INSTRUCTIONS

STEP 1 Loop light bulb socket (B) under bracket (A) with the cord side of the socket facing towards the inside of the bracket. Rest socket in divet located inside the star unit (A). Put fastener over bulb casing and clip onto plastic frame of star to hold light bulb in place (this step is optional, and fastener is only available on some models).

STEP 2 Screw light bulb into the light bulb socket.

STEP 3 Swing handle 1 and handle 2, located inside star unit, out and around until they are touching.

STEP 4 Once the two handles have met, use the two clasps to secure the handles and connect the two sides.

STEP 5 Insert batteries into the battery timer. The timer system is designed to light up for 6 hours and turn off for 18 hours.

> a. If you would like to use the timer, press the button at the top of the battery timer. The ball will light up and stay on for 6 hours and turn off for 18 hours, repeating the process.

> b. If you wish to simply turn on the light ball, press the button twice.

> c. If you want to turn off the light ball, press the button three times.

STEPS 1-2

STEP 3

STEP 4

Elf Logic ®