


Document number: pe00_19-p-2300-97tb
Document title: Wiring diagram for interior CAN bus

Code:	Designation:	Position:
A0	Explanation of color codes	
A1	Instrument cluster	2L
A2	Radio	37L
A2	Radio	
A2/56	Radio and navigation unit	
A40/3	COMMAND operating, display and control module	
N10/1	Driver-side SAM control module with fuse and relay module	27L
N18	HEAT pushbutton control module	16L
N22	AAC pushbutton control module	20L
N22/7	Comfort AAC pushbutton control module	20L
N52	Power soft top control module	33L
N72/1	Upper control panel control module	23L
N73	EIS [EZS] control unit	6L
N80	Steering column module	12L
N93	Central gateway control module	9L
U1	Valid for {[USA]}	35F
U29	Valid for AAC [KLA]	18E
U33	Valid for all except {[USA]} {[Japan]}	35F
U550	Valid for HEAT [HAU]	14E
U673	Valid for Comfort AAC [K-KLA]	18F
X30/5	Left voltage distributor (CAN) connector	4A
X30/5	Left voltage distributor (CAN) connector	12A
X30/5	Left voltage distributor (CAN) connector	20A
X30/5	Left voltage distributor (CAN) connector	28A
X30/5	Left voltage distributor (CAN) connector	36A
X30/6	Cockpit voltage distributor (CAN) connector	30L






X30/5

X30/5

X30/5



cut here

Affix page 3 here

