

# Barbasol®

## Rechargeable Wet & Dry Shaver



### USE AND CARE GUIDE (For model: CBR1-1001)

Manufactured under exclusive license of Perio Inc. ©Barbasol

#### **PLEASE RETAIN THIS USER GUIDE FOR FUTURE REFERENCE**

When using an electrical appliance, basic precautions should always be observed. Read all instructions before using this shaver.

#### **DANGER**

To reduce the risk of electric shock:

1. Do not reach for an appliance that has fallen into water. Unplug it immediately.
2. Do not charge while bathing or in the shower.
3. Do not charge this unit near a tub, toilet or sink.

#### **WARNING/IMPORTANT**

1. Read the instruction manual thoroughly before using the device.
2. Use the shaver only for purposes described in this instruction book.
3. For the hygienic reason, the shaver should not be shared with others.
4. This appliance is not intended for use by persons (including children) with reduced physical sensory or mental capabilities, or lack of experience and knowledge.
5. Regularly check the foil condition, if signs of damage are visible, do not use.
6. Do not use if skin is red, irritated, inflamed, infected or blistered.
7. Foils and blades will wear over time and may require replacing.
8. This product is for household use only.
9. Do not place or store your unit in direct sunlight. Store only in a cool dry place.
10. Keep your unit out of reach of children.
11. Do not charge the shaver where the temperature is below (32 °F), or higher than (100 °F), or where it will be exposed to direct sunlight or a heat source, or near excessive moisture.
12. Use the included charging cord only.
13. Dry the shaver completely before charging it.
14. Keep the charging cord away from water and handle with dry hands.
15. Do not pull, twist, or severely bend the cord.

16. Do not wrap the power cord tightly around the appliance.

17. Do not take the housing apart.

#### **CHARGING**

1. Prior to first use, charge for 12 hours.
2. Regular Shaving will require 12 hours charging time for 60 minutes of runtime. Usage time may decrease over time.
3. Do not overcharge, as this may damage the battery life.
4. The shaver will not charge when it is switched on. Be sure to check that the "On/Off switch" is set to "Off" when charging.

#### **SHAVING**

##### **HOW TO USE**

1. Switch on by pushing the on/off switch.
2. Hold the shaver at a right angle to your skin.
3. Apply gentle pressure as you move the shaver across your face, stretching the skin with your free hand. Move the shaver back and forth to achieve the desired result.
4. Applying excessive pressure will not result in a closer shave and may cause irritation or skin damage.
5. To use the beard trimmer, slide the trimmer handle up to open the trimmer, place the trimmer at a right angle to your skin and move it down to trim sideburns.

#### **STORAGE**

Always store this appliance and adaptor in a moisture-free area.

#### **CLEANING**

Press the "Head Removal Catch" to release the "Head Cover". Remove any hair debris after each use using the brush provided.

Rinse the "Head Cover" only under running water and dry thoroughly with a towel.

**DO NOT REMOVE THE BATTERY.**

#### **ENVIRONMENT PROTECTION**

NOTE! The battery the appliance is equipped with contains substances, which may result in environmental pollution.



Do not dispose of the appliance. Please take all WEEE marked waste to your local recycling center for proper disposal.

## 2 Year Limited Warranty

Questions: call toll-free at 877- 536-8766

Email Support: [customerservice@xtremecables.com](mailto:customerservice@xtremecables.com)

This product is covered under warranty for a period of 2 years from the purchase date. Improper use or failure to follow operation and instruction guide will void this warranty. Do not return to the store. Please send a proof of purchase, return label with your name and address, along with a check for \$4.95 to cover S/H. Please allow 6-8 weeks to process your return.

Make check payable to Xtreme Personal Care, Inc.

Clip & Return to:  
Xtreme Personal Care  
32 Brunswick Ave.  
Edison NJ 08817  
Att: Customer Service

Customer Name \_\_\_\_\_

Return Address \_\_\_\_\_

Date Purchased \_\_\_\_\_

Store \_\_\_\_\_

Brief Description of Issue \_\_\_\_\_