## **RESOLVE LEXIA 3 VCI NO CONNECTION PROBLEM**

## **Matched Product**



## Lexia 3 PP2000 PSA XS Evolution Peugeot Citroen Diagnostic Tool

Buy it Now: **\$69.80** 

Click Here to Shop 📀

Brief Description: Lexia 3 PP2000 PSA XS Evolution Peugeot Citroen Diagnostic Tool with latest Diagbox 7.52 works with both Citroen and Peugeot. It is...

## Description

This article is tell you Why there will be NO VCI FOUND problem in Lexia 3 PSA diagnose tool. And how to resolve the problem.

VCI NO FOUND and can not connect to car or laptop.

Sometimes we get VCI NO FOUND problem when we use LEXIA 3 PSA DIAGNOSE to test car.

Especially at the first time we use it. That is because of following 2 reasons.

1. The laptop did not install drivers for Lexia 3 VCI when you connect it to laptop.

2.The version of APPLICATION(firmware) does not match the version of diagbox. For example the diagbox 7.49 needs APPLICATION to be 4.3.2. You can not connect VCI to laptop or car if your APPLICATION is 4.3.0.

Firstly, we resolve the problem #1.

Install diagbox and connect Lexia 3 VCI to laptop by USB cable. You will see the green led on VCI blink 3 times.

And then we go to next step.

Install INTERFACE CHECKER INSTALL from DVD.



You will get 2 small programmers, INTERFACE CHECKER and INTERFACE INSTALL

Open the INTERFACE INSTALL and install drivers for Lexia 3 VCI Step by Step (Please shut down internet and anti-virus software before installing drivers). The VCI maybe has problem if you can not install driver successfully.

Open the interface checker after installing driver and click ACTIVATE. You will see the version of your VCI such as application, series number and so on.

PSA Interface Checker. V 3	Scarymistake	×
Version of the current application: Version APPLI_XS_Fuji_ P106138		ACTIVATE
Reference Serial:	1.5.2 Grief in 65.61.11	Quit
Reference 921815 C/	Inconnue	
Version of the selected file (APPLI.com): Select File		
Download the Flash App:		
Downloading		DIAGBOX
INIT OK Majcon	n 3, 1, 1, 0 / Gestcomm 3, 1, 1, 0	

That means you already connect VCI to your laptop.

Secondly, for resolving the APPLICATION problem.

Please kindly contact us (under condition of you bought VCI from us). We can help you update the application by remote control of team viewer.

We do hope that article will help you!

OBDMORE.COM

More related topic FAQ OF INSTALL AND USING VOLVO VIDA DICE SOFTWARE Mercedes star diagnose c4 firmware updating OBDMORE Updated Renault CAN Clip Software to V149 Version