
# XT-ONE How to replace the incline system service kit instructions









#### SERVICE KIT CONTENTS (P/N 113200-001)



#2 Phillips screwdriver 4mm hex wrench

13mm wrench

clean mobil cloth lithium grease


small brush

flat head cutters screwdriver (optional)


wire

#### **STEPS**

1. To access the incline column and tube, press Quick Start Hike.




# standard console



smart console






**NOTE:** For standard consoles you need to pedal the machine. Once the incline is at 5 you can stop pedaling.

If you have an incline error 40, press and hold **PAUSE CLEAR** for three seconds to clear the error. Once the error is clear, start pedaling and press **Quick Start Hike**. You may have to repeat this procedure a few times if the error keeps returning.

**NOTE:** For smart consoles, once the incline is at 5 you need to disconnect the power. Disconnecting the power shuts down the console and keeps the incline set at 5.


2. Remove the top shroud.








3. Disconnect the battery.




4. If center cable tie is present, snip cable tie and apply DO NOT GREASE labels to both sides of the frame as shown. If needed, use cable ties provided with this kit to secure any loose cables.





#### **IMPORTANT!**


**DO NOT GREASE THE INCLINE LEAD SCREW.** THE NEW ASSEMBLY CONTAINS A FRICTION WASHER THAT MUST STAY CLEAN AND DRY. IF THE FRICTION WASHER GETS GREASY, IT COULD COME LOOSE AND JAM THE MECHANISM.








5. Remove the incline clevis covers.



6. Remove and discard the incline tube column hardware: right side followed by left side, and then gently rest the incline column on the pedal.



6

4mm hex wrench


13mm wrench

flat head screwdriver (optional)






7. Remove and discard incline screw frame hardware.






8. Remove and discard faulty incline extension tube and screw assembly.








9. Install new incline extension tube and screw assembly. Verify incline switch bracket is on the right side as shown.



10. Grease swivel shafts on both sides of the incline extension tube assembly as shown.











11. Fasten the incline extension tube and screw to the frame using the frame hardware provided with this kit.





12. Grease the pivot spacers and washers and assemble the hardware as shown.











13. Align the incline column with the extension tube and attach the hardware as shown.








14. Reattach the incline clevis covers.



15. Reconnect the battery.









16. For smart consoles: reconnect the power. If the console has a power switch on the back of the console, press the power on/off switch. If the console does not have a power switch, the console powers on automatically. When the console boots up, press Quick Start Walk, wait for the incline to adjust down to 1 and then press Quick Start Climb. Verify the incline is smoothly adjusting and the machine is operating as intended.

For **standard consoles**: pedal the machine and then press **Quick Start Walk**, wait for the incline to adjust down to 1 and then press **Quick Start Climb**. Verify the incline is smoothly adjusting and the machine is operating as intended.



17. Reattach the top shroud.



# **Questions? Contact Octane Fitness Service and Support**

## USA/CANADA

1-888-975-1376

customerservice@octanefitness.com

Octane Fitness Headquarters 7601 Northland Drive North, Suite 100 Brooklyn Park, MN 55428

#### LATIN AMERICA

001-763-757-2662 LAService@octanefitness.com

### **ASIA PACIFIC**

001-763-757-2662 APService@octanefitness.com

#### Mark Brue | Customer Service Manager

+1 763-230-3023

mbrue@octanefitness.com



#### EUROPE/MIDDLE EAST/AFRICA

31-10-2662412

EMEAService@octanefitness.com

Octane Fitness International Headquarters Rivium Westlaan 19 2909 LD, Capelle a/d Ijssel The Netherlands

# Frank van Waveren | Service and Support Coordinator

+31 10 266 2412

fvanwaveren@octanefitness.com



#### **UNITED KINGDOM**

0800 088 5540 UKService@octanefitness.com

Octane Fitness UK Ltd. Friary Court 1321 High Street Guilford GU1 3DL United Kingdom